

Service Training

# FT65 - FENDT introductory course

## Vario series



FT65

Marktobendorf  
AGCO GmbH - Johann-Georg-Fendt-Str. 4 - D-87616 Marktobendorf  
FENDT is a worldwide brand of AGCO  
© AGCO 2016

September 2016  
5047  
EAME  
English

## Subject to changes and additions

### IMPORTANT:

*This document is valid from the chassis number noted. The last valid chassis number could not be determined at the time of creation. Use AGCONET or contact FENDT Technical Service to ascertain whether a current wiring diagram set is available with an updated chassis number range.*

Due to further developments to the vehicle, the content of this document is subject to change.

The relevant accident prevention regulations must be observed, as must as any generally acknowledged safety, industrial medicine and traffic regulations. The manufacturer does not accept liability for damage resulting from unauthorized modifications to the machine.

**Property of AGCO GmbH.**

**Any disclosure to third parties—either in return for payment or free of charge—is prohibited.**

# FT65 - FENDT introductory course - Vario series



1-1	1 Safety briefing
1-3	1.1 Safety briefing
1-3	1.1.1 Safety briefing
2-1	2 Presentation
2-3	2.1 Technical specification
2-3	2.1.1 Overview of current Fendt wheeled tractor models
2-13	2.1.2 Overview of technical data for 200 Vario S3 to 1000 Vario S4
2-20	2.1.3 Maintenance schedule
2-27	2.2 Faults
2-27	2.2.1 Structure of fault codes
2-28	2.2.2 Confirming, calling up, deleting fault codes
2-30	2.2.3 Fault code 00.0.00
2-34	2.2.4 Fault code 04.1.00
2-45	2.2.5 Fault code 0A.1.00
2-57	2.2.6 Fault code 1D.0.00
2-68	2.2.7 General information on calibration
2-72	2.2.8 Calibration code 1001 (crossgate lever)
2-77	2.2.9 Calibration code 7666 (front axle suspension)
2-80	2.2.10 Calibration code 4001 (clutch pedal)
2-82	2.2.11 Calibration code 4002 (hand throttle)
2-85	2.2.12 Calibration code 4003 (travel speed range selector)
2-88	2.2.13 Calibration code 4005 (foot throttle/accelerator pedal)
2-90	2.2.14 Calibration code 4007 (transmission ratio characteristic)
2-95	2.2.15 Calibration code 4009 (turbo-clutch function)
2-98	2.2.16 Calibration code 4010 (accelerator pedal resolution)
2-101	2.2.17 Calibration fault codes
3-1	3 Operation
3-3	3.1 Operating controls
3-3	3.1.1 Instrument panel
3-4	3.1.2 Operating status display
3-5	3.1.3 Multiple display
3-7	3.1.4 Control panel
3-11	3.1.5 Joystick
3-17	3.2 Other operating controls for 700 Vario S4
3-17	3.2.1 Multifunction armrest keypad
3-18	3.2.2 Dashboard
3-19	3.2.3 EPC operating controls
3-21	3.2.4 Safety switch
3-21	3.2.5 Crossgate lever and linear module
3-23	3.3 Terminal
3-23	3.3.1 Terminal overview
3-24	3.3.2 Terminal display
3-25	3.3.3 External control panel
3-26	3.3.4 Page layout and screen allocation
3-27	3.3.5 Menu overview of tractor operation
3-33	3.3.6 Information regarding terminal simulation
3-33	3.3.7 Tasks for terminal settings
FT65 - FENDT introductory course - Vario series	

4-1	<b>4 motor</b>
4-3	<b>4.1 Fuel system</b>
4-3	4.1.1 Fuel system
4-5	4.1.2 Diesel high-pressure pump: Bosch CP 4.1
4-9	<b>4.2 Exhaust gas system</b>
4-9	4.2.1 Exhaust after-treatment
4-12	4.2.2 CSF particulate filter (reduction of soot particles)
4-13	4.2.3 SCR catalytic converter
5-1	<b>5 Vario transmission</b>
5-3	<b>5.1 Function</b>
5-3	5.1.1 Transmission control system functional sequence
5-6	5.1.2 Transmission function diagram
5-11	5.1.3 Transmission diagram ML400
5-13	<b>5.2 Emergency mode</b>
5-13	5.2.1 Driving in emergency mode
5-19	5.2.2 Towing
6-1	<b>6 Electrical system/electronics</b>
6-3	<b>6.1 Procedure</b>
6-3	6.1.1 Button & switch functionality
6-8	6.1.2 Hall sensor operation
6-14	6.1.3 Rotary position sensor function, when used as a current divider
6-20	<b>6.2 Measure and test</b>
6-20	6.2.1 Measure and test
6-26	6.2.2 Component position
6-28	<b>6.3 CAN BUS</b>
6-28	6.3.1 Description of CAN bus system
6-29	6.3.2 FENDT 300 Vario S4 electronics concept - Profi/ProfiPlus
7-1	<b>7 Hydraulics</b>
7-3	<b>7.1 Basics</b>
7-3	7.1.1 Task sheet: Hydraulic pumps
7-4	7.1.2 Basic hydraulic systems
7-7	7.1.3 Task sheet: Carry out hydraulic measurement

**FENDI**



# 1. Safety briefing

<b>1.1 Safety briefing</b> .....	<b>1-3</b>
1.1.1 Safety briefing .....	1-3





## 1.1 Safety briefing

### 1.1.1 Safety briefing

<b>Contractor:</b>	See supplementary sheet (list of participants as per supplementary sheet)
<b>Project:</b>	Training course at the Technical Service training center
<b>Instructor:</b>	Training leader

Reference has been made to:

**Compliance with the relevant accident prevention regulations**

**Local conditions**

(workplace environment, emergency exit routes, fire extinguishers, switch boxes, extraction systems)

**Responsibilities**

(First-aiders)

**Fire prevention**

**Separation of waste**

**Personal protective equipment**

**Cleanliness and tidiness**

**Traffic on the work premises/training premises**

**Restriction of access for other branches of industry**

**No smoking or alcohol**

**Working under specific risk**

Measurements on running machines — "Operator's Manual MOD\_081"

**Working on working platforms**

**Driving the tractor**

In front of the training building/on the circuit — "work instruction MOD 86-10A"

**NOTE:**

Due to the employment of the instructor, neither the contractor nor its representatives are responsible for work safety within the training center.

**Important telephone numbers:**

<b>Rescue:</b>		7777
<b>Emergency medics:</b>		210
<b>First aiders in the training center:</b>		901 Mr Porer 905 Mr Haf

By signing here, the signatory confirms within the role of contractor that the contents of the training will be disseminated accordingly among the employees of the contractor.

211		<b>Fire:</b>
7632 Mr Einsiedler		<b>Fire warden:</b>
0175229775		
245		<b>Gate:</b>





## 2. Presentation

<b>2.1 Technical specification</b>	<b>2-3</b>
2.1.1 Overview of current Fendt wheeled tractor models	2-3
2.1.2 Overview of technical data for 200 Vario S3 to 1000 Vario S4	2-13
2.1.3 Maintenance schedule	2-20
<b>2.2 Faults</b>	<b>2-27</b>
2.2.1 Structure of fault codes	2-27
2.2.2 Confirming, calling up, deleting fault codes	2-28
2.2.3 Fault code 00.0.00	2-30
2.2.4 Fault code 04.1.00	2-34
2.2.5 Fault code 0A.1.00	2-45
2.2.6 Fault code 1D.0.00	2-57
2.2.7 General information on calibration	2-68
2.2.8 Calibration code 1001 (crossgate lever)	2-72
2.2.9 Calibration code 7666 (front axle suspension)	2-77
2.2.10 Calibration code 4001 (clutch pedal)	2-80
2.2.11 Calibration code 4002 (hand throttle)	2-82
2.2.12 Calibration code 4003 (travel speed range selector)	2-85
2.2.13 Calibration code 4005 (foot throttle/accelerator pedal)	2-88
2.2.14 Calibration code 4007 (transmission ratio characteristic)	2-90
2.2.15 Calibration code 4009 (turbo-clutch function)	2-95
2.2.16 Calibration code 4010 (accelerator pedal resolution)	2-98
2.2.17 Calibration fault codes	2-101



## 2.1 Technical specification

### 2.1.1 Overview of current Fendt wheeled tractor models

Tractor: FENDT - series 200 V,F,P Vario			
Model	Chassis number	Emission levels	Equipment
207	232/.../ (V) 239/.../ (F)	S3 Tier 3b EU (2017)	Vario joystick, Profi joystick
208	233/.../ (V) 240/.../ (F)	S3 Tier 3b EU (2017)	Vario joystick, Profi joystick
209	234/.../ (V) 241/.../ (F)	S3 Tier 3b EU (2017)	Vario joystick, Profi joystick
210	235/.../ (V) 242/.../ (F)	S3 Tier 3b EU (2017)	Vario joystick, Profi joystick
211	236/.../ (V) 243/.../ (F)	S3 Tier 3b EU (2017)	Vario joystick, Profi joystick
	253/.../ (P)		

Tractor: FENDT - series 200 S Vario			
Model	Chassis number	Emission levels	Equipment
207	300/.../	S3 Tier 3b EU (2017)	
208	301/.../	S3 Tier 3b EU (2017)	
209	302/.../	S3 Tier 3b EU (2017)	
210	303/.../	S3 Tier 3b EU (2017)	
211	304/.../	S3 Tier 3b EU (2017)	

Tractor: FENDT - series 300 Vario			
Model	Chassis number	Emission levels	Equipment
<b>310</b>	<b>347/2/1/...</b> (Professional) 347/21/ from 5001 (type approval "Mother Regulation") <b>347/23/...</b> (Power) 347/23/ from 5001 (type approval "Mother Regulation")	<b>S4</b> (Level 4, Tier 4f); EU	Power, Profi, ProfiPlus
<b>311</b>	<b>348/2/1/...</b> (Professional) 348/21/ from 5001 (type approval "Mother Regulation") <b>348/23/...</b> (Power) 348/23/ from 5001 (type approval "Mother Regulation")	<b>S4</b> (Level 4, Tier 4f); EU	Power, Profi, ProfiPlus
<b>312</b>	<b>349/2/1/...</b> (Professional) 349/21/ from 5001 (type approval "Mother Regulation") <b>349/23/...</b> (Power) 349/23/ from 5001 (type approval "Mother Regulation")	<b>S4</b> (Level 4, Tier 4f); EU	Power, Profi, ProfiPlus
<b>313</b>	<b>350/2/1/...</b> (Professional) 350/21/ from 5001 (type approval "Mother Regulation") <b>350/23/...</b> (Power) 350/23/ from 5001 (type approval "Mother Regulation")	<b>S4</b> (Level 4, Tier 4f); EU	Power, Profi, ProfiPlus



Tractor: FENDT - series 500 Vario			
Model	Chassis number	Emission levels	Equipment
512	435/21/... (Professional) 435/21/ from 5001 (type approval "Mother Regulation") 435/23/... (Power) 435/23/ from 5001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); EU	Power, PowerPlus, Profi, ProfiPlus
	435/22/... (Professional) 435/22/ from 5001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); NA	Profi, ProfiPlus
513	436/21/... (Professional) 436/21/ from 5001 (type approval "Mother Regulation") 436/23/... (Power) 436/23/ from 5001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); EU	Power, PowerPlus, Profi, ProfiPlus
	436/22/... (Professional) 436/22/ from 5001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); NA	Profi, ProfiPlus
514	437/21/... (Professional) 437/21/ from 5001 (type approval "Mother Regulation") 437/23/... (Power) 437/23/ from 5001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); EU	Power, PowerPlus, Profi, ProfiPlus

Tractor: FENDT - series 700 Vario			
Model	Chassis number	Emission levels	Equipment
<b>714</b>	<b>738/21/...</b> (Professional) 738/21/ from 6001 (type approval "Mother Regulation") <b>738/23/...</b> (Power) 738/23/ from 6001 (type approval "Mother Regulation")	<b>S4</b> (Level 4, Tier 4f); EU	Power, PowerPlus, Profi, ProfiPlus
	<b>738/22/...</b> (Professional) 738/22/ from 6001 (type approval "Mother Regulation")	<b>S4</b> (Level 4, Tier 4f); NA	Profi, ProfiPlus
	<b>738/25/...</b> (Professional) 738/25/ from 6001 (type approval "Mother Regulation")	<b>EEA</b> (G3) Russia	Profi, ProfiPlus

Tractor: FENDT - series 500 Vario			
Model	Chassis number	Emission levels	Equipment
<b>516</b>	<b>438/21/...</b> (Professional) 438/21/ from 5001 (type approval "Mother Regulation") <b>438/23/...</b> (Power) 438/23/ from 5001 (type approval "Mother Regulation")	<b>S4</b> (Level 4, Tier 4f); EU	Power, PowerPlus, Profi, ProfiPlus
	<b>438/22/...</b> (Professional) 438/22/ from 5001 (type approval "Mother Regulation")	<b>S4</b> (Level 4, Tier 4f); NA	Profi, ProfiPlus
	<b>437/22/...</b> (Professional) 437/22/ from 5001 (type approval "Mother Regulation")	<b>S4</b> (Level 4, Tier 4f); NA	Profi, ProfiPlus

Tractor: FENDT - series 700 Vario				
Model	Chassis number	Emission levels	Equipment	
716	739/21/... (Professional) 739/21/ from 6001 (type approval "Mother Regulation") 739/23/... (Power) 739/23/ from 6001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); EU	Power, PowerPlus, Profi, ProfiPlus	
	739/22/... (Professional) 739/22/ from 6001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); NA	Profi, ProfiPlus	
	739/25/... (Professional) 739/25/ from 6001 (type approval "Mother Regulation")	EEA (G3) Russia	Profi, ProfiPlus	
	718	740/21/... (Professional) 740/21/ from 6001 (type approval "Mother Regulation") 740/23/... (Power) 740/23/ from 6001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); EU	Power, PowerPlus, Profi, ProfiPlus
717	740/22/... (Professional) 740/22/ from 6001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); NA	Profi, ProfiPlus	
	740/25/... (Professional) 740/25/ from 6001 (type approval "Mother Regulation")	EEA (G3) Russia	Profi, ProfiPlus	
	720	741/21/... (Professional) 741/21/ from 6001 (type approval "Mother Regulation") 741/23/... (Power) 741/23/ from 6001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); EU	Power, PowerPlus, Profi, ProfiPlus
	741/22/... (Professional) 741/22/ from 6001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); NA	Profi, ProfiPlus	

Tractor: FENDT - series 700 Vario			
Model	Chassis number	Emission levels	Equipment
722	742/21/... (Professional) 742/21/ from 6001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); EU	Power, PowerPlus, Profi, ProfiPlus
	742/23/... (Power) 742/23/ from 6001 (type approval "Mother Regulation")		
724	743/21/... (Professional) 743/21/ from 6001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); EU	Power, PowerPlus, Profi, ProfiPlus
	743/23/... (Power) 743/23/ from 6001 (type approval "Mother Regulation")		
724	743/22/... (Professional) 743/22/ from 6001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); NA	Profi, ProfiPlus
	743/25/... (Professional) 743/25/ from 6001 (type approval "Mother Regulation")	EEA (G3) Russia	Profi, ProfiPlus

Tractor: FENDT - series 800 Vario			
Model	Chassis number	Emission levels	Equipment
822	839/21 or 23/... (1-circuit/2-circuit)	S4 (Level 4, Tier 4f); EU	Power, PowerPlus, Profi, ProfiPlus
	839/21 or 23/... from 5001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); NA	
	839/22,24/... from 5001 (type approval "Mother Regulation")	EEA (G3) Russia	
824	840/21,23/... (1-circuit/2-circuit)	S4 (Level 4, Tier 4f); EU	Power, PowerPlus, Profi, ProfiPlus
	840/22,24/... from 5001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); NA	
	840/25,26/... from 5001 (type approval "Mother Regulation")	EEA (G3) Russia	
826	841/21,23/... (1-circuit/2-circuit)	S4 (Level 4, Tier 4f); EU	Power, PowerPlus, Profi, ProfiPlus
	841/22,24/... (1-circuit/2-circuit)	S4 (Level 4, Tier 4f); NA	
	841/25,26/... (1-circuit/2-circuit)	EEA (G3) Russia	

Tractor: FENDT - series 900 Vario			
Model	Chassis number	Emission levels	Equipment
<b>927</b>	950/21,23/... (1-circuit/2-circuit) (type approval "Mother Regulation") 950/21,23/... from 5001	<b>S4</b> (Level 4, Tier 4f); EU	Power, PowerPlus, Profi, ProfiPlus
	950/22,24/... (1-circuit/2-circuit) (type approval "Mother Regulation") 950/22,24/... from 5001		
	950/25,26/... (1-circuit/2-circuit) (type approval "Mother Regulation") 950/25,26/... from 5001		
	950/25,26/... (1-circuit/2-circuit) (type approval "Mother Regulation") 950/25,26/... from 5001		
<b>930</b>	951/21,23/... (1-circuit/2-circuit) (type approval "Mother Regulation") 951/21,23/... from 5001	<b>S4</b> (Level 4, Tier 4f); EU	Power, PowerPlus, Profi, ProfiPlus
	951/22,24/... (1-circuit/2-circuit) (type approval "Mother Regulation") 951/22,24/... from 5001		
	951/22,24/... (1-circuit/2-circuit) (type approval "Mother Regulation") 951/22,24/... from 5001		
	951/22,24/... (1-circuit/2-circuit) (type approval "Mother Regulation") 951/22,24/... from 5001		

Tractor: FENDT - series 800 Vario			
Model	Chassis number	Emission levels	Equipment
<b>828</b>	842/21,23/... (1-circuit/2-circuit) (type approval "Mother Regulation") 842/21,23/... from 5001	<b>S4</b> (Level 4, Tier 4f); EU	Power, PowerPlus, Profi, ProfiPlus
	842/22,24/... (1-circuit/2-circuit) (type approval "Mother Regulation") 842/22,24/... from 5001		
	842/25,26/... (1-circuit/2-circuit) (type approval "Mother Regulation") 842/25,26/... from 5001		
	842/25,26/... (1-circuit/2-circuit) (type approval "Mother Regulation") 842/25,26/... from 5001		

Tractor: FENDT - series 900 Vario			
Model	Chassis number	Emission levels	Equipment
933	951/25,26/... (1-circuit/2-circuit) 951/25,26/... from 5001 (type approval "Mother Regulation")	EEA (G3) Russia	
	952/21,23/... (1-circuit/2-circuit) 952/21,23/... from 5001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); EU	Power, PowerPlus, Profi, ProfiPlus
	952/22,24/... (1-circuit/2-circuit) 952/22,24/... from 5001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); NA	
936	952/25,26/... (1-circuit/2-circuit) 952/25,26/... from 5001 (type approval "Mother Regulation")	EEA (G3) Russia	
	953/21,23/... (1-circuit/2-circuit) 953/21,23/... from 5001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); EU	Power, PowerPlus, Profi, ProfiPlus
	953/22,24/... (1-circuit/2-circuit) 953/22,24/... from 5001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); NA	
939	953/25,26/... (1-circuit/2-circuit) 953/25,26/... from 5001 (type approval "Mother Regulation")	EEA (G3) Russia	
	954/21,23/... (1-circuit/2-circuit) 954/21,23/... from 5001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); EU	Power, PowerPlus, Profi, ProfiPlus

Tractor: FENDT - series 1000 Vario			
Model	Chassis number	Emission levels	Equipment
1038	527/23/... 527/23/... from 5001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); EU	PowerPlus, Profi, Profi-Plus
	527/24/... 527/24/... from 5001 (type approval "Mother Regulation")		
	527/26/... 527/26/... from 5001 (type approval "Mother Regulation")		
1042	528/23/... 528/23/... from 5001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); EU	PowerPlus, Profi, Profi-Plus
	528/24/... 528/24/... from 5001 (type approval "Mother Regulation")		
	528/26/... 528/26/... from 5001 (type approval "Mother Regulation")		
1046	529/23/... 529/23/... from 5001 (type approval "Mother Regulation")	S4 (Level 4, Tier 4f); EU	PowerPlus, Profi, Profi-Plus
	529/24/... 529/24/... from 5001 (type approval "Mother Regulation")		
	529/26/... 529/26/... from 5001 (type approval "Mother Regulation")		



Tractor: FENDT - series 1000 Vario			
Model	Chassis number	Emission levels	Equipment
1050	530/23/...	S4 (Level 4, Tier 4f); EU	PowerPlus, Profi, Profi-Plus
	530/24/...	S4 (Level 4, Tier 4f); NA	
	530/26/...	EEA (G 3) Russia	
	530/26/... (type approval "Mother Regulation")		

## 2.1.2 Overview of technical data for 200 Vario S3 to 1000 Vario S4

### Technical data for 200 Vario V/F/P S3

Technical data for 200 Vario V/F/P S3					
Model	Rated power ECE R 120	Motor			
V/F/P 207	V/F/P 208	V/F/P 209	V/F/P 210	V/F/P 211	
53 kW / 72 HP	60 kW / 81 HP	67 kW / 91 HP	73 kW / 99 HP	74 kW / 101 HP	
AGCO Power 3-cylinder 33 A/Wl, water-cooled with turbocharger					
Injection type/emissions optimisation					
Common rail/EGR/DOC					
Displacement/rated engine speed					
3.3 l/2100 rpm					
Gearbox type (drive train)					
Infinitely variable Vario gearbox (ML70)					
Rear axle/rear brakes					
HA70/ring piston brake					
Driving range (forwards/reverse)					
AWD: 0,02 km/h to 40 km/h/0,02 km/h to 25 km/h					
Maximum speed					
40 km/h   40 km/h   40 km/h   40 km/h   40 km/h					
Front axle					
Manufacturer/axle type					
Planetary steering axle (DANA)/rigid axle					
Spring travel					
± 40 mm					
Hydraulics					
Type					
Electrohydraulic standard power lift (EFC) with shock load stabilizing system					
Hydraulic pump output					
Tandem pump (33 l/min + 42 l/min)/Load Sensing system (33 l/min + 71 l/min) optional					
Operating pressure					
200 bar					
Vehicle concept					
Integrated housing					
Monoblock design					

### Technical data for 200 Vario Standard S3

#### Technical data for 200 Vario Standard S3

Model	207	208	209	210	211
<b>Rated power ECE R 120</b>	53 kW / 72 HP	60 kW / 81 HP	67 kW / 91 HP	73 kW / 99 HP	74 kW / 101 HP
<b>motor</b>	AGCO Power 3-cylinder 33 AWI, water-cooled with turbocharger				
Injection type/emissions optimisation	Common rail/EGR/DCC				
Displacement/rated engine speed	3.3 l/2100 rpm				
<b>Gearbox</b>					
Gearbox type (drive train)	Infinitely variable Vario gearbox (ML75)				
Rear axle/rear brakes	HA75/ring piston brake				
Driving range (forwards / reverse)	AWD: 0,02 km/h to 40 km/h/0,02 km/h to 25 km/h				
Maximum speed	40 km/h	40 km/h	40 km/h	40 km/h	40 km/h
<b>Front axle</b>					
Manufacturer/axle type	Planetary steering axle (DANA)/rigid axle				
Spring travel	± 40 mm				
<b>Hydraulics</b>					
Type	Electrohydraulic standard power lift (EPC) with shock load stabilizing system				
Hydraulic pump output	Tandem pump (33 l/min + 42 l/min)/Load Sensing system (33 l/min + 71 l/min) optional				
Operating pressure	200 bar				
<b>Vehicle concept</b>					
Integrated housing	Monoblock design				

### Technical data for 300 Vario S4

#### Technical data for 300 Vario S4

Model	310	311	312	313
<b>Equipment variants</b>	Power/Profit/ProfitPlus			
<b>Rated power ECE R 120</b>	74 kW/100 HP	83 kW/113 HP	90 kW/123 HP	97 kW/133 HP
<b>motor</b>	AGCO Power 4-cylinder 44 AVF HD, water-cooled with turbocharger			
Injection type/emissions optimisation	Common rail/EGR/DOC/SCR			
Displacement/rated engine speed	4,4 l/2100 rpm			
<b>Gearbox</b>				
Gearbox type (drive train)	Infinitely variable Vario gearbox (ML75)			
Rear axle/rear brakes	HA75/ring piston brake			
Driving range (forwards / reverse)	AWD: 0,02 km/h to 40 km/h/0,02 km/h to 20 km/h			
Maximum speed	40 km/h	40 km/h	40 km/h	40 km/h

Technical data for 500 Vario S4				
Model				
	512	513	514	516
Equipment variants				
	Power/PowerPlus/Profi/ProfiPlus			
Rated power ECE R 120				
	91 kW/124 HP	98 kW/133 HP	110 kW/150 HP	120 kW/163 HP
motor				
	Deutz 4-cylinder TCD 4.1 L04F 4V, water-cooled with turbo-charger			
Injection type/emissions optimisation				
	Common rail/EGR/DOC/DPF/SCR			
Displacement/rated engine speed				
	4,1 l/2100 rpm			
Gearbox				
	Infinitely variable Vario gearbox (ML90)			
	HA90			
Travel range:				
	Travel range I: 0,02 km/h to 28 km/h/0,02 km/h to 17 km/h			
	Travel range II: 0,02 km/h to 50 km/h/0,02 km/h to 33 km/h			
Front axle				
	Maximum speed			
	50 km/h			
Manufacturer/axle type				
	Planetary steering axle (DANA)/rigid axle			
Spring travel				
	± 50 mm			
Hydraulics				
	Type			
	Load-sensing system for Power and Profi			
	Power and PowerPlus 75 l/min (optionally 110 l/min)/Profi and ProfiPlus 110 l/min (optionally 158 l/min)			

**Technical data for 500 Vario S4**

Technical data for 300 Vario S4				
Model				
	310	311	312	313
Front axle				
	Manufacturer/axle type			
	Planetary steering axle (DANA)/rigid axle			
Spring travel				
	± 40 mm			
Hydraulics				
	Type			
	Constant current system (Power)/Load sensing system for Profi and ProfiPlus (optional with Power)			
	Power 84 (46 l/min + 38 l/min) optional 110 l/min/Profi and ProfiPlus 110 l/min			
Operating pressure				
	200 bar			
Vehicle concept				
	Integrated housing			
	Half frame design			



Technical data for 700 Vario S4						
Model						
	714	716	718	720	722	724
Equipment variants						
Rated power ECE R 120	106 HP	120 HP	133 HP	148 HP	163 HP	174 HP
	106 kW/144	120 kW/163	133 kW/181	148 kW/201	163 kW/222	174 kW/237
motor						
Deutz 6-cylinder TCD 6.1 L06 4V, water-cooled with turbocharger						
Injection type/emissions optimisation						
Displacement/rated engine speed						
6,1 l/2100 rpm						
Gearbox						
Gearbox type (drive train)						
ML180						
Rear axle/rear brakes						
HA140/to activate the brake, a V-notch is used to press the brake covering at the brake discs. HA140/to activate the brake, a V-notch is used to press the brake covering at the brake discs.						
Travel range:						
Range I (forwards/reverse)						
Travel range I: 0,02 km/h to 28 km/h/0,02 km/h to 17 km/h						
Range II (forwards/reverse)						
Travel range II: 0,02 km/h to 50 km/h/0,02 km/h to 33 km/h						
Maximum speed						
50 km/h						
Front axle						
Manufacturer/axle type						
Planetary steering axle (ZF)/rigid axle						
Spring travel						
± 50 mm						
Hydraulics						
Type						
Load-sensing system for Power and Profi						
Hydraulic pump output						
Power and PowerPlus 109 l/min (optionally 152 l/min)/Profi and Profi-Plus 152 l/min (optionally 193 l/min)						
Operating pressure						
200 bar						
Vehicle concept						
Integrated housing						
Half frame design						

## Technical data for 700 Vario S4

Technical data for 500 Vario S4						
Model						
	512	513	514	516		
Equipment variants						
Rated power ECE R 120						
106 HP						
120 HP						
133 HP						
148 HP						
163 HP						
174 HP						
106 kW/144						
120 kW/163						
133 kW/181						
148 kW/201						
163 kW/222						
174 kW/237						
motor						
Deutz 6-cylinder TCD 6.1 L06 4V, water-cooled with turbocharger						
Injection type/emissions optimisation						
Displacement/rated engine speed						
6,1 l/2100 rpm						
Gearbox						
Gearbox type (drive train)						
ML180						
Rear axle/rear brakes						
HA140/to activate the brake, a V-notch is used to press the brake covering at the brake discs. HA140/to activate the brake, a V-notch is used to press the brake covering at the brake discs.						
Travel range:						
Range I (forwards/reverse)						
Travel range I: 0,02 km/h to 28 km/h/0,02 km/h to 17 km/h						
Range II (forwards/reverse)						
Travel range II: 0,02 km/h to 50 km/h/0,02 km/h to 33 km/h						
Maximum speed						
50 km/h						
Front axle						
Manufacturer/axle type						
Planetary steering axle (ZF)/rigid axle						
Spring travel						
± 50 mm						
Hydraulics						
Type						
Load-sensing system for Power and Profi						
Hydraulic pump output						
Power and PowerPlus 109 l/min (optionally 152 l/min)/Profi and Profi-Plus 152 l/min (optionally 193 l/min)						
Operating pressure						
200 bar						
Vehicle concept						
Integrated housing						
Half frame design						

**Technical data for 800 Vario S4**

Technical data for 800 Vario S4					
Model	Equipment variants				
828	Power/PowerPlus/Profi/ProfiPlus				
	166 kW/226 HP	181 kW/246 HP	195 kW/265 HP	211 kW/287 HP	
	Deutz 6-cylinder TTCD 6.1 L06 4V, water-cooled with two-stage charging				
	Injection type/emissions optimisation				
	Displacement/rated engine speed				
	6,1 l /2100 rpm				
Gearbox					
	Gearbox type (drive train)				
	Infinitely variable Vario gearbox (ML260)				
	Rear axle/rear brakes				
	HA220/ring piston brake				
	Travel range:				
	Range I (forwards/reverse)				
	Range II (forwards/reverse)				
	Travel range I: 0,02 km/h to 35 km/h/0,02 km/h to 20 km/h				
	Travel range II: 0,02 km/h to 60 km/h/0,02 km/h to 33 km/h				
	Maximum speed				
	60 km/h				
Front axle					
	Manufacturer/axle type				
	Planetary steering axle (DANA)/rigid axle				
	Spring travel				
	± 60 mm				
Hydraulics					
	Type				
	Load-sensing system for Power and Profi				
	Hydraulic pump output				
	All equipment variants 152 l/min (optionally 205 l/min)				
	Operating pressure				
	200 bar				
Vehicle concept					
	Integrated housing				
	Half frame design				

**Technical data for 900 Vario S4**

Technical data for 900 Vario S4					
Model	Equipment variants				
927	Power/PowerPlus/Profi/ProfiPlus				
	202 kW/275 HP	224 kW/305 HP	247 kW/336 HP	269 kW/366 HP	291 kW/396 HP
	Deutz 6-cylinder TTCD 7.8 L6 4V, water-cooled with two-stage charging				
	Injection type/emissions optimisation				
	Displacement/rated engine speed				
	7,8 l /2100 rpm				
Gearbox					
	Gearbox type (drive train)				
	Infinitely variable Vario gearbox (260)				

Technical data for 1000 Vario S4				
Model	1050	1046	1042	1038
<b>Equipment variants</b>	PowerPlus/Profi/ProfiPlus			
<b>Rated power ECE R 120</b>	291 kW / 396 HP	320 kW / 435 HP	350 kW / 476 HP	380 kW / 517 HP
<b>motor</b>	MAN D2676 LE 121 water-cooled with VTG turbocharger			
<b>Injection type/emissions optimisation</b>	Common rail/EGR/SCR			
<b>Displacement</b>	12,4 l/1700 rpm			
<b>Gearbox</b>	Infinitely variable Vario gearbox (ML400)			
<b>Gearbox type (drive train)</b>	HA400/ring piston brake			
<b>Rear axle/rear brakes</b>	Driving range (forwards / reverse) 0,02 km/h to 60 km/h/0,02 km/h to 33 km/h			
<b>Maximum speed</b>	60 km/h			
<b>Front axle</b>				
<b>Manufacturer/axle type</b>	Planetary steering axle (DANA)/individual wheel suspension			
<b>Spring travel</b>	± 157 mm			
<b>Hydraulics</b>				
<b>Type</b>	Electrohydraulic standard power lift (EPC) with shock load stabilizing system			

**Technical data for 1000 Vario S4**

Technical data for 900 Vario S4				
Model	927	930	933	936
<b>Rear axle/rear brakes</b>	HA260F/to activate the brake, a V-notch is used to press the brake covering at the brake discs.			
<b>Travel range:</b>	Travel range I: 0,02 km/h to 35 km/h/0,02 km/h to 20 km/h Travel range II: 0,02 km/h to 60 km/h/0,02 km/h to 33 km/h			
<b>Maximum speed</b>	60 km/h	60 km/h	60 km/h	60 km/h
<b>Front axle</b>				
<b>Manufacturer/axle type</b>	Planetary steering axle (DANA)/individual wheel suspension			
<b>Spring travel</b>	± 157 mm			
<b>Hydraulics</b>				
<b>Type</b>	Electrohydraulic standard power lift (EPC) with shock load stabilizing system			
<b>Hydraulic pump output</b>	All equipment variants 152 l/min (optionally 205 l/min)			
<b>Operating pressure</b>	200 bar			
<b>Vehicle concept</b>				
<b>Integrated housing</b>	Monoblock design			

Technical data for 1000 Vario S4				
Model	1038	1042	1046	1050
Hydraulic pump output	Power Plus 165 l/min (optionally 220 l/min)/Profi and Profi-Plus 165 l/min (optionally 220 l/min or 430 l/min with second pump 210 l/min)			
Operating pressure	200 bar			
<b>Vehicle concept</b>				
Integrated housing	Monoblock design			



### 2.1.3 Maintenance schedule

FENDT 714 Vario, 716 Vario, 718 Vario, 720 Vario, 722 Vario, 724 Vario

From chassis number 738 .. 0101, 739 .. 0101, 740 .. 0101, 741 .. 0101, 742 .. 0101, 743 .. 0101

For work during and after the running-in period and for workshop work after the 5th routine service

**IMPORTANT:**

Consult the fuels and lubricants list in this maintenance manual for the respective types and quantities of oil.

**NOTE:**

The technical service carried out must be documented by the dealer in the Service Record Book and by with an on-line Internet application in AGCONET (see Service Bulletin 45/08)!

Technical service			Regular <sup>[1]</sup> Annually or every 500 hours	Every 2 years or every 2000 hours	Daily	Work to be carried out  See also: Operator's Manual Service and maintenance	Information and technical data on materials <sup>[2]</sup>  Filling levels are determined with a dipstick or by over-flow at level bungs etc.
1.	2.	3.					
50 h	500 h	1000 h					
	X	X	X		X	<b>Engine</b> Check engine oil level.  Perform stationary regeneration of diesel particulate filter.	After 100 running hours, add oil to the MAX mark on the dipstick. Wait until level is just above the MIN marking. Do not fill above MAX marking.  If the last stationary regeneration was over 50 hrs ago. Stationary regeneration must always be performed before changing the engine oil.  If the soot load is low (green status display), stationary regeneration must be triggered via Serdia.
X	X	X	X	X		Change engine oil and filter cartridge. <sup>[3]</sup> Change the AdBlue® filter cartridge.	



Technical service			Regular <sup>[1]</sup>		Daily	Work to be carried out	Information and technical data on materials <sup>[2]</sup>
1.	2.	3.	Annually or every 500 hours	Every 2 years or every 2000 hours		See also: Operator's Manual Service and maintenance	Filling levels are determined with a dipstick or by over-flow at level bungs etc.
50 h	500 h	1000 h				Change AdBlue <sup>®</sup> breather filter.	
			X	X		Check valve clearances, adjust if necessary - workshop function.	<b>Valve clearance:</b> Intake valve 75°, exhaust valve 120° (corresponds to 0.3/0,5 mm clearance) when the engine is cold (max. 50°C) locknut tightening torque 20 Nm.
					X	Replace fuel filter element.	Repeat more often if engine performance begins to drop.
			X	X		Drain fuel pre-filter.	Repeat more often if engine performance begins to drop.
						Replace fuel pre-filter	Repeat more often if engine performance begins to drop.
			As required			Check poly-V belt.	
X	X	X	X			Check coolant level, top up if necessary.	<b>Coolant level:</b> With the engine cold, top up if necessary with clean, demineralized water containing anti-freeze to between the MIN and MAX mark on the expansion reservoir.
X	X	X	X	X		Visual check of coolant hoses for leaks.	A concentration of 35–50% vol. of antifreeze and anticorrosion inhibitor is necessary throughout the year, even in frost-free areas.
				X		Change coolant.	Add anti-freeze as indicated in Fendt Service Bulletin 11/02.

Technical service			Regular <sup>[1]</sup>	Daily	Work to be carried out	Information and technical data on materials <sup>[2]</sup>
1.	2.	3.				
50 h	500 h	1000 h	Annually or every 500 hours	Every 2 years or every 2000 hours	See also: Operator's Manual Service and maintenance	Filling levels are determined with a dipstick or by overflow at level bungs etc.
		X		X 1000 h or if warning appears		
					Check, and if necessary clean, the cooling fins on the engine, gearbox and air conditioning.  Change air filter main cartridge.	Main cartridge must not be blown out or cleaned. After the third replacement of the main cartridge or if the main cartridge was damaged, the safety cartridge must also be replaced.
X	X	X	X		Check the air filter suction line for leaks; check maintenance switch and indication on multiple display.	There should be no cracks on the intake hoses.
				X	<b>Transmission, rear axle final drives and front PTO</b>  Check oil level in gearbox.	
				X	Change the gearbox oil and replace the gearbox oil suction filter.  Replace gearbox oil pressure filter.	If the "pressure filter dirty" symbol appears on the multiple display, replace the filter as soon as possible.
X		X	X		Check the oil level at the rear axle drives.	<b>Oil level:</b> Fill to overflow mark at filler hole.

Technical service			Regular <sup>[1]</sup>		Daily	Work to be carried out	Information and technical data on materials <sup>[2]</sup>
1.	2.	3.	Annually or every 500 hours	Every 2 years or every 2000 hours		See also: Operator's Manual Service and maintenance	Filling levels are determined with a dipstick or by overflow at level bungs etc.
50 h	500 h	1000 h				Oil change at rear axle final drives. <b>NOTE: On the rear bar axle version, the oil quantity and type do not change.</b> Front PTO: change transmission oil and pressure filter Check the oil level of the front PTO transmission	
	X	X	X	X		<b>Front axle</b> Check oil level in differential. Check oil level of drive hubs. Oil change for differential and drive hubs.	Wait until level is just above the MIN marking. Do not fill above MAX marking. Oil level up to overflow at level bung, top up if necessary.
X	X	X	X	X		Check toe-in and adjust if necessary.	<b>Toe-in:</b> 0 +2 mm.
		2000 h 1000 h		2000 h 1000 h		<b>Hydraulic system</b> Change the oil along with the return filter, breather filter and control pressure fine filter.	

Technical service			Regular <sup>[1]</sup>		Daily	Work to be carried out	Information and technical data on materials <sup>[2]</sup>
1.	2.	3.	Annually or every 500 hours	Every 2 years or every 2000 hours		See also: Operator's Manual Service and maintenance	Filling levels are determined with a dipstick or by overflow at level bungs etc.
50 h	500 h	1000 h				With <b>biodegradable oils</b> : Change the oil along with the return filter, breather filter and control pressure fine filter.	<b>Also permissible:</b> For temperatures over 10 °C, HD-SAE 20W-20 acc. to API-CD
		1000 h	As required	1000 h		Sieve filter external pressure supply	If the external pressure supply does not function properly.
	X	X	X	X		<b>Electrical, electronic systems</b> Check battery electrolyte level; if necessary top up with distilled water. Not applicable to maintenance-free batteries.	Level approx. 15 mm above the top of the plates. Open-circuit voltage with battery fully charged 12.75 V.
X	X	X	X	X		Check lighting and signaling system and all monitoring and warning systems for correct operation. Check diagnostic memory and rectify any faults.	Short circuit sensor. A fault message (symbol) must appear on the multiple display accompanied by an intermittent audible signal.
X	X	X	X	X		Check software versions and interconnection of the electronic components and update if necessary.	Complete tractor programming with EOL program and tractor calibration — check interconnection. If required, explain new control functions.

Technical service			Regular <sup>[1]</sup>		Daily	Work to be carried out	Information and technical data on materials <sup>[2]</sup>
1.	2.	3.	Annually or every 500 hours	Every 2 years or every 2000 hours		See also: Operator's Manual Service and maintenance	Filling levels are determined with a dipstick or by over-flow at level bungs etc.
X	X	X	X	X	X	Setting the next customer service interval	Setting the service counter using the diagnostic software Checking and entering workshop contact data in the terminal
X	X	X	X	X	X	<b>Compressed air system</b> Check tank.	Pull cable to operate drainage valve. If water runs out of the drain valve, replace the air dryer cartridge and drain all tanks.
		X			1000 h	Cartridge change	
	X	X	X	X		<b>Assemblies/general</b> Change fresh air and recirculation filter on heater, air conditioning and fan.	Repeat more frequently if fan output begins to fall.
X	X	X	X	X		Check that bolted connections are tight, especially the wheels, engine, gearbox, front axle, body and hydraulics; tighten if necessary. Only tighten hydraulic screw connections in the event of a leak. In particular, check the steering hydraulic hoses and the front hydraulic system for chafing points.	Check hydraulic hoses and replace if they show signs of damage. Check for loose parts or missing safety devices. Switch off engine before tightening pressure lines. With front axle suspension, also unload pressure in the lines.
X	X	X	X	X	1500 h	Check functioning of the sunblind, replace clamping strips as necessary. Check hose clamps on the air intake and coolant pipes, tighten as necessary.	Switch off engine before tightening hose clamps.

Technical service			Regular <sup>[1]</sup>	Daily	Work to be carried out	Information and technical data on materials <sup>[2]</sup>
1.	2.	3.				
50 h	500 h	1000 h	Annually or every 500 hours	Every 2 years or every 2000 hours	See also: Operator's Manual Service and maintenance	Filling levels are determined with a dipstick or by overflow at level bungs etc.
X	X	X	X	X	Check the trailer hitch.	Swivel joint on trailer hitch: max. play 3 mm
X	X	X	X	X	Check and correct tire pressures, if necessary.	See technical data.
X	X	X	X	X	For lubrication of greasing points refer to lubrication chart, lubricate all joints.	From 20 km/h, the tractor must come to standstill within a stopping distance of 4 m to 6 m.
X	X	X	X	X	Test drive the tractor, checking braking efficiency, adjust if necessary.	Warning and fault messages that indicate a malfunction in the electro-hydraulic steering may not appear on the multiple display.
X	X	X	X	X	Check electro-hydraulic steering.	

[1] Max. values. Whichever comes first. More frequent maintenance is recommended in difficult operating conditions. Always have the main service carried out before long idle periods.

[2] For authorised trade names, refer to the current Fendt fuels and lubricants list, which is available from authorized Fendt workshops as a technical service bulletin.

[3] If the diesel fuel contains more than 0.5% sulphur, the oil replacement intervals must be halved. Use only diesel fuel approved in accordance with EN 590 (see technical service bulletin 04/2016)

**NOTE:**

*When carrying out any maintenance work, instructions on how to avoid accidents and how to handle materials (including disposal) must be observed.*

## 2.2 Faults

### 2.2.1 Structure of fault codes

Warning and fault messages are indicated by symbols on the multiple display on the instrument panel. The warning lamp also flashes and a warning signal sounds.

If a fault code is displayed, additional fault codes can be called up for the exact determination of faults. These fault codes are stored automatically and can be called up in the workshop for rapid troubleshooting.

#### Fault code 06.1.01 as an example on the multiple display

- (A) Number of faults
- (B) Fault currently on display
- (C) Fault code




Fig. 1

The fault code consists of characters (hexadecimal numbers, letters up to F), which are separated from each other with full stops and so form three groups of characters.

**The first group** consists of two characters and can contain numbers and letters. This group indicates the **fault location**, e.g. 06 — the fault is in the area of the rear PTO.

List of fault locations:

- 00 = instrument cluster
- 01 = EDC engine control
- 02 = Vario terminal
- 03 = multifunction armrest (MFA)
- 04 = gearbox
- 05 = comfort hydraulics (AWD, differential lock)
- 06 = rear PTO
- 07 = front PTO
- 08 = rear power lift (EPC)
- 09 = front power lift
- 0A = electric auxiliary control valves
- 0B = TeachIn
- 0D = VarioDoc
- 0E = VarioGuide
- 0F = central electrical system (ZE)
- 10 = air-conditioning system (HVAC)
- 11 = instrument panel
- 12 = tire pressure monitoring system (TPMS)
- 14 = front loader
- 15 = front axle suspension
- 17 = ISO bus implementation control (Joystick)
- 18 = track guidance preparation (EHL)
- 1A = ABS
- 1D = diesel engine
- 1E = diesel engine
- 1F = basic control unit (EXT)
- 20 = VarioGuide CEA

**The second group** consists of a number and indicates the **fault weighting**, e.g. 1 — medium-severity fault.

- 0 = high
- 1 = medium
- 2 = low

**The third group** consists of two characters (numbers and letters) and is a **sequential number**, which is used to sort the fault codes.

• 01... = sequential number

In the fault code lists for the "electrical auxiliary spool valves", fault codes with an X can be found in the third character group, e.g. 0A.1.X0 or 0A.1.X7. The X stands for the valve number. If, for example, the fault codes 0A.1.10 and 0A.1.37 are displayed, this means the following:

- 0A.1.10 = position 1 valve does not report on CAN
- 0A.1.37 = position pickup sensor fault for position 3 valve

## 2.2.2 Confirming, calling up, deleting fault codes

### Confirm fault code

Cancelling a fault code does not remove the fault; it is simply no longer displayed.



Press button repeatedly until no more fault codes are indicated on the display.

### NOTE:

*Each stored fault code must be cleared individually. The message will be displayed again the next time the tractor is started up.*

### Call up fault code



Press button, the first main menu level appears on the multiple display.




Press one of the buttons repeatedly until the symbol (A) flashes.



Press button, the following image appears on the multiple display.

- (A) Number of faults
- (B) Fault currently on display
- (C) Störkode



Press one of the buttons and the faults are displayed one after the other along with their fault code.




Fig. 2




Fig. 3



**Delete fault code**  
 First call up the fault code, making a note of it if necessary.  
 Press button, the following image appears



on the multiple display.

Press buttons (A), (B) and (C) (both arrow keys) simultaneously.

All fault codes in the fault memory of A007 - Instrument panel are deleted.

**NOTE:**

Fault codes are also stored in the A050 - ECU, basic control unit and, where necessary, in the A099 - Engine control ECU.

Fault codes can only be deleted from the A050 and A099 using the appropriate diagnostic software.




Fig. 4




Fig. 5

**2.2.3 Fault code 00.0.00 -**

<b>Fault code</b>	<b>DIN brief description</b>	<b>Cause</b>	<b>Consequences</b>	<b>Note/remedy</b>
00.0.01	<b>A050</b> basic control unit ECU	Bus fault EDC, no speed setting to EDC	Engine malfunction	EOL programming
00.0.02	<b>A103</b> NT01/02 terminal	Terminal BUS fault, does not report to BUS		EOL programming
00.0.03	<b>A100</b> MFA, multifunction armrest	Multifunction armrest BUS fault, does not report to BUS		EOL programming
00.0.04	<b>A050</b> basic control unit ECU	Transmission BUS fault, no setpoint value to actuator unit	Functions non-operational, no display	EOL programming
00.0.05	<b>A050</b> basic control unit ECU	Bus fault AR/Diff.	Functions non-operational, no display	EOL programming
00.0.06	<b>A050</b> basic control unit ECU	Rear PTO bus fault	Functions non-operational, no display	EOL programming
00.0.07	<b>A050</b> basic control unit ECU	Front PTO BUS fault	Function non-operable, no display	EOL programming
00.0.08	<b>A050</b> basic control unit ECU	Rear EPC BUS fault	Function non-operable, no display	EOL programming
00.0.09	<b>A050</b> basic control unit ECU	Front EPC BUS fault	Function non-operable, no display	EOL programming

Fault code	DIN brief description	Cause	Consequences	Note/remedy
00.0.0A	<b>A050</b> basic control unit ECU	Bus fault, el. valve	Function non-operable, no display	EOL programming
00.0.0B	<b>A050</b> basic control unit ECU	Teach-in function BUS fault	Function non-operable, no display	EOL programming
00.0.0D	<b>A101</b> VarioDoc ECU	VarioDoc BUS fault	Function non-operable, no display	EOL programming
00.0.0E	<b>A102</b> VarioGuide GNSS ECU	VarioGuide BUS fault	Function non-operable, no display	EOL programming
00.0.0F	<b>A111</b> central electrical system ECU	Central electrical system BUS fault	Function non-operable, no display	EOL programming
00.0.10	<b>A050</b> basic control unit ECU	Air conditioning system BUS fault	Function non-operable, no display	EOL programming
00.0.11	<b>A050</b> basic control unit ECU	Electrical control panel BUS fault	Function non-operable, no display	EOL programming
00.0.15	<b>A050</b> basic control unit ECU	Bus fault, VA suspension	Function non-operable, no display	EOL programming
00.0.16	<b>A050</b> basic control unit ECU	EPC CAN BUS fault Auto mode	Function non-operable, no display	EOL programming
00.0.17	<b>A050</b> basic control unit ECU	Bus fault, Vario control unit		EOL programming
00.0.18	<b>A050</b> basic control unit ECU	Electro-hydraulic steering (EHL) BUS fault		EOL programming

Fault code	DIN brief description	Cause	Consequences	Note/remedy
00.0.19	<b>A050</b> basic control unit ECU	ISO task BUS fault		EOL programming
00.0.1D	<b>A050</b> basic control unit ECU	EDC17 reports incorrectly to instrument panel — BUS fault		EOL programming
00.0.1F	<b>A050</b> basic control unit ECU	Fault management BUS fault		EOL programming
00.0.21	<b>A050</b> basic control unit ECU	On-board computer BUS fault		EOL programming
00.1.4D	<b>A007</b> instrument panel	Checksum Menu images, instrument panel memory faulty	Display fault in instrument panel	EOL programming
00.1.4E	<b>A007</b> instrument panel	Checksum Warning images, instrument panel memory faulty	Display fault in instrument panel	EOL programming
00.1.4F	<b>A007</b> instrument panel	Checksum GD table	Display fault in instrument panel	EOL programming
00.1.50	<b>A007</b> instrument panel	VDO instrument panel EEPROM not programmed	Malfunctions in instrument panel	EOL programming
00.1.54	<b>B060</b> compressed air supply sensor (circuit <sup>1)</sup> )	Sensor faulty Signal fault	Function non-operable Compressed air display, 4WD is switched on until the next cold start	
00.1.55	<b>B084</b> hydraulic oil level sensor	12 V supply fault Sensor faulty Signal fault	A007 - instrument panel	

Fault code	DIN brief description	Cause	Consequences	Note/remedy
00.1.59	<b>B007</b> immersed tube fuel-level sensor	Sensor faulty, Signal fault	No display	
00.1.5A	<b>B019</b> compressed air supply sensor (circuit 2)	Sensor faulty, Signal fault	Function non-operable Compressed air display, 4WD is switched on until the next cold start	
		12 V supply fault	A007 - instrument panel	
00.1.71	<b>A128</b> control panel for right/left dashboard	Enter key	Button non-operable	
00.1.72	<b>A128</b> control panel for right/left dashboard	ESC button	Button non-operable	
00.1.73	<b>A128</b> control panel for right/left dashboard	Up button	Button non-operable	
00.1.74	<b>A128</b> control panel for right/left dashboard	Down button	Button non-operable	
00.1.75	<b>A128</b> control panel for right/left dashboard	Enter button pressed > 30s	Button non-operable or button released	
00.1.76	<b>A128</b> control panel for right/left dashboard	Esc button pressed > 30s	Button non-operable or button released	
00.1.77	<b>A128</b> control panel for right/left dashboard	Up button pressed > 30s	Button non-operable or button released	
00.1.78	<b>A128</b> control panel for right/left dashboard	Down button pressed > 30s operated	Button non-operable or button released	
00.1.A8	<b>B060</b> compressed air supply sensor (circuit 1)	Compressed air supply circuit 1, vacuum	4WD is switched on until the next cold start	

## 2.2.4 Fault code 04.1.00 -

Fault code	DIN brief description	Cause	Consequences	Note/remedy
04.1.04	<b>B017</b> clutch pedal sensor	Sensor faulty, Signal fault	Loss of comfort control/ function in final speed control;	
			No cruise control func- tion, TMS is switched off	
04.1.05	<b>B039</b> high-pressure sensor 2	Faulty 8.5 V supply	A013, fuse 05	
		Sensor faulty, Signal fault	TMS is switched off	
			Transmission protection function active (engine power is limited to 70 percent)	
04.1.06	<b>B055</b> foot throttle sensor	12 V supply fault	A013, fuse 31	
		Sensor faulty, Signal fault	Emergency mode if throttle pedal mode is active, TMS is switched off	
04.1.07	<b>B008</b> high-pressure sensor 1	Faulty 8.5 V supply	A013, fuse 19	
		Sensor faulty, Signal fault	Pressure spikes in the transmission are no longer monitored, TMS is switched off	
			Transmission protection function active (engine power is limited to 70 percent)	

Fault code	DIN brief description	Cause	Consequences	Note/remedy
04.1.08	<b>B016</b> travel range detection sensor	12 V supply fault	A013, fuse 32	
		Sensor faulty, Signal fault	TMS is switched off	
		Faulty 8.5 V supply	A013, fuse 06	
04.1.19	<b>A050</b> basic control unit ECU	Error on reading-in throttle pedal parameters		
04.1.20	<b>A100</b> MFA, multifunction armrest	Throttle pedal resolution potentiometer	Throttle pedal mode not possible, TMS is switched off	Calibration code "4010"
		EEPROM checksum incorrect or not calibrated		
04.1.22	<b>A100</b> MFA, multifunction armrest	Throttle pedal resolution potentiometer faulty, Signal fault	TMS is switched off	
04.1.23	<b>A100</b> MFA, multifunction armrest	Joystick signal "Tempomat cruise control ON" faulty	Continuation in emergency mode possible	
04.1.24	<b>S080</b> hand brake switch	Faulty switch,	TMS is switched off,	
		Signal fault	4WD is switched on	
04.1.25	<b>A100</b> MFA, multifunction armrest	Joystick "F/R quick reverse" signal faulty	TMS is switched off	
04.1.26	<b>A100</b> MFA, multifunction armrest	Accelerator pedal mode button faulty,	Throttle pedal mode inoperable	
		Signal fault		
04.1.28	<b>A009</b> actuator unit V/R incremental encoder	Faulty path signal	Continuation in emergency mode possible	
04.1.29	<b>A100</b> MFA, multifunction armrest	Joystick signal "park position" faulty	TMS is switched off	
04.1.2A	<b>B015</b> bevel pinion sensor	Sensor faulty,	Continuation in emergency mode possible	
		Direction signal faulty		

Fault code	DIN brief description	Cause	Consequences	Note/remedy
04.1.2B	<b>A100</b> MFA, multifunction armrest Travel speed range selection button I/II	Faulty button, Signal fault		
04.1.2C	<b>A100</b> MFA, multifunction armrest Neutral/Active Standstill button	Faulty button, Signal fault	Continuation in emergency mode possible	
04.1.2D	<b>S157</b> forward - reverse shuttle switch Forward/reverse shuttle switch on control stalk	Faulty forward travel signal	TMS is switched off	
04.1.2E	<b>S157</b> forward - reverse shuttle switch Forward/reverse shuttle switch on control stalk	Faulty reverse travel signal	TMS is switched off	
04.1.2F	<b>A100</b> MFA, multifunction armrest Joystick	Joystick signal "v-" faulty (joystick to rear)	Continuation in emergency mode possible	
04.1.31	<b>B014</b> collecting shaft sensor	Sensor faulty, Direction signal faulty	Continuation in emergency mode possible	
04.1.32	<b>A100</b> MFA, multifunction armrest Joystick activation button	Faulty button, signal fault	Continuation in emergency mode possible	
04.1.33	<b>A100</b> MFA, multifunction armrest	Faulty joystick signal "v+" (joystick forward)	Continuation in emergency mode possible	
04.1.3D	<b>A050</b> basic control unit ECU	Derating parameter checksum error (Error occurs when there is a reduction in engine power due to an exhaust system fault)	Continuation in emergency mode possible	



Fault code	DIN brief description	Cause	Consequences	Note/remedy
04: 1.3E	<b>A050</b> basic control unit ECU	Derating active (Restrictions due to exhaust system)	Engine torque is reduced, max. engine speed is limited, TMS is switched off	Read out engine fault with SERDIA
04: 1.42	<b>B014</b> collecting shaft sensor	Sensor faulty, Speed signal faulty Faulty 8.5 V supply	Continuation in emergency mode possible A013, fuse 07	
04: 1.45	<b>B015</b> bevel pinion sensor (=road speed)	Sensor faulty, Speed signal faulty Faulty 8.5 V supply	Continuation in emergency mode possible A013, fuse 08	
04: 1.46	<b>Y004</b> clutch/turbo-clutch solenoid valve	Pressure does not drop when the TK valve is opened	TK valve jams, TK valve external energizing	
04: 1.47	<b>B016</b> travel range detection sensor <b>Y002</b> travel speed range I solenoid valve <b>Y003</b> travel speed range II solenoid valve	Travel speed range selector: Does not come out of gear when travel speed range valve is energized	Travel speed range detection sensor faulty, incorrect valve connected or valve is faulty	
04: 1.48	<b>B016</b> travel range detection sensor <b>Y002</b> travel speed range I solenoid valve <b>Y003</b> travel speed range II solenoid valve	Travel speed range selector: Cannot shift to neutral	Travel speed range detection sensor faulty, incorrect valve connected or valve is faulty	
04: 1.49	<b>S017</b> filter contamination switch	Plausibility error	Switch supplies incorrect information (engine is off and switch displays contamination)	

Fault code	DIN brief description	Cause	Consequences	Note/remedy
04.1.50	<b>S017</b> filter contamination switch	Filter clogged	No further indication of clogging	Switch function not active at oil temperature below 50°
04.1.53	<b>B009</b> discharge temperature sensor	"Transmission oil temperature more than 110°C"	transmission damage if journey is continued!	
04.1.56	<b>S017</b> filter contamination switch	Faulty switch, Signal line fault		
04.1.58	Transmission hydraulics	Transmission slip monitor Transmission output speed deviates by more than 30% from setpoint value	May occur at extremely low temperatures in isolated cases; repeated occurrence under normal conditions causes a rise in oil temperature and further transmission damage; TMS is switched off	("Ideal ratio/actual ratio" comparison) Fault not active if turbo-clutch (TK) function is on - clutch is depressed, check clutch from actuator unit
04.1.59	<b>A050</b> basic control unit ECU	Emergency mode has been activated manually	Transmission emergency mode	
04.1.61	<b>A050</b> basic control unit ECU <b>Y002</b> travel speed range I solenoid valve	Faulty actuation of travel speed range I valve	Cannot switch to travel speed range I	
04.1.62	<b>A050</b> basic control unit ECU <b>Y003</b> travel speed range II solenoid valve	Faulty actuation of travel speed range II valve	Cannot switch to travel speed range II	
04.1.63	<b>A050</b> basic control unit ECU <b>Y005</b> speed governor solenoid valve	Valve actuation for mechanical speed limiter faulty		
04.1.64	<b>A050</b> basic control unit ECU <b>Y004</b> clutch/turbo-clutch solenoid valve	Turbo-clutch solenoid valve actuation faulty, fuse F56 faulty	TK valve cannot be actuated manually, i.e. tractor must not be driven!	

Fault code	DIN brief description	Cause	Consequences	Note/remedy
04.1.69	<b>S053</b> driver presence switch	Seat switch faulty (Error code is output by the "hand brake warning message" function)		
04.1.70	<b>A100</b> MFA, multifunction armrest Cruise control button, C1	Faulty button, Signal fault	Cruise control 1 cannot be activated	
04.1.71	<b>A100</b> MFA, multifunction armrest Cruise control button, C2	Faulty button, Signal fault	Cruise control 2 cannot be activated	
04.1.76	<b>S047</b> engine brake switch	Switch faulty or communication error to EDC, Signal fault	TMS is switched off	
04.1.77	<b>A100</b> MFA, multifunction armrest Joystick acceleration rate I...IV	Signal fault	Only rate III available in the event of a fault	
04.1.78	<b>S053</b> driver presence switch	Faulty switch, Signal fault	TMS is switched off	
04.1.79	<b>A050</b> basic control unit ECU	Output for reverse warning signal not OK (Current > 2500 mA or short circuit)		
04.1.82	<b>B014</b> collecting shaft sensor <b>B015</b> bevel pinion sensor <b>B016</b> travel range detection sensor	Plausibility error (=speeds do not match) fault output as of 5 km/h	Continuation in emergency mode possible	
04.1.83	<b>B014</b> collecting shaft sensor <b>B015</b> bevel pinion sensor	Plausibility error (=speeds do not match) Fault output as of 5 km/h	Continuation in emergency mode possible	
04.1.84	<b>A100</b> MFA, multifunction armrest Joystick switch (V, R, VR, cruise control, default position)	Plausibility error (=signals do not match)	Continuation in emergency mode possible	

Fault code	DIN brief description	Cause	Consequences	Note/remedy
04:185	<b>B085</b> camshaft speed sensor <b>B088</b> crankshaft speed sensor	Engine speed sensors do not supply plausible speed curves. Output speed increase or decrease is outside limits.	Continuation in emergency mode possible	
04:186	<b>B008</b> high-pressure sensor 1 <b>B039</b> high-pressure sensor 2	Plausibility error in both pressure sensors	TMS is switched off Transmission protection function active (engine power is limited to 70 percent)	
04:187	<b>S157</b> forward - reverse shuttle switch	Plausibility error at F/R switch, quick reverse	F/R switch inoperable, quick reverse on steering wheel adjustment, S079 switch,	Check the forward/reverse shuttle switch
04:189	<b>B009</b> discharge temperature sensor	Plausibility error, transmission temperature		
04:18A	<b>B017</b> clutch pedal sensor <b>S074</b> starter lockout switch/clutch pedal limit switch	Plausibility error; electrical clutch pedal (TK line not opened when clutch pedal depressed)		
04:18F		Currently selected tire circumference is too small	- The speed display is no longer correct in certain circumstances - Transmission controls no longer working correctly in certain circumstances (e.g. TMS, final speed control, cruise control)	Enter correct tire circumference
04:194	<b>A050</b> basic control unit ECU <b>A100</b> MFA, multifunction armrest	Faulty CAN communication between e-box and CAN joystick		

Fault code	DIN brief description	Cause	Consequences	Note/remedy
04.1.A1	<b>A009</b> actuator unit	Turn angle is not reached within 2 seconds.	Continuation in emergency mode possible	Mechanical check: check smooth adjustment action in emergency mode. Refer to Service Information 26/04
04.1.A2	<b>A009</b> actuator unit <b>A050</b> basic control unit ECU	CAN Bus actuation fault	Continuation in emergency mode possible	Check CAN bus
04.1.A3	<b>A009</b> actuator unit	Fault or logic error in incremental sensor signal (actual position signal)	Continuation in emergency mode possible	
04.1.A4	<b>A009</b> actuator unit	Fault or logical error signal in EST.	Continuation in emergency mode possible	
04.1.A5	<b>A009</b> actuator unit	Initial reference (=zero position) could not be found during Ignition ON	Continuation in emergency mode possible	Refer to Service Information 26/04
04.1.A6	<b>A009</b> actuator unit	Reference point signal fault during operation	Continuation in emergency mode possible	
04.1.B0	All bus users	Initialisation error TeachIn fault	Restricted CAN bus data communication	Check CAN bus
04.1.B1	<b>A050</b> basic control unit ECU	Fatal error, range change (e.g. valve fault) TeachIn fault	Emergency mode	
04.1.B5	<b>A050</b> basic control unit ECU	Checksum error rate parameters, quick reverse for Tractor Management System (TMS)	TMS is switched off	EOL programming
04.1.B7	<b>B009</b> discharge temperature sensor	Incorrect checksum		EOL programming

Fault code	DIN brief description	Cause	Consequences	Note/remedy
04.1.CB	<b>A100</b> MFA, multifunction armrest	Warning message: "Travel range button "under excessive pressure"		
04.1.CF	<b>A050</b> basic control unit ECU	Internal error, A050 basic operating system		
04.1.D5	<b>A050</b> basic control unit ECU	Communication error during workshop mode	Emergency mode, transmission	Perform restart
04.1.E1	<b>A050</b> basic control unit ECU	Traction control regulator parameters (ML transmission adjustment) not plausible or read incorrectly	Emergency mode	EOL programming
04.1.E2	<b>A050</b> basic control unit ECU	Traction control regulator parameters not plausible (B008/B039) or read incorrectly.	Emergency mode	EOL programming
04.1.E3	<b>A050</b> basic control unit ECU	Checksum error, parameter for throttle pedal mode	Emergency mode TMS is switched off	EOL programming
04.1.E5	<b>A050</b> basic control unit ECU	Checksum error for range control, speed limiting valve etc. faulty	Range control not possible	EOL programming
04.1.E6	<b>A050</b> basic control unit ECU	Incorrect checksum, load limit control parameters	Emergency mode, transmission	EOL programming
04.1.E7	<b>A050</b> basic control unit ECU	Incorrect checksum, joystick parameters	Possible to drive with default values	EOL programming
04.1.E9	<b>A050</b> basic control unit ECU	Speed selection parameters incorrect		EOL programming
04.1.EA	<b>A050</b> basic control unit ECU	Error in checksum parameter for transmission teeth number	Continuation in emergency mode possible	EOL programming
04.1.EB	<b>B016</b> travel range detection sensor	Checksum error or range control calibration missing		Calibration code "4003"

Fault code	DIN brief description	Cause	Consequences	Note/remedy
04.1.EC	<b>B055</b> foot throttle sensor	No calibration or drifted, changed values	Continuation in emergency mode possible	Calibration code "4005"
04.1.ED	<b>B017</b> clutch pedal sensor	No calibration or drifted, changed values	Continuation in emergency mode possible	Calibration code "4001"
04.1.EE	<b>A050</b> basic control unit ECU Transmission characteristic	No calibration or drifted, changed values	Continuation in emergency mode possible	Calibration code "4007"
04.1.EF	<b>A050</b> basic control unit ECU Turbo-clutch characteristic	No calibration or drifted, changed values	Continuation in emergency mode possible	Calibration code "4009"
04.1.F0	<b>A050</b> basic control unit ECU	Checksum parameter for transmission calibration incorrect	Transmission cannot be calibrated	EOL programming
04.1.F1	<b>A050</b> basic control unit ECU	Checksum parameter for stationary control incorrect	Emergency mode	EOL programming
04.1.F2	<b>A050</b> basic control unit ECU	Characteristic offset deviation outside permitted range	Only fault code display	
04.1.F3	<b>A050</b> basic control unit ECU	Ratio restriction checksum faulty	Emergency mode, transmission	EOL programming
04.1.F4	<b>A050</b> basic control unit ECU	EXT memory could not be reserved	Continuation in emergency mode possible	EOL programming
04.1.F5	<b>A050</b> basic control unit ECU	Checksum error, "instance for selecting the optimum speed source" parameter		EOL programming
04.2.40	<b>B016</b> travel range detection sensor	Transmission travel speed range is not recognized correctly		Calibration code "4003"

Fault code	DIN brief description	Cause	Consequences	Note/remedy
04.2.41	<b>A050</b> basic control unit ECU <b>B009</b> discharge temperature sensor	Condition for switching switch level not fulfilled.		
04.2.51	<b>B009</b> discharge temperature sensor	Transmission oil temperature >95°C	Switching from travel speed range 2 to travel speed range 1	
04.2.52	<b>B009</b> discharge temperature sensor	Transmission oil temperature >105°C	Continuing to drive will cause transmission damage	
04.2.D0	<b>A050</b> basic control unit ECU	Workshop mode: Ratio restriction active		After workshop mode is complete, the restart function must be performed



## 2.2.5 Fault code 0A.1.00 -

Fault code	DIN brief description	Cause	Consequences	Note/remedy
<b>X stands for the valve number, e.g. 0A.1.10 = position 1 valve does not report to CAN or 0A.1.37 = position pickup sensor error in position 3 valve</b>				
0A.1.X0	<b>Y176</b> position 1 spool valve (yellow) <b>Y177</b> position 2 spool valve (blue) <b>Y178</b> position 3 spool valve (red) <b>Y179</b> position 4 spool valve (green) <b>Y180</b> position 5 spool valve (brown) <b>Y182</b> position 7 spool valve (olive) <b>Y183</b> position 8 spool valve (gray)	Valve does not report to CAN <b>(X=valve number)</b>	Valve moves to neutral and locks	
0A.1.X1	<b>Y176</b> position 1 spool valve (yellow) <b>Y177</b> position 2 spool valve (blue) <b>Y178</b> position 3 spool valve (red) <b>Y179</b> position 4 spool valve (green) <b>Y180</b> position 5 spool valve (brown) <b>Y182</b> position 7 spool valve (olive) <b>Y183</b> position 8 spool valve (gray)	EEPROM inconsistent <b>(X=valve number)</b>	Valve moves to neutral and locks	
0A.1.X2	<b>Y176</b> position 1 spool valve (yellow) <b>Y177</b> position 2 spool valve (blue) <b>Y178</b> position 3 spool valve (red) <b>Y179</b> position 4 spool valve (green) <b>Y180</b> position 5 spool valve (brown) <b>Y182</b> position 7 spool valve (olive) <b>Y183</b> position 8 spool valve (gray)	Undervoltage (where $U < 8V$ ) <b>(X=valve number)</b>	Valve moves to neutral and locks	

Fault code	DIN brief description	Cause	Consequences	Note/remedy
0A.1.X3	<b>Y176</b> position 1 spool valve (yellow) <b>Y177</b> position 2 spool valve (blue) <b>Y178</b> position 3 spool valve (red) <b>Y179</b> position 4 spool valve (green) <b>Y180</b> position 5 spool valve (brown) <b>Y182</b> position 7 spool valve (olive) <b>Y183</b> position 8 spool valve (gray)	Overvoltage, safe (where $U > 18\text{ V}$ ) <b>(X=valve number)</b>	Valve moves to neutral and locks	
0A.1.X4	<b>Y176</b> position 1 spool valve (yellow) <b>Y177</b> position 2 spool valve (blue) <b>Y178</b> position 3 spool valve (red) <b>Y179</b> position 4 spool valve (green) <b>Y180</b> position 5 spool valve (brown) <b>Y182</b> position 7 spool valve (olive) <b>Y183</b> position 8 spool valve (gray)	Valve spool stops short (frequent cause: control pressure dips briefly or oil too viscous at very low temperatures) <b>(X=valve number)</b>	Valve moves to neutral and locks	
0A.1.X5	<b>Y176</b> position 1 spool valve (yellow) <b>Y177</b> position 2 spool valve (blue) <b>Y178</b> position 3 spool valve (red) <b>Y179</b> position 4 spool valve (green) <b>Y180</b> position 5 spool valve (brown) <b>Y182</b> position 7 spool valve (olive) <b>Y183</b> position 8 spool valve (gray)	High overvoltage ( $> 45\text{ V}$ ) <b>(X=valve number)</b>	Valve moves to neutral and locks	

Fault code	DIN brief description	Cause	Consequences	Note/remedy
0A.1.X6	<b>Y176</b> position 1 spool valve (yellow) <b>Y177</b> position 2 spool valve (blue) <b>Y178</b> position 3 spool valve (red) <b>Y179</b> position 4 spool valve (green) <b>Y180</b> position 5 spool valve (brown) <b>Y182</b> position 7 spool valve (olive) <b>Y183</b> position 8 spool valve (gray)	Final stage error (pilot control solenoid valve) <b>(X=valve number)</b>	Valve moves to neutral and locks	
0A.1.X7	<b>Y176</b> position 1 spool valve (yellow) <b>Y177</b> position 2 spool valve (blue) <b>Y178</b> position 3 spool valve (red) <b>Y179</b> position 4 spool valve (green) <b>Y180</b> position 5 spool valve (brown) <b>Y182</b> position 7 spool valve (olive) <b>Y183</b> position 8 spool valve (gray)	Position pickup sensor error <b>(X=valve number)</b>	Valve moves to neutral and locks	
0A.1.X8	<b>Y176</b> position 1 spool valve (yellow) <b>Y177</b> position 2 spool valve (blue) <b>Y178</b> position 3 spool valve (red) <b>Y179</b> position 4 spool valve (green) <b>Y180</b> position 5 spool valve (brown) <b>Y182</b> position 7 spool valve (olive) <b>Y183</b> position 8 spool valve (gray)	Valve actuator does not return to neutral position (frequent cause: valve actuator mechanically jams (pilot control or main actuator) caused by contamination in hydraulics area) <b>(X=valve number)</b>	Valve remains deflected when engine is on; valve locks, Pilot pressure OFF	

Fault code	DIN brief description	Cause	Consequences	Note/remedy
0A.1.X9	<b>Y176</b> position 1 spool valve (yellow) <b>Y177</b> position 2 spool valve (blue) <b>Y178</b> position 3 spool valve (red) <b>Y179</b> position 4 spool valve (green) <b>Y180</b> position 5 spool valve (brown) <b>Y182</b> position 7 spool valve (olive) <b>Y183</b> position 8 spool valve (gray)	Valve actuator not in neutral position when switched on (frequent cause: valve actuator mechanically jams (pilot control or main actuator) caused by contamination in hydraulics area)  <b>(X=valve number)</b>	Valve remains deflected when engine is on; valve locks, Pilot pressure OFF	
0A.1.XA	<b>Y176</b> position 1 spool valve (yellow) <b>Y177</b> position 2 spool valve (blue) <b>Y178</b> position 3 spool valve (red) <b>Y179</b> position 4 spool valve (green) <b>Y180</b> position 5 spool valve (brown) <b>Y182</b> position 7 spool valve (olive) <b>Y183</b> position 8 spool valve (gray)	Valve spool is deflected too far  <b>(X=valve number)</b>	Valve moves to neutral and locks	
0A.1.XB	<b>Y176</b> position 1 spool valve (yellow) <b>Y177</b> position 2 spool valve (blue) <b>Y178</b> position 3 spool valve (red) <b>Y179</b> position 4 spool valve (green) <b>Y180</b> position 5 spool valve (brown) <b>Y182</b> position 7 spool valve (olive) <b>Y183</b> position 8 spool valve (gray)	Floating position is not reached  <b>(X=valve number)</b>	Valve moves to neutral and locks	

Fault code	DIN brief description	Cause	Consequences	Note/remedy
0A.1.XC	<b>Y176</b> position 1 spool valve (yellow) <b>Y177</b> position 2 spool valve (blue) <b>Y178</b> position 3 spool valve (red) <b>Y179</b> position 4 spool valve (green) <b>Y180</b> position 5 spool valve (brown) <b>Y182</b> position 7 spool valve (olive) <b>Y183</b> position 8 spool valve (gray)	Manual actuation (occurs when a valve is deflected from its neutral position) <b>(X=valve number)</b>	All valve positions, no function; Valve locked, Pilot pressure OFF	
0A.1.XD	<b>Y176</b> position 1 spool valve (yellow) <b>Y177</b> position 2 spool valve (blue) <b>Y178</b> position 3 spool valve (red) <b>Y179</b> position 4 spool valve (green) <b>Y180</b> position 5 spool valve (brown) <b>Y182</b> position 7 spool valve (olive) <b>Y183</b> position 8 spool valve (gray)	Pilot control actuator jams <b>(X=valve number)</b>	Valve locked, Pilot pressure OFF	
0A.1.XE	<b>Y176</b> position 1 spool valve (yellow) <b>Y177</b> position 2 spool valve (blue) <b>Y178</b> position 3 spool valve (red) <b>Y179</b> position 4 spool valve (green) <b>Y180</b> position 5 spool valve (brown) <b>Y182</b> position 7 spool valve (olive) <b>Y183</b> position 8 spool valve (gray)	RAM or FLASH test fault <b>(X=valve number)</b>	Valve moves to neutral and locks, pilot pressure OFF	

Fault code	DIN brief description	Cause	Consequences	Note/remedy
0A.1.XF	<b>Y176</b> position 1 spool valve (yellow) <b>Y177</b> position 2 spool valve (blue) <b>Y178</b> position 3 spool valve (red) <b>Y179</b> position 4 spool valve (green) <b>Y180</b> position 5 spool valve (brown) <b>Y182</b> position 7 spool valve (olive) <b>Y183</b> position 8 spool valve (gray)	No setpoint message, no configuration message, setpoint message not plausible, configuration message not plausible. Potentiometer/PW error <b>(X=valve number)</b>	Valve moves to neutral and locks Pilot pressure OFF	
0A.1.A2	<b>A050</b> basic control unit ECU	More valves connected than registered via EOL programming		
0A.1.A4	<b>A050</b> basic control unit ECU	Checksum error when reading the parameters for valve heating	Deactivation of valve heating function	
0A.1.B0	<b>A100</b> MFA, multifunction armrest Crossgate lever	Crossgate lever is not calibrated	Crossgate lever not working	Calibration code "1001"
0A.1.B1	<b>A100</b> MFA, multifunction armrest Crossgate lever	Crossgate lever X axis faulty or engaged when ignition switched on	Crossgate lever not working	
0A.1.B2	<b>A100</b> MFA, multifunction armrest Crossgate lever	Crossgate lever Y axis faulty or engaged when ignition switched on	Crossgate lever not working	
0A.1.B3	<b>A100</b> MFA, multifunction armrest Crossgate lever	Crossgate lever missing (both axes)	Crossgate lever not working	
0A.1.B5	<b>A100</b> MFA, multifunction armrest	Joystick center position recognition faulty (electrical fault) or engaged when ignition switched on	Valve position not functioning, lock valve	
0A.1.B6	<b>A100</b> MFA, multifunction armrest	Linear module 1 (rocker) not calibrated	Valve position not functioning	Calibration code "1003"

Fault code	DIN brief description	Cause	Consequences	Note/remedy
0A.1.B7	<b>A100</b> MFA, multifunction armrest	Linear module 1 (rocker) faulty or engaged when ignition switched on	Valve position not functioning, lock valve	
0A.1.B8	<b>A100</b> MFA, multifunction armrest	Linear module 2 (rocker) not calibrated	Valve position not functioning	Calibration code "1004"
0A.1.B9	<b>A100</b> MFA, multifunction armrest	Linear module 2 (rocker) faulty or engaged when ignition switched on	Valve position not functioning, lock valve	
0A.1.BA	<b>A100</b> MFA, multifunction armrest	Linear module 3 (rocker) not calibrated	Valve position not functioning	Calibration code "1005"
0A.1.BB	<b>A100</b> MFA, multifunction armrest	Linear module 3 (rocker) faulty or engaged when ignition switched on	Valve position not functioning, lock valve	
0A.1.BC	<b>A100</b> MFA, multifunction armrest	Linear module 4 (rocker) not calibrated	Valve position not functioning	Calibration code "1006"
0A.1.BD	<b>A100</b> MFA, multifunction armrest	Faulty linear module 4 (rocker)	Valve position not functioning, lock valve	
0A.1.C0	<b>A100</b> MFA, multifunction armrest	MFA not fitted	No auto mode, Valve locked	
0A.1.C1	<b>A050</b> basic control unit ECU <b>A100</b> MFA, multifunction armrest	MFA GD fault in button used by hydraulics	Valve locked	
0A.1.C2	<b>A100</b> MFA, multifunction armrest	Faulty MFA button (total lock)	Total unlocking not possible, valves locking	

Fault code	DIN brief description	Cause	Consequences	Note/remedy
0A.1.C6	<b>A128</b> control panel for right/left dashboard Cargo front loader tool lock button	Faulty button, Signal fault	Function non-operable	
0A.1.C7	<b>A128</b> control panel for right/left dashboard Cargo front loader suspension button	Faulty button, Signal fault	Function non-operable	
0A.1.C8	Cargo front loader tool lock solenoid valve	Solenoid valve faulty	Function non-operable	
0A.1.C9	Cargo front loader suspension solenoid valve	Solenoid valve faulty	Function non-operable	
0A.1.CA	<b>A050</b> basic control unit ECU	Steering axle checksum incorrect	Steering axle deactivation	EOL programming
0A.1.CD	<b>R019</b> front-loader detection resistor (MK) <b>X4006</b> - Cargo cable coupling	Front loader detection input error		
0A.1.CE	Auxiliary control units	Valve actuator does not return to neutral position	Valve remains deflected when engine is on, valve locks, pilot pressure OFF	
0A.1.CF	Auxiliary control units	Floating position is not reached	Valve moves to neutral and locks	
0A.1.D0	<b>A100</b> MFA, multifunction armrest Button for hydraulic circuit 3	Faulty button, Signal fault	Button inoperable until next trouble-free cold start	
0A.1.D1	<b>A100</b> MFA, multifunction armrest Button for hydraulic circuit 4	Faulty button, Signal fault	Button inoperable until next trouble-free cold start	
0A.1.D2	<b>A100</b> MFA, multifunction armrest Red raise/lower/floating position button on joystick	Faulty button, Signal fault	Valve position not functioning, Valve locked	



Fault code	DIN brief description	Cause	Consequences	Note/remedy
0A.1.D3	<b>A100</b> MFA, multifunction armrest Green raise/lower/floating position button on joystick	Faulty button, Signal fault	Valve position not functioning, Valve locked	
0A.1.D4	<b>S021</b> external raise front power lift button <b>S022</b> external lower front power lift button	Double actuation (button possibly stuck) Faulty button, Signal fault	Valve in neutral	
0A.1.D5	<b>S022</b> external lower front power lift button	Faulty button, Signal fault	Button inoperable until next trouble-free cold start	
0A.1.D6	<b>S021</b> external raise front power lift button	Faulty button, Signal fault	Button inoperable until next trouble-free cold start	
0A.1.D7	<b>B084</b> hydraulic oil level sensor	Sensor faulty, Signal fault	Fill level is no longer monitored	
0A.1.D8	<b>B084</b> hydraulic oil level sensor	Warning, hydraulic oil tank	Warning display only	
0A.1.D9	<b>B084</b> hydraulic oil level sensor	Hydraulic oil tank empty	Valves are locked and pilot control is switched off	
0A.1.DA	<b>B013</b> hydraulic oil temperature sensor	Warning, hydraulic oil temperature too high	Warning display only (without storing)	
0A.1.DB	<b>B013</b> hydraulic oil temperature sensor	Hydraulic oil temperature too high	Is stored	
0A.1.DC	<b>B013</b> hydraulic oil temperature sensor	Warning, hydraulic oil temperature not plausible	Warning display only	
0A.1.DD	<b>S119</b> hydraulic oil filter contamination switch	Filter clogged	Warning display only	
0A.1.DE	<b>S119</b> hydraulic oil filter contamination switch	Faulty switch, Signal fault	Warning display only	

Fault code	DIN brief description	Cause	Consequences	Note/remedy
0A.1.DF	<b>Y176</b> position 1 spool valve (yellow) <b>Y177</b> position 2 spool valve (blue) <b>Y178</b> position 3 spool valve (red) <b>Y179</b> position 4 spool valve (green) <b>Y180</b> position 5 spool valve (brown) <b>Y182</b> position 7 spool valve (olive) <b>Y183</b> position 8 spool valve (gray)	Priority volume greater than pump volume		
0A.1.E0	<b>A050</b> basic control unit ECU	Steering axle volume greater than pump volume		
0A.1.EC	<b>Y173</b> trailer brake release solenoid valve	Solenoid valve faulty		
0A.1.ED	<b>A128</b> control panel for right/left dashboard	ABV activation button faulty		
0A.1.EE	<b>Y023</b> solenoid valve for compressed air pilot control system	Solenoid valve faulty	Compressed air pilot control system is switched off	
0A.1.F0	<b>Y032</b> control pressure solenoid valve	+UB short circuit	No valve actuation possible	
0A.1.F2	<b>Y032</b> control pressure solenoid valve	Current too high, faulty valve (short circuit to earth)	No valve actuation possible	
0A.1.F3	<b>Y032</b> control pressure solenoid valve	Break in wiring	No valve actuation possible	
0A.1.F4	<b>Y181</b> front power lift control valve	Short circuit to earth or +UB or break in wiring	No raising possible	
0A.1.F5	<b>Y181</b> front power lift control valve	Short circuit to earth or +UB or break in wiring	No lowering possible	
0A.1.F6	<b>Y060</b> rear hydraulic oil preheater solenoid valve	Actuation fault	No further valve heating possible	
0A.1.F7	<b>Y061</b> middle hydraulic oil preheater solenoid valve	Actuation fault	No further valve heating possible	

Fault code	DIN brief description	Cause	Consequences	Note/remedy
0A.1.F9	<b>Y012</b> suspension loading/oil preheating solenoid valve	Loading valve fault		
0A.1.FA	<b>S067</b> external raise valve actuation button	Faulty button, Signal fault	Button inoperable until next trouble-free cold start	
0A.1.FB	<b>S068</b> external lower valve actuation button	Faulty button, Signal fault	Button inoperable until next trouble-free cold start	
0A.1.FC	<b>S067</b> external raise valve actuation button <b>S068</b> external lower valve actuation button	Double actuation, faulty button, signal fault		
0A.1.FD	<b>Y082</b> lock lower link stabilizer solenoid valve	Solenoid valve faulty	No locking possible	
0A.1.FE	<b>Y083</b> release lower link stabilizer solenoid valve	Solenoid valve faulty	No opening possible	
0A.2.92	<b>A100</b> MFA, multifunction armrest	Linear module 1 (rocker) stuck		
0A.2.93	<b>A100</b> MFA, multifunction armrest	Linear module 2 (rocker) stuck		
0A.2.94	<b>A100</b> MFA, multifunction armrest	Linear module 3 (rocker) stuck		
0A.2.95	<b>A100</b> MFA, multifunction armrest	Linear module 4 (rocker) stuck		
0A.2.96	<b>A100</b> MFA, multifunction armrest	Crossgate lever (horizontal) stuck		
0A.2.97	<b>A100</b> MFA, multifunction armrest	Crossgate lever (horizontal) stuck		
0A.2.9A	<b>A100</b> MFA, multifunction armrest	Right joystick actuation, one of the three buttons is stuck		
0A.2.9B	<b>A100</b> MFA, multifunction armrest	Left joystick actuation, one of the three buttons is stuck		
0A.2.A8	<b>A100</b> MFA, multifunction armrest	Crossgate lever double actuation "yellow"		

Fault code	DIN brief description	Cause	Consequences	Note/remedy
0A.2.A9	<b>A100</b> MFA, multifunction armrest Crossgate lever	Crossgate lever double actuation "blue"		
0A.2.AA	<b>A100</b> MFA, multifunction armrest Joystick	Joystick double actuation, right		
0A.2.AB	<b>A100</b> MFA, multifunction armrest Joystick	Joystick double actuation, left		
0A.2.AC	<b>A100</b> MFA, multifunction armrest	Linear module 1 double actuation (rocker)		
0A.2.AD	<b>A100</b> MFA, multifunction armrest	Linear module 2 double actuation (rocker)		
0A.2.AE	<b>A100</b> MFA, multifunction armrest	Linear module 3 double actuation (rocker)		
0A.2.AF	<b>A100</b> MFA, multifunction armrest	Linear module 4 double actuation (rocker)		
0A.2.CB	<b>A050</b> basic control unit ECU	Steering axle active		
0A.2.CC	<b>A050</b> basic control unit ECU	Steering axle not active		

## 2.2.6 Fault code 1D.0.00 -

Fault code	DIN brief description	Cause	Consequences	Note/remedy
<b>If the following errors occur (1D.0 etc.), they must be deleted in the engine control unit following error correction with SERDIA!</b>				
1D.0.09	<b>B086</b> rail pressure sensor	Opening of rail DBV valve recognized	Message appears, indicating that the engine will stop after approx. five minutes	Read out the KWP code using SERDIA/Fendias
1D.0.40	<b>B102</b> AdBlue temperature/level sensor	Reduction in power as fill level is too low (with warning bleeper)	Top up AdBlue	
1D.0.42	AdBlue	Reduction in power due to AdBlue quality (with warning bleeper)		
1D.0.44	<b>A099</b> engine control ECU (EDC 17)	Reduction in power due to incorrect AdBlue conversion rate (with warning bleeper)		
1D.0.46	<b>A099</b> engine control ECU (EDC 17)	Reduction in power as manipulation of the SCR system was detected (with warning bleeper)		
1D.0.62	<b>B086</b> rail pressure sensor	Rail pressure fault		Read out the KWP code using SERDIA/Fendias
1D.0.A1	<b>B090</b> oil pressure sensor	Engine oil pressure too low		Read out the KWP code using SERDIA/Fendias
1D.1.00	<b>A099</b> engine control ECU (EDC 17)	Original Deutz error		Read out the KWP code using SERDIA/Fendias
1D.1.01	<b>B090</b> oil pressure sensor	Broken wire or short circuit. Oil pressure outside of setpoint range		Read out the KWP code using SERDIA/Fendias

Fault code	DIN brief description	Cause	Consequences	Note/remedy
1D.1.02	<b>B087</b> fuel low pressure sensor	Broken wire or short circuit Fuel low pressure outside setpoint range	Check fuel system; air may be in the system or the fuel filter may be blocked	Read out the KWP code using SERDI/A/Fendias
1D.1.03	<b>B092</b> boost pressure/charge air temperature sensor	Broken wire or short circuit Limits exceeded or specified values not reached	Reduced power	Read out the KWP code using SERDI/A/Fendias
1D.1.04	<b>B086</b> rail pressure sensor	Broken wire or short circuit Rail pressure outside setpoint range	Message appears, indicating that the engine will stop after approx. 5 minutes	Read out the KWP code using SERDI/A/Fendias
1D.1.05	<b>B089</b> engine temperature sensor (Deutz)	Coolant temperature sensor: break in wiring or short circuit. Coolant temperature outside setpoint area		Read out the KWP code using SERDI/A/Fendias
1D.1.07	<b>B085</b> camshaft speed sensor <b>B088</b> crankshaft speed sensor	Camshaft sensor faulty or no signal; crankshaft sensor faulty or no signal; camshaft/crankshaft speed signals out of phase	Starting possible after prolonged unsuccessful attempt, engine runs "rough"	Read out the KWP code using SERDI/A/Fendias
1D.1.08	<b>Y091</b> fuel dispensing unit <b>B086</b> rail pressure sensor	Dispensing unit not connected, Short circuit to battery or earth Rail pressure outside setpoint range	Message appears, indicating that the engine will stop after approx. five minutes	Read out the KWP code using SERDI/A/Fendias
1D.1.0A	<b>B085</b> camshaft speed sensor <b>B088</b> crankshaft speed sensor	Engine overspeed Value exceeded, pushing mode		Read out the KWP code using SERDI/A/Fendias
1D.1.0C	<b>K063</b> heater flange relay	Broken wire or short circuit Actuation faulty	Preheater inoperable	Read out the KWP code using SERDI/A/Fendias
1D.1.0D	<b>S034</b> coolant level switch	Coolant level too low		Read out the KWP code using SERDI/A/Fendias

Fault code	DIN brief description	Cause	Consequences	Note/remedy
1D.1.10	<b>B102</b> AdBlue temperature/level sensor	Broken wire or short circuit, Fill level too low, Temperature limit exceeded or not reached		Read out the KWP code using SERDI/A/Fendias
1D.1.11	<b>Y120</b> AdBlue metering valve	Broken wire or short circuit Current value too low Nozzle jammed Coolant line to metering valve crushed		Read out the KWP code using SERDI/A/Fendias
1D.1.12	<b>A084</b> AdBlue module	Broken wire or short circuit, Current value too low, Limit exceeded or not reached Return valve fault, Pressure too low, General module fault	Check AdBlue filter, Check the intake opening on the <b>B102</b> AdBlue temperature/level sensor, Check the AdBlue suction line from the <b>B102</b> AdBlue temperature/level sensor to the AdBlue module Check relay K090, Check earth points	Read out the KWP code using SERDI/A/Fendias
1D.1.13	<b>A082</b> nitrogen oxide NOx sensor 1, upstream of SCR	Current value too low or wire break, NOx Sensor CAN message faulty	Check fuse F60	Read out the KWP code using SERDI/A/Fendias
1D.1.14	<b>A083</b> nitrogen oxide NOx sensor 2, downstream of SCR	Current value too low or wire break NOx Sensor CAN message faulty	Check fuse F60	Read out the KWP code using SERDI/A/Fendias
1D.1.15 <b>for 700 series</b>	<b>B236</b> exhaust gas temperature upstream of SCR sensor	Broken wire or short circuit Limit exceeded or specified value not reached		Read out the KWP code using SERDI/A/Fendias

Fault code	DIN brief description	Cause	Consequences	Note/remedy
1D.1.15 <b>for 500 series</b>	<b>B244</b> - Exhaust gas temperature upstream of SCR sensor	Broken wire or short circuit Limit exceeded or specified value not reached		Read out the KWP code using SERDIA/Fendias
1D.1.16	SCR general	NOx conversion rate insufficient - SCR catalytic converter faulty - Insufficient AdBlue quality		Read out the KWP code using SERDIA/Fendias
1D.1.17	<b>A099</b> engine control ECU (EDC 17) <b>Y095</b> injector 1 <b>Y096</b> injector 2 <b>Y097</b> injector 3 <b>Y098</b> injector 4 <b>Y100</b> injector 5 <b>Y101</b> injector 6	Misfiring on one or more injectors Broken wire or short circuit		Read out the KWP code using SERDIA/Fendias
1D.1.19	<b>Y222</b> Visco fan (Viscotronic)	Broken wire or short circuit Limits exceeded or specified values not reached		Read out the KWP code using SERDIA/Fendias
1D.1.1B	<b>A099</b> engine control ECU (EDC 17)	EDC internal error		Read out the KWP code using SERDIA/Fendias
1D.1.1C	<b>M001</b> starter	Broken wire or short circuit Terminal 50 signal faulty		Read out the KWP code using SERDIA/Fendias



Fault code	DIN brief description	Cause	Consequences	Note/remedy
1D.1.1D	DBV rail	Pressure-limiting valve (DBV) has reached maximum number of switching operations. DBV has exceeded maximum permitted opening time	Replace rail pressure DBV and <b>B086</b> rail pressure sensor. Reset "rail pressure DBV counter" using SERDIA	Read out the KWP code using SERDIA/Fendias
1D.1.20	<b>S047</b> engine brake switch <b>Y170</b> engine brake solenoid valve	Valve or switch wire break or short circuit		Read out the KWP code using SERDIA/Fendias
1D.1.21	<b>B092</b> boost pressure/charge air temperature sensor	Charge air temperature too high		Read out the KWP code using SERDIA/Fendias
1D.1.22	<b>B004</b> vacuum switch (air filter)	Air filter contaminated		Read out the KWP code using SERDIA/Fendias
1D.1.23	<b>A077</b> immobilizer ECU <b>A099</b> engine control ECU (EDC 17)	No manipulation protection		Read out the KWP code using SERDIA/Fendias
1D.1.24	<b>A099</b> engine control ECU (EDC 17)	Engine starting problems (e.g. fault in injection system)		Read out the KWP code using SERDIA/Fendias
1D.1.25	<b>A084</b> AdBlue module <b>E216</b> AdBlue suction and return line heater <b>E217</b> AdBlue pressure line heater	Cable iced up, pressure too high or low, heater faulty, return valve jammed	Check fuse F55, Check relay K091 and K092, Check earth points	Read out the KWP code using SERDIA/Fendias
1D.1.26	<b>A084</b> AdBlue module	Not possible to empty system		Read out the KWP code using SERDIA/Fendias

Fault code	DIN brief description	Cause	Consequences	Note/remedy
1D.1.29	Exhaust gas temperature upstream of turbo	Broken wire or short circuit, Limit value outside setpoint range		
1D.1.30	<b>A136</b> wastegate ECU	Current value too low or wire break, CAN message from/to actuator faulty, other actuator error		Read out the KWP code using SERDI/A/Fendias
1D.1.31	<b>B195</b> AdBlue quality sensor	Insufficient AdBlue quality	Check AdBlue quality	Read out the KWP code using SERDI/A/Fendias
1D.1.32	<b>B102</b> AdBlue temperature/level sensor	AdBlue level too low	Top up AdBlue	Read out the KWP code using SERDI/A/Fendias
1D.1.34	<b>B192</b> CSF differential pressure sensor	Broken wire or short circuit Pressure difference outside limit value		Read out the KWP code using SERDI/A/Fendias
1D.1.35	<b>A134</b> exhaust gas recirculation ECU	Internal fault, calibration fault, CAN message from/to actuator faulty, Other actuator fault		Read out the KWP code using SERDI/A/Fendias
1D.1.37	<b>B191</b> exhaust gas pressure upstream of turbo sensor	Broken wire or short circuit Limit exceeded		Read out the KWP code using SERDI/A/Fendias
1D.1.38	<b>B193</b> exhaust temperature upstream of CSF sensor	Broken wire or short circuit Limit exceeded		Read out the KWP code using SERDI/A/Fendias
1D.1.39	<b>B194</b> pressure downstream of CSF sensor	Broken wire or short circuit Limit exceeded		Read out the KWP code using SERDI/A/Fendias

Fault code	DIN brief description	Cause	Consequences	Note/remedy
1D.1.3A	<b>B102</b> AdBlue temperature/level sensor	AdBlue tank temperature not in operating range		Read out the KWP code using SERDI/A/Fendias
1D.1.3B	<b>A133</b> air intake throttle ECU	Broken wire or short circuit Overcurrent, incorrect angle		Read out the KWP code using SERDI/A/Fendias
1D.1.4C <b>for 700 series</b>	<b>B236</b> exhaust gas temperature upstream of SCR sensor	Measured value is illogical		Read out the KWP code using SERDI/A/Fendias
1D.1.4C <b>for 500 series</b>	<b>B244</b> - Exhaust gas temperature upstream of SCR sensor	Measured value is illogical		Read out the KWP code using SERDI/A/Fendias
1D.1.4E	<b>A099</b> engine control ECU (EDC 17)	DPF regeneration monitoring		Read out the KWP code using SERDI/A/Fendias
1D.1.4F	<b>A099</b> engine control ECU (EDC 17)	SCR regeneration		Read out the KWP code using SERDI/A/Fendias
1D.1.54	<b>A099</b> engine control ECU (EDC 17)	Temperature outside target range		Read out the KWP code using SERDI/A/Fendias
1D.1.60	<b>B086</b> rail pressure sensor	Leak detected		Read out the KWP code using SERDI/A/Fendias
1D.1.65	<b>B092</b> boost pressure/charge air temperature sensor	Boost pressure outside target range		Read out the KWP code using SERDI/A/Fendias

Fault code	DIN brief description	Cause	Consequences	Note/remedy
1D.1.66	<b>A134</b> exhaust gas recirculation ECU	EGR flow		Read out the KWP code using SERDIA/Fendias
1D.1.68	<b>B218</b> venturi differential pressure sensor	Short circuit to battery or broken wire		Read out the KWP code using SERDIA/Fendias
1D.1.69	<b>A134</b> exhaust gas recirculation ECU	Actuator blocked or sluggish		Read out the KWP code using SERDIA/Fendias
1D.1.76	<b>A099</b> engine control ECU (EDC 17) <b>Y095</b> injector 1 <b>Y096</b> injector 2 <b>Y097</b> injector 3 <b>Y098</b> injector 4 <b>Y100</b> injector 5 <b>Y101</b> injector 6	Fault in one or more injectors		Read out the KWP code using SERDIA/Fendias
1D.1.79	<b>B217</b> temperature downstream of venturi sensor	Electrical fault		Read out the KWP code using SERDIA/Fendias
1D.1.7A	<b>B194</b> pressure downstream of CSF sensor	Plausibility error		Read out the KWP code using SERDIA/Fendias
1D.1.7C	<b>B092</b> boost pressure/charge air temperature sensor	Boost pressure too high		Read out the KWP code using SERDIA/Fendias
1D.1.A5	<b>B089</b> engine temperature sensor (Deutz)	Coolant temperature too high		Read out the KWP code using SERDIA/Fendias

Fault code	DIN brief description	Cause	Consequences	Note/remedy
1D.1.A9	<b>A099</b> engine control ECU (EDC 17)	SCR lines, SCR pressure monitoring/return line		Read out the KWP code using SERDI/A/Fendias
1D.1.AA	<b>A099</b> engine control ECU (EDC 17)	SCR monitoring, crystallization, Standstill requested		Read out the KWP code using SERDI/A/Fendias
1D.1.AB	<b>A099</b> engine control ECU (EDC 17)	SCR, emissions not met, Emissions efficiency test, emissions above upper physical value		Read out the KWP code using SERDI/A/Fendias
1D.1.AC	<b>A099</b> engine control ECU (EDC 17)	DPF, ash/soot load of particulate filter, Warning/shut-off threshold for ash load exceeded		Read out the KWP code using SERDI/A/Fendias
1D.1.B2	<b>A099</b> engine control ECU (EDC 17)	Fault in voltage supply		Read out the KWP code using SERDI/A/Fendias
1D.1.B5	<b>Y170</b> engine brake solenoid valve			Read out the KWP code using SERDI/A/Fendias
1D.1.B6	<b>Y170</b> engine brake solenoid valve			Read out the KWP code using SERDI/A/Fendias
1D.1.BA	<b>A099</b> engine control ECU (EDC 17)	CAN bus fault		Read out the KWP code using SERDI/A/Fendias
1D.2.06	<b>B055</b> foot throttle sensor	Broken wire or short circuit Signal does not match idle sensor signal	Speed maintained, can be used with hand throttle by increasing speed briefly	Read out the KWP code using SERDI/A/Fendias

Fault code	DIN brief description	Cause	Consequences	Note/remedy
1D.2.0B	<b>A099</b> engine control ECU (EDC 17)	CAN BUS fault		Read out the KWP code using SERDIA/Fendias
1D.2.18	<b>B076</b> exterior temperature sensor	Broken wire or short circuit Limits exceeded or specified values not reached		Read out the KWP code using SERDIA/Fendias
1D.2.1A	<b>B091</b> water in fuel sensor	Broken wire or short circuit Water level above setpoint range	Draining water	Read out the KWP code using SERDIA/Fendias
1D.2.1E	<b>Y169</b> AdBlue tank heater solenoid valve	Broken wire or short circuit Valve jammed	Check fuse F52, Check relay K083	Read out the KWP code using SERDIA/Fendias
1D.2.1F	<b>A077</b> immobilizer ECU <b>A099</b> engine control ECU (EDC 17)	Immobilizer fault		Read out the KWP code using SERDIA/Fendias
1D.2.41	<b>B102</b> AdBlue temperature/level sensor	Reduction in power as fill level is too low (without warning bleeper)	Top up AdBlue	
1D.2.43	AdBlue	Reduction in power due to AdBlue quality (without warning bleeper)		
1D.2.45	<b>A099</b> engine control ECU (EDC 17)	Reduction in power due to incorrect AdBlue conversion rate (without warning bleeper)		
1D.2.47	<b>A099</b> engine control ECU (EDC 17)	Reduction in power as manipulation of the SCR system was detected (without warning bleeper)		
1D.2.49	<b>A099</b> engine control ECU (EDC 17)	Torque reduction without fault in order to protect the engine		Read out the KWP code using SERDIA/Fendias
1D.2.52	<b>A133</b> air intake throttle ECU			Read out the KWP code using SERDIA/Fendias

Fault code	DIN brief description	Cause	Consequences	Note/remedy
1D.2.77	<b>A099</b> engine control ECU (EDC 17) <b>Y095</b> injector 1 <b>Y096</b> injector 2 <b>Y097</b> injector 3 <b>Y098</b> injector 4 <b>Y100</b> injector 5 <b>Y101</b> injector 6	Fault in one or more injectors		Read out the KWP code using SERDIA/Fendias
1D.2.AF	<b>A099</b> engine control ECU (EDC 17)	Oil change request due to excessively frequent requests for standstill regeneration		Read out the KWP code using SERDIA/Fendias
1D.2.B3	<b>A099</b> engine control ECU (EDC 17)	Fault in voltage supply		Read out the KWP code using SERDIA/Fendias
1D.2.B8	<b>A099</b> engine control ECU (EDC 17)	Ambient pressure		Read out the KWP code using SERDIA/Fendias
1D.2.F0	<b>A099</b> engine control ECU (EDC 17)			Read out the KWP code using SERDIA/Fendias

**NOTE:**  
Observe the calibration sequence.  
Calibrations 1 to 9 as well as 17 to 19 can be performed in any order.  
**Calibrations 10 to 15 must be performed in sequence and as a block** (transmission calibration)  
The transmission emergency operation must not be switched on during calibration.  
(In case of transmission calibration, transmission oil temperature should be higher than approx. 40 °C.)

If incorrect values are detected or the conditions are not met, the message **ERROR** appears. If calibration completes successfully, **OK** is displayed, and the new sensor settings are stored. Data is only accepted when the ignition key is turned to position "0". Wait for at least 15 seconds before switching on the ignition again.

- The following sensors and functions require calibration**
1. EPC rear calibration (depth control code 8001 and rear power lift position code 8002)
  2. Front EPC calibration (code 9001 and code 9002)
  3. Calibration, crossgate lever (hydraulic auxiliary valves) (code 1001)
  4. Calibration of linear modules 1–4; for hydraulic auxiliary spool valves (code 1003–1006)
  5. Front axle suspension calibration (code 766)
  6. Steering angle sensor calibration (2401)
  7. VarioGuide steering valve calibration (Code 2403)
  8. Rear PTO engagement time calibration (code 6034)
  9. Front PTO engagement time calibration (code 7034)
  10. Drive clutch pedal calibration (code 4001)
  11. Hand throttle calibration (code 4002)
  12. Travel range selector calibration, (code 4003)
  13. Foot throttle pedal calibration (code 4005)
  14. Transmission ratio characteristic calibration (code 4007)
  15. Turbo-clutch function calibration (code 4009)
  16. Accelerator pedal resolution Calibration, (code 4010)
  17. Heater valve Calibration, (no code)
  18. Maintenance — change windscreen wiper (300°) (no code)
  19. Speed display calibration (no code)

To compensate for mechanical and electrical tolerances in sensors, the sensors concerned must be calibrated.

If a sensor is replaced, it must also be calibrated.

## 2.2.7 General information on calibration



**Menu levels on the A007 - Instrument panel**

**If no error message is present:**



Press "Return." The first main menu level appears on the multiple display.



Press one of the buttons repeatedly until the symbol (A) flashes.



Press "Return". The second main menu level appears on the multiple display.

Second main menu on the A007 instrument panel




Fig. 6




Fig. 7



Transmission menu (A)

Front PTO menu (B) (for front PTO only)

Front power lift menu (C) (for EPC front power lift only)

Front axle suspension menu (D)

Rear PTO menu (E)

**Rear PTO menu**

Rear PTO menu




Fig. 9



Transmission calibration, display (A)

Change wheel circumference, display (B)

Calibrating speed display (C)

Change acceleration rate | display (D) (Note: Adjustment range from 0,02 km/h ... 0,5 km/h possible)

**Transmission menu**

Transmission menu




Fig. 8



Rear power lift menu (F)

Hydraulics menu (G)

Steering menu (H)

Heater valve menu and windscreen wiper (300°) menu (J)



Rear PTO calibration, display (A)



Select factory setting for auto mode switch-on point, display (B) (see also: Operating Manual)



Change auto mode switch-on point, display (C) (see also: Operating Manual)

### Heater and windscreen wiper (300°) menu Move windscreen wiper (300°) to tool change position

- The heating valve calibration/windscreen wiper menu level appears on the multiple display.



Press one of the buttons repeatedly until the symbol (A) flashes.



Press button.

- The symbol to the left appears on the multiple display.
- The windscreen wiper moves to a horizontal position.
- The wiper blade can be changed in this position.



Fig. 10



Fig. 11



Press the button several times to return to the default display in the instrument panel.

- Once the wiper blade has been changed, the windscreen wiper can be moved to the default position using the combination switch (F).





Fig. 12



Press ESC to confirm the warning and fault messages displayed on the **A007** - instrument panel.

Fig. 14



Refer to Service Information 18/2012.

**IMPORTANT:**

- Hand brake applied
- Ignition ON
- If fault messages are displayed, the faults must be confirmed one by one.


**Important: The following preparatory steps must be carried out.**

**2.2.8 Calibration code 1001 (crossgate lever)**

**NOTE:** Settings are only stored when the ignition key has been turned to the "0" position. Wait for at least 15 seconds before switching on the ignition again.

If incorrect values are detected or the conditions are not met, the message **ERROR** appears. If calibration is completed without errors, **O.K.** appears and the new sensor settings are saved.

Fig. 13



The display flashes during the calibration process.

**NOTE:**

Press the button until the heater symbol flashes.  
The calibration process is automatic (approx. 30 seconds).  
The heater valve stepper motor is opened and closed slowly.



**Adjusting heater valve**



Press "Return." The first main menu level appears on the multiple display.



Press one of the buttons repeatedly until the symbol (A) flashes



Press "Return". The second main menu level appears on the multiple display.



Press one of the buttons repeatedly until the symbol (A) flashes.



Press "Return" to confirm.

The auxiliary spool valve menu appears on the multiple display.



Press one of the buttons repeatedly until the symbol (A) flashes.



Press "Return" to confirm.

Input code **1001**



Press one of buttons until desired number is displayed.



Press "Return" to confirm.

Fig. 18




Fig. 17




Fig. 16





Fig. 15






Fig. 19




Fig. 20




Fig. 21








Fig. 22

Release crossgate lever (centres automatically).  
 Press "Return" to confirm this position.

Push crossgate lever to right and exert excessive pressure against spring.  
 Hold crossgate lever.  
 Press "Return" to confirm this position.

Push crossgate lever to left (exert excessive pressure against spring).  
 Hold crossgate lever.  
 Press "Return" to confirm this position.

Push crossgate lever forward (exert excessive pressure against spring).  
 Hold crossgate lever.  
 Press "Return" to confirm this position.

Pull crossgate lever backwards (exert excessive pressure against spring).  
 Hold crossgate lever.  
 Press "Return" to confirm this position.



First move the crossgate lever to the right, and exert and hold excessive pressure on the spring. In this position, move the crossgate lever forwards and exert excessive pressure on the spring. Hold crossgate lever.  
 Press "Return" to confirm this position.



First move the crossgate lever to the right, and exert and hold excessive pressure on the spring. In this position, move the crossgate lever backwards and exert excessive pressure on the spring. Hold crossgate lever.  
 Press "Return" to confirm this position.



First move the crossgate lever to the left, and exert and hold excessive pressure on the spring. In this position, move the crossgate lever backwards and exert excessive pressure on the spring. Hold crossgate lever.  
 Press "Return" to confirm this position.




Fig. 23




Fig. 24




Fig. 25




Fig. 26

First move the crossgate lever to the left, and exert and hold excessive pressure on the spring. In this position, move the crossgate lever forwards and exert excessive pressure on the spring. Hold crossgate lever. Press "Return" to confirm this position.



Push crossgate lever to right (do not exert excessive pressure against spring). Hold crossgate lever. Press "Return" to confirm this position.



Push crossgate lever to left (do not exert excessive pressure against spring). Hold crossgate lever. Press "Return" to confirm this position.



Push crossgate lever forwards (do not exert excessive pressure against spring). Hold crossgate lever. Press "Return" to confirm this position.




Fig. 27




Fig. 28




Fig. 29




Fig. 30




Pull crossgate lever backwards (do not exert excessive pressure against spring).  
Hold crossgate lever.



Press "Return" to confirm this position.

Fig. 31



If calibration is completed without errors, **O.K.** appears and the new sensor settings are saved.  
**NOTE:** Settings are only adopted when the ignition key has been turned to "0" position. Wait for at least 15 seconds before switching on the ignition again.

If incorrect values are detected or the conditions are not met, the message **ERROR** appears.

**1001** = calibration code

**FXX** = fault code

**NOTE:**

See also: fault code for calibration 1001

Fig. 32




Fig. 33



## 8. Calibrating the front axle suspension (7666)



**WARNING:**

Once the input code has been confirmed, the tractor will raise and lower automatically!

**Important: The following preparatory steps must be carried out.**

- Position the tractor on a flat, level surface
- Hand brake applied
- Start engine.
- If fault messages are displayed, the faults must be confirmed one by one.



Press "ESC" to confirm the warning and fault messages displayed on the A007 instrument panel.



Press "Return." The first main menu level appears on the multiple display.



Press one of the buttons repeatedly until the symbol (A) flashes.



Press "Return". The second main menu level appears on the multiple display.



Press one of the buttons repeatedly until the symbol (A) flashes.



Press "Return" to confirm.



Press one of the buttons repeatedly until the symbol (A) flashes.



Press "Return" to confirm.




Fig. 34




Fig. 35




Fig. 36





Fig. 37

**WARNING:** Once the input code has been confirmed, the tractor will raise and lower automatically!  
 Input code **7666**



Press one of the buttons until the desired number is displayed.



Press "Return" to confirm.

The flashing arrow indicates the desired limit position.

The tractor is raised to the upper limit position.



Press "Return" to confirm the upper limit position.

The flashing arrow indicates the desired limit position.

The tractor is lowered to the lower limit position.



Press "Return" to confirm the lower limit position.




Fig. 38




Fig. 39




Fig. 40

If incorrect values are detected or the conditions are not met, the message **ERROR** appears.


If calibration is completed without errors, **O.K.** appears and the new sensor settings are saved.

**NOTE:**

Settings are only adopted when the ignition key has been turned to "0" position. Wait for at least 15 seconds before switching on the ignition again.

If incorrect values are detected or the conditions are not met, the message **ERROR** appears.  
**7666** = calibration code  
**FXX** = fault code  
**NOTE:** See also: "Fault code for calibration code 7666"

Fig. 41



## 2.2.10 Calibration code 4001 (clutch pedal)

### 12. Calibrating the clutch pedal

The following preparatory steps must be carried out

- Ignition ON
- Hand brake applied
- If fault messages are displayed, the faults must be confirmed one by one.



Press "ESC" to confirm the warning and fault messages displayed on the A007 instrument panel.



Press one of the buttons repeatedly until the symbol (A) flashes.



Press "Return." The first main menu level appears on the multiple display.



Press "Return". The second main menu level appears on the multiple display.

Fig. 43






Fig. 42



The second main menu level appears on the multiple display.




Press one of the buttons repeatedly until the symbol (A) flashes.

Press "Return" to confirm.



The transmission menu level appears on the multiple display.




Press one of the buttons repeatedly until the symbol (A) flashes.

Press "Return" to confirm.



Input code **4001**



Press one of buttons until desired number is displayed.

Press "Return" to confirm.



Clutch pedal **not** depressed



Press "Return" to confirm.

Fig. 44




Fig. 45




Fig. 46





Fig. 47



Clutch pedal depressed



Press "Return" to confirm.

If calibration is completed without errors, **O.K.** appears and the new sensor settings are saved.

**NOTE:**

Settings are only adopted when the ignition key has been turned to "0" position. Wait for at least 15 seconds before switching on the ignition again.

If incorrect values are detected or the conditions are not met, the message **ERROR** appears.

**4001** = calibration code

**FXX** = error code (see table)

### 2.2.11 Calibration code 4002 (hand throttle)

#### 13. Calibrating the hand throttle (4002)

The following preparatory steps must be carried out

- Hand brake applied
- Ignition ON
- If fault messages are displayed, the faults must be confirmed one by one.




Fig. 48




Fig. 49



Fig. 50



Press "ESC" to confirm the warning and fault messages displayed on the A007 instrument panel.



Press "Return." The first main menu appears on the multiple display.



Press one of the buttons repeatedly until the symbol (A) flashes.



Press "Return". The second main menu level appears on the multiple display.



Press one of the buttons repeatedly until the symbol (A) flashes.



Press "Return" to confirm.

The transmission menu level appears on the multiple display.



Press one of the buttons repeatedly until the symbol (A) flashes.



Press "Return" to confirm.




Fig. 51




Fig. 52




Fig. 53




Fig. 54

Input code **4002**



Press one of buttons until desired number is displayed.



Press "Return" to confirm.

Turn the hand throttle to the **maximum** position.



Press "Return" to confirm.

Turn the hand throttle to the **minimum** position.



Press "Return" to confirm.

If calibration is completed without errors, **O.K.** appears and the new sensor settings are saved.

**NOTE:** Settings are only adopted when the ignition key has been turned to "0" position. Wait for at least 15 seconds before switching on the ignition again.



Fig. 55




Fig. 56




Fig. 57




Fig. 58



If incorrect values are detected or the conditions are not met, the message **ERROR** appears.  
**4002** = calibration code  
**FX** = error code (see table)




Fig. 59

## 2.2.12 Calibration code 4003 (travel speed range selector)

### 14. Calibrating the travel speed range selector (4003)

The following preparatory steps must be carried out

- Transmission oil temperature is approx. 40 °C
- Hand brake applied
- Start engine.
- Clutch pedal depressed
- Engine speed approx. 800 rpm (idle speed)
- If fault messages are displayed, the faults must be confirmed one by one:



Press "ESC" to confirm the warning and fault messages displayed on the A007 instrument panel.



Press "Return." The first main menu level appears on the multiple display.



Press one of the buttons repeatedly until the symbol (A) flashes.



Press "Return". The second main menu level appears on the multiple display.

Fig. 60






Fig. 61



The second main menu level appears on the multiple display.




Press one of the buttons repeatedly until the symbol (A) flashes.

Press "Return" to confirm.



The transmission menu level appears on the multiple display.




Press one of the buttons repeatedly until the symbol (A) flashes.

Press "Return" to confirm.



Input code **4003**



Press one of buttons until desired number is displayed.

Press "Return" to confirm.



Travel speed range I is displayed and enabled automatically.




Fig. 62




Fig. 63



Fig. 64




Fig. 65

Travel speed range II is displayed and enabled automatically.

The center position is displayed and enabled automatically.

If incorrect values are detected or the conditions are not met, the message **ERROR** appears.



If calibration is completed without errors, the screen appears and the new settings are saved. Press "ESC" to confirm the warning and fault messages displayed on the A007 instrument panel.

**NOTE:** Settings are only adopted when the ignition key has been turned to "0" position. Wait for at least 15 seconds before switching on the ignition again.

If calibration is completed without errors, **O.K.** appears and the new sensor settings are saved.




Fig. 66




Fig. 67




Fig. 68




Fig. 69

If incorrect values are detected or the conditions are not met, the message **ERROR** appears.  
**4003** = calibration code  
**FXX** = fault code




Fig. 70

### 2.2.13 Calibration code 4005 (foot throttle/accelerator pedal)

#### 15. Calibrating the foot throttle/accelerator pedal (4005)

The following preparatory steps must be carried out

- Hand brake applied
- Ignition ON

- If fault messages are displayed, the faults must be confirmed one by one.



Press "ESC" to confirm the warning and fault messages displayed on the A007 instrument panel.



Press one of the buttons repeatedly until the symbol (A) flashes.



Press "Return." The first main menu level appears on the multiple display.



Press "Return." The second main menu level appears on the multiple display.




Fig. 71





Fig. 72

The second main menu level appears on the multiple display.




Press one of the buttons repeatedly until the symbol (A) flashes.

Press "Return" to confirm.



The transmission menu level appears on the multiple display.




Press one of the buttons repeatedly until the symbol (A) flashes.

Press "Return" to confirm.



Input code **4005**



Press one of buttons until desired number is displayed.

Press "Return" to confirm.



**Fully depress** the foot throttle/driving pedal



Press "Return" to confirm.




Fig. 73




Fig. 74




Fig. 75




Fig. 76

- Transmission oil temperature is approx. 40 °C
- Hand brake applied
- Start engine.
- Tractor stationary (speed below 0,01 km/h)
- Engine speed 1600 rpm ± 30 rpm
- The engine speed must not drop below 1400 rpm during calibration

The following preparatory steps must be carried out:

16. Calibrating the transmission ratio characteristic

2.2.14 Calibration code 4007 (transmission ratio characteristic)

If incorrect values are detected or the conditions are not met, the message **ERROR** are not met, the message **ERROR** 4005 = calibration code FXX = fault code

**NOTE:** Settings are only adopted when the ignition key has been turned to "0" position. Wait for at least 15 seconds before switching on the ignition again.

If calibration is completed without errors, **O.K.** appears and the new sensor settings are saved.

Press "Return" to confirm.



Foot throttle/driving pedal in idle position



Fig. 79




Fig. 78




Fig. 77

- No error messages from speed sensors (sensor, engine speed and B014 sensor, hydrostatic collecting shaft)
- Neutral switch not in neutral (LED off), transmission is engaged (active standstill)
- Range selector in neutral (normal after calibration of the travel range selector (code 4003))
- Manually set the transmission to neutral via the emergency operation if necessary.
- Clutch pedal not depressed
- If fault messages are displayed, the faults must be confirmed one by one.



Press "ESC" to confirm the warning and fault messages displayed on the A007 instrument panel.




Fig. 80



Transmission in active standstill display

Press "ESC" to confirm




Fig. 81



"Transmission in neutral" display

Press "ESC" to confirm




Fig. 82



Press "Return;" The first main menu appears on the multiple display



Press one of the buttons repeatedly until the symbol (A) flashes



Press "Return"; The second main menu appears in the multiple display



Press one of the buttons repeatedly until the symbol (A) flashes



Press "Return" to confirm



Press one of the buttons repeatedly until the symbol (A) flashes



Press "Return" to confirm



Press one of the buttons repeatedly until the symbol (A) flashes



Press "Return" to confirm



Press one of the buttons repeatedly until the symbol (A) flashes




Fig. 83




Fig. 84




Fig. 85

**NOTE:** Since the transmission automatically reverts to neutral after 15 sec. when the hand brake is applied, reactivate the transmission as necessary.



Input code **4007**



Press one of buttons until desired number is displayed



Press "Return" to confirm

Test steps one (Step1)

to seven (Step 7) run automatically

If calibration completes successfully, the image is displayed and the new sensor values are saved



Press "ESC" to confirm




Fig. 86




Fig. 87




Fig. 88




Fig. 89




Fig. 91




Fig. 90

If incorrect values are detected or the conditions are not met, an **ERROR** message appears (4007) calibration code (FXX) error code (see table)

If calibration is completed without errors, **O.K.** appears and the new sensor settings are saved.  
**NOTE:** Settings are only stored when ignition key has been turned to "0" position.  
 Wait for at least 15 seconds before switching on the ignition again.

Graphic overview of transmission ratio calibration




Fig. 92

**2.2.15 Calibration code 4009 (turbo-clutch function)**

**17. Calibrating the turbo-clutch function (4009)**

The following preparatory steps must be carried out

- Transmission oil temperature is approx. 40 °C
- Start engine.

- Engage transmission travel range II with the switch in the **A100** - Multifunction armrest (MFA)
- Hand brake applied Caution: The tractor may start moving during calibration
- Tractor stationary (speed below 0,01 km/h)
- Engine speed 1100 rpm ± 40 rpm
- Engine speed drops to approx. 800 rpm during the calibration operation
- If fault messages are displayed, the faults must be confirmed one by one.

Press "ESC" to confirm the warning and fault messages displayed on the A007 instrument panel.



Press "Return," The first main menu level appears on the multiple display.

Press one of the buttons repeatedly until the symbol (A) flashes.

Press "Return". The second main menu level appears on the multiple display.



The second main menu level appears on the multiple display.



Press one of the buttons repeatedly until the symbol (A) flashes.

Press "Return" to confirm.




Fig. 93




Fig. 94





Fig. 95

The transmission menu level appears on the multiple display.

Press one of the buttons repeatedly until the symbol (A) flashes.




Press "Return" to confirm.



Input code **4009**

Press one of buttons until desired number is displayed.



Press "Return" to confirm.



The calibration process runs automatically from this point.

The following images appear alternately:

Fig. 96




Fig. 97





Fig. 98



EK107849

- Hand brake applied
- Ignition ON
- If fault messages are displayed, the faults must be confirmed one by one.

**The following preparatory steps must be carried out**  
**18. Calibrating the accelerator pedal resolution (4010)**

**2.2.16 Calibration code 4010 (accelerator pedal resolution)**



Fig. 102




Fig. 101




Fig. 100

If incorrect values are detected or the conditions are not met, the message **ERROR** appears.  
**4009** = calibration code  
**FXX** = fault code

**NOTE:**  
 Settings are only adopted when the ignition key has been turned to the "0" position. Wait for at least 15 seconds before switching on the ignition again.

If calibration is completed without errors, **O.K.** appears and the new sensor settings are saved.



Press "ESC" to confirm the warning and fault messages displayed on the A007 instrument panel.



Press "Return." The first main menu level appears on the multiple display.



Press one of the buttons repeatedly until the symbol (A) flashes.



Press "Return". The second main menu level appears on the multiple display.



Press one of the buttons repeatedly until the symbol (A) flashes.



Press "Return" to confirm.

The second main menu level appears on the multiple display.



Press one of the buttons repeatedly until the symbol (A) flashes.



Press "Return" to confirm.




Fig. 103




Fig. 104




Fig. 105




Fig. 106

Input code **4010**



Press one of buttons until desired number is displayed.



Press "Return" to confirm.

Set "accelerator pedal resolution" sliding switch to *maximum*.



Press "Return" to confirm.

Set "accelerator pedal resolution" sliding switch to *minimum*.



Press "Return" to confirm.

If calibration is completed without errors, **O.K.** appears and the new sensor settings are saved.

**NOTE:** Settings are only adopted when the ignition key has been turned to "0" position. Wait for at least 15 seconds before switching on the ignition again.




Fig. 107




Fig. 108




Fig. 109




Fig. 110



If incorrect values are detected or the conditions are not met, the message **ERROR** appears.  
**4010** = calibration code  
**FXx** = fault code

Fig. 111



## 2.2.17 Calibration fault codes

### Fault code for calibration code 1001

Fault code	Cause	DIN short description
F01	Preliminary conditions for calibration not satisfied	<b>A050</b> basic control unit ECU
F02	Calibrated values are faulty	<b>A100</b> MFA, multifunction armrest
F03	<b>A100</b> MFA, multifunction armrest not responding	<b>A100</b> MFA, multifunction armrest
F08	Calibration taking too long (more than 30 seconds)	
F09	User terminated calibration with "ESC"	

### Fault code for calibration code 1003

Fault code	Cause	DIN short description
F01	Preliminary conditions for calibration not satisfied	<b>A050</b> basic control unit ECU
F02	Calibrated values are faulty	<b>A100</b> MFA, multifunction armrest
F03	<b>A100</b> MFA, multifunction armrest not responding	<b>A100</b> MFA, multifunction armrest
F08	Calibration taking too long (more than 30 seconds)	
F09	User terminated calibration with "ESC"	

### Fault code for calibration code 1004

Fault code	Cause	DIN short description
F01	Preliminary conditions for calibration not satisfied	<b>A050</b> basic control unit ECU
F02	Calibrated values are faulty	<b>A100</b> MFA, multifunction armrest
F03	<b>A100</b> MFA, multifunction armrest not responding	<b>A100</b> MFA, multifunction armrest
F08	Calibration taking too long (more than 30 seconds)	
F09	User terminated calibration with "ESC"	

Fault code	Cause	DIN short description
F01	Preliminary conditions for calibration not satisfied	A050 basic control unit ECU
F04	Switching between "reverse operation" and "normal operation"	B168 steering angle sensor
F08	Calibration taking too long (more than 30 seconds)	
F09	User terminated calibration with "ESC"	
F10	Plausibility of "center position" calibration value	
F11	Plausibility of "left stop" calibration value	
F12	Plausibility of "right stop" calibration value	
F13	Plausibility of calibration values with each other	
F20	Steering wheel sensor behavior for "center position" not as expected	
F21	Steering wheel sensor behavior for "left stop" not as expected	
F22	Steering wheel sensor behavior for "right stop" not as expected	

#### Fault code for calibration code 2401

Fault code	Cause	DIN short description
F01	Preliminary conditions for calibration not satisfied	A050 basic control unit ECU
F02	Calibrated values are faulty	A100 MFA, multifunction armrest
F03	A100 MFA, multifunction armrest not responding	Gray linear module
F08	Calibration taking too long (more than 30 seconds)	
F09	User terminated calibration with "ESC"	

#### Fault code for calibration code 1006

Fault code	Cause	DIN short description
F01	Preliminary conditions for calibration not satisfied	A050 basic control unit ECU
F02	Calibrated values are faulty	A100 MFA, multifunction armrest
F03	A100 MFA, multifunction armrest not responding	Linear module, olive
F08	Calibration taking too long (more than 30 seconds)	
F09	User terminated calibration with "ESC"	

#### Fault code for calibration code 1005

Fault code	Cause	DIN short description
F01	User terminated calibration with "ESC"	A050 basic control unit ECU
F02	Pedal in rest position: Signal greater than allowed (22 mAdc)	B017 clutch pedal sensor
F03	Pedal in rest position: Signal smaller than allowed (2 mAdc)	B017 clutch pedal sensor
F04	Pedal fully depressed: Signal greater than allowed (22 mAdc)	B017 clutch pedal sensor
F05	Pedal fully depressed: Signal smaller than allowed (2 mAdc)	B017 clutch pedal sensor
F06	Calibrated min. and max. values are too close together Minimum difference of 10 mAdc necessary	B017 clutch pedal sensor
F07	Calibration taking too long (more than 30 seconds)	B017 clutch pedal sensor
F08	Transmission in "Active standstill" (Remedy: Put transmission into neutral)	B017 clutch pedal sensor

**Fault code for calibration code 4001**

Fault code	Cause	DIN short description
F01	Preliminary conditions for calibration not satisfied	A050 basic control unit ECU
F02	Front wheels are not straight	A050 basic control unit ECU
F03	Manual steering wheel actuation during calibration	A050 basic control unit ECU
F04	Switching between "normal operation" and "reverse operation"	A050 basic control unit ECU
F05	Handbrake not applied	A050 basic control unit ECU
F06	No movement in direction "steering to left"	A050 basic control unit ECU
F07	No movement in direction "steering to right"	A050 basic control unit ECU
F08	Calibration taking too long	A050 basic control unit ECU
F09	User terminated calibration with ESC	A050 basic control unit ECU
F11	Plausibility: Signal in direction "steering to left"	A050 basic control unit ECU
F12	Plausibility: Signal in direction "steering to right"	A050 basic control unit ECU
F30	Error when switching off the spool position monitoring	A050 basic control unit ECU
F31	Error when switching the spool position monitoring back on	A050 basic control unit ECU

**Fault code for calibration code 2403**

Fault code	Cause	DIN short description
F01	User terminated calibration with "ESC"	A050 basic control unit ECU
F02	Speed above 0,1 Km/h	
F03	Engine speed below 600 rpm	
F04	Engine speed above 900 rpm	
F05	Transmission not in neutral	
F06	Clutch not depressed	
F07	- B015 bevel pinion sensor faulty	
F08	- B014 collecting shaft sensor faulty	
F09	Faulty speed signal from engine	
F10	Neutral switch, joystick faulty ( A100 MFA, multi-function armrest)	
F11	- B016 travel range detection sensor faulty	
F12	- Y002 travel speed range I solenoid valve faulty	
F13	- Y003 travel speed range II solenoid valve faulty	
F20	Calibrated values for neutral position incorrect	
F21	Calibrated values for travel speed range I incorrect	
F22	Calibrated values for travel range II incorrect	
F23	Calibrated values do not match	
F30	Error reading from EEPROM ( A050 basic control unit ECU)	
F31	Error while writing to EEPROM ( A050 basic control unit ECU)	

#### Fault code for calibration code 4003

Fault code	Cause	DIN short description
F02	Calibrated values are faulty	A050 basic control unit ECU A100 MFA, multifunction armrest hand throttle
F03	A100 MFA, multifunction armrest not responding	
F08	Calibration taking too long (more than 30 seconds)	
F09	User terminated calibration with "ESC"	

#### Fault code for calibration code 4002

Fault code	Cause	DIN short description
F02	<b>A009</b> actuator unit reporting a fault Frequent cause of fault: During previous fault-generated calibration exit, no "key reset (ignition OFF/ON)" was carried out	<b>A050</b> basic control unit ECU
F03	<b>A009</b> actuator unit fails to control the specified value exactly. Check that the transmission adjustment is smooth.	
F04	Transmission ratio adjustment not effected within 8 sec. Check that the transmission adjustment is smooth.	
F05	Step 1 = <b>A009</b> actuator unit does not find neutral point 0 in forwards direction. Step 2 = <b>A009</b> actuator unit does not find neutral point 0 in reverse direction. Check connection of <b>A009</b> actuator unit to actuator shaft.	

**Fault code for calibration code 4007**

Fault code	Cause	DIN short description
F21	Transmission in "ACTIVE STANDSTILL". (Remedy: Put transmission into neutral)	<b>A050</b> basic control unit ECU
F22	Signal smaller than 3 mAdc	<b>B055</b> foot throttle sensor
F23	Signal greater than 21 mAdc	
F24	Rotation angle of <b>B055</b> foot throttle sensor is too great (more than 250 steps)	
F25	Distance between idle and full throttle too short (less than 12 mAdc) or <b>B055</b> foot throttle sensor incorrectly calibrated	
F26	Distance between idle and full throttle too short (less than 70%) or <b>B055</b> foot throttle sensor incorrectly calibrated	
F27	Time for a calibration increment exceeded (longer than 60 seconds)	
F28	Internal error in the <b>A050</b> basic control unit ECU Error while saving calibrated values to EEPROM (EOL reprogramming may be necessary)	
F30	User interrupted with ESC	

**Fault code for calibration code 4005**

Fault code	Cause	DIN short description
F06	See under error message F05	
F07	Step 2: The neutral points of the transmission control system for forwards and reverse travel are too far apart, more than 8°. Check connection of <b>A009</b> actuator unit to actuator shaft.	
F08	Step 3: Max. transmission ratio forward point not found. Target value min. 155°, max. 187° Step 4: Max. transmission ratio reverse point not found. Target value min. 136°, max. 165°. Check connection of <b>A009</b> actuator unit to actuator shaft.	
F09	Step 3: Forward actuator shaft adjustment greater than 155°, but transmission rotation reacts less than 155° Step 4: Reverse actuator shaft adjustment greater than 135°, but transmission adjustment reacts below 135° Check connection of <b>A009</b> actuator unit to actuator shaft.	
F10	Transmission ratio characteristic illogical e.g. shifted forward and reverse detected. Repeat calibration. See also error message F 2. Check rotational direction signal from <b>B014</b> collecting shaft sensor	
F11/12	Step 7: check Step 1 to Step 6 values. ML transmission ratio not OK. Repeat calibration. See also error message F 2. Then check hydrostatic power branch, e.g. via emergency operation.	
F13	1. End of line programming incorrect (before step 1) 2. Values stored in the <b>A050</b> basic control unit ECU are illogical Remedy: 1. Perform end of line programming again 2. See 1. Replace <b>A050</b> basic control unit ECU if necessary	
F14	See F 11/F 12	

Fault code	Cause	DIN short description
F01	User terminated calibration with ESC	<b>A050</b> basic control unit ECU
F02	Calibration in emergency mode not possible	<b>Y004</b> clutch/turbo-clutch solenoid valve
F03	Internal error in the <b>A050</b> basic control unit ECU: Error while saving calibrated values to EEPROM (EOL reprogramming may be necessary)	
F04	Road speed greater than 0,1 km/h.	

### Fault code for calibration code 4009

Fault code	Cause	DIN short description
F15	Maximum forward and/or reverse transmission ratio not achieved. Remedy: Repeat calibration (see also F2). Then check hydraulic power distribution system if necessary, e.g. using emergency operation.	
F50	User interrupted with "ESC"	
F51	Speed above 0,1 km/h	
F52	Engine speed below 1400 rpm	
F53	Handbrake not applied	
F54	Faulty speed signal from <b>B015</b> bevel pinion sensor	
F55	Faulty speed signal from <b>B015</b> bevel pinion sensor	
F56	Faulty speed signal from engine	
F57	Clutch pedal depressed	
F58	- <b>B017</b> clutch pedal sensor faulty	
F59	Travel range I button was actuated	
F60	Travel range I button faulty	
F61	Travel range II button was actuated	
F62	Travel range II button faulty	
F63	Range control I/II is not in neutral - Range selector in neutral (normal after calibration of the travel range selector (code 4003)) - Manually set the transmission to neutral via the emergency operation if necessary	
F64	Electrical fault in <b>Y005</b> speed governor solenoid valve	

Fault code	Cause	DIN short description
F05	Engine speed too low when starting calibration Nominal engine speed = 1100 +/- 40 rpm	
F06	Engine speed too low during calibration Nominal engine speed = 1100 +/- 400 rpm	
F07	Faulty speed signal from engine	
F08	Driving range II not engaged	
F09	- <b>B016</b> travel range detection sensor faulty	
F10	Transmission not in neutral	
F11	Neutral button faulty ( <b>A100</b> MFA, multifunction armrest)	
F12	Clutch pedal depressed	
F13	- <b>B017</b> clutch pedal sensor faulty	
F14	Transmission pressure too high when starting calibration (above 100 [bar])	
F15	Transmission pressure too high when starting calibration (above 200 [bar])	
F16	- <b>B008</b> high-pressure sensor 1 faulty	
F17	- <b>S015</b> hand brake switch faulty	
F18	Handbrake not applied	
F19	Fault in <b>A009</b> actuator unit	
F20	Fault in <b>Y004</b> clutch/turbo-clutch solenoid valve	
F21	Plausibility error: Power consumption of <b>Y004</b> clutch/turbo-clutch solenoid valve to transmission high pressure illogical	
F22	Error in transmission ratio	
F23	Plausibility error: Power consumption on <b>Y004</b> clutch/turbo-clutch solenoid valve illogical (e.g. short circuit in Y004 solenoid valve)	



Fault code	Cause	DIN short description
F01	Preliminary conditions for calibration not satisfied	<b>A050</b> basic control unit ECU <b>A100</b> MFA, multifunction arrest
F02	Calibrated values are invalid	
F03	<b>A100</b> MFA, multifunction arrest not responding	
F08	Calibration takes too long (more than 60 seconds)	
F09	User terminated calibration with "ESC"	

**Fault code for calibration code 8001**

Fault code	Cause	DIN short description
F01	User terminated calibration with ESC	<b>A050</b> basic control unit ECU <b>B003</b> front-axle suspension position sensor
F02	Raising the suspension takes too long (longer than 40 seconds)	
F03	Lowering the suspension takes too long (longer than 40 seconds)	
F04	Calibrated min. and max. values are too close together	
F05	Internal error in the <b>A050</b> basic control unit ECU Error while saving calibrated values to EEPROM (EOL reprogramming may be necessary)	
F06	Engine speed too low	
F07	Road speed too high (greater than 0,1 km/h)	

**Fault code for calibration code 7666**

Fault code	Cause	DIN short description
F02	Calibrated value of the current actuator position is invalid	<b>A050</b> basic control unit ECU <b>A100</b> MFA, multifunction arrest
F03	<b>A100</b> MFA, multifunction arrest not responding	
F08	Calibration taking too long (more than 30 seconds)	
F09	User terminated calibration with ESC	

**Fault code for calibration code 4010**



Fault code	Cause	DIN short description
F01	User terminated calibration with "ESC"	<b>A139</b> - Cargo Profi ECU
F02	Calibration taking too long (more than 30 seconds)	<b>B214</b> tipping cylinder (length measurement) sensor
F15	<b>B214</b> tipping cylinder sensor is faulty - Break in the wiring - Short circuit to earth	
F16	Road speed is too high	
F17	Front loader fork is too high/low (the quick-change frame cannot move fully through the working range) Raise the front loader fork at least 30 percent	
F32	Incorrect values were found during calibration (Calibration is not valid)	
F33	No calibration of the front loader fork (Calibration 8020)	

**Fault code for calibration code 8021**

Fault code	Cause	DIN short description
F01	User terminated calibration with "ESC"	<b>A139</b> - Cargo Profi ECU
F02	Calibration taking too long (more than 30 seconds)	<b>B212</b> rotation angle sensor of the front loader jib
F15	Sensor fault: <b>B212</b> rotation angle sensor of the front loader jib	
F16	Road speed is too high	
F32	Incorrect values were found during calibration (Calibration is not valid)	

**Fault code for calibration code 8020**

Fault code	Cause	DIN short description
F01	User terminated calibration with "ESC"	<b>Front loader hysteresis</b> <b>A139</b> - Cargo Profi ECU
F03	- Release crossgate lever - Release 4th circuit button	<b>B210</b> raise lift cylinder sensor <b>B211</b> sensor, lower lift cylinder
F15	<b>B212</b> tilt sensor is faulty - Break in the wiring - Short circuit to earth	<b>B212</b> front loader fork sensor
F16	Road speed is too high	
F18	Tippling cylinder could not be fully retracted by quick-change frame (no more than 95 percent)	
F32	Incorrect values were found during calibration (Calibration is not valid)	
F33	No calibration 8020 (front loader fork)	
F34	No calibration 8021 (tip cylinder for quick-change frame)	
F35	No calibration 8022 (tilt)	
F37	Unknown front loader type	

**Fault code for calibration code 8023**

Fault code	Cause	DIN short description
F01	User terminated calibration with "ESC"	<b>A139</b> - Cargo Profi ECU
F02	Calibration taking too long (more than 30 seconds)	<b>B213</b> tilt sensor on coupling arm "pendulum"
F15	<b>B213</b> tilt sensor is faulty - Break in the wiring - Short circuit to earth	
F16	Road speed is too high	
F32	Incorrect values were found during calibration (Calibration is not valid)	

**Fault code for calibration code 8022**



Fault code	Cause	DIN short description
F01	Calibration not permitted (engine speed too low or faulty)	A050 basic control unit ECU
F02	Calibration takes too long (more than 60 seconds)	
F03	Electrical fault on M049 heater valve	

#### Fault code for calibration of heater valve

Fault code	Cause	DIN short description
F01	Calculated tire circumference is too small	A050 basic control unit ECU
F02	Calculated tire circumference is too large	
F03	Calculated impulse total per meter of traveling distance too small for radar sensor	
F04	Calculated impulse total per meter of traveling distance too large for radar sensor	
F06	Internal error in the A050 basic control unit ECU: Error while saving calibrated values to EEPROM (EOL reprogramming may be necessary)	

#### Fault code for calibration of tire circumference

Fault code	Cause	DIN short description
F01	Calibrated values are invalid or incorrect	A050 basic control unit ECU
F02	Resistance value is incorrect, Linkage may not be in the lower end position (Release control only)	B040 front power lift position sensor
	Y172 release control solenoid valve with incorrect electrical connection	

#### Fault code for calibration code 9002

Fault code	Cause	DIN short description
F01	Preliminary conditions for calibration not satisfied	A050 basic control unit ECU
F02	Calibrated values are invalid	A100 MFA, multifunction armrest
F03	A100 MFA, multifunction armrest not responding	
F08	Calibration taking too long (more than 30 seconds)	
F09	User terminated calibration with "ESC"	

#### Fault code for calibration code 9001





## 3. Operation

<b>3.1 Operating controls</b>	3-3
3.1.1 Instrument panel	3-3
3.1.2 Operating status display	3-4
3.1.3 Multiple display	3-5
3.1.4 Control panel	3-7
3.1.5 Joystick	3-11
<b>3.2 Other operating controls for 700 Vario S4</b>	3-17
3.2.1 Multifunction armrest keypad	3-17
3.2.2 Dashboard	3-18
3.2.3 EPC operating controls	3-19
3.2.4 Safety switch	3-21
3.2.5 Crossgate lever and linear module	3-21
<b>3.3 Terminal</b>	3-23
3.3.1 Terminal overview	3-23
3.3.2 Terminal display	3-24
3.3.3 External control panel	3-25
3.3.4 Page layout and screen allocation	3-26
3.3.5 Menu overview of tractor operation	3-27
3.3.6 Information regarding terminal simulation	3-33
3.3.7 Tasks for terminal settings	3-33





### 3.1 Operating controls

#### 3.1.1 Instrument panel













Fig. 1  
 (A) Operating status display, displays engine and PTO speeds.  
 (B) Multiple display, displays time, operating hours, air conditioning system, warning and fault messages.  
 (C) Operating status display, displays speed information.

Warning light		Warning flasher unit	
Left direction indicator		Right direction indicator	
Forward travel direction		Reverse travel direction	
Direction indicator repeater for 1st trailer		High beam	
Direction indicator repeater for 2nd trailer		Indicator lamp for parking brake	
Charging indicator 1 (right side), alternator not charging		4WD engaged	
Charging indicator 2 (left side), alternator not charging		Differential lock engaged	
Preheater indicator		Cruise control enabled	

- (A) **AdBlue® display (DEF)**  
**NOTE:** DEF = Diesel Exhaust Fluid  
 Gage in red range, low AdBlue® volume. Top up AdBlue®.  
 Gage flashing in red range, AdBlue® volume is very low. Top up AdBlue®.
- (B) **Fuel supply**  
 Display in red zone, fuel supply is low. Fill up with fuel.  
 Display flashes in red zone, fuel supply is very low. Fill up with fuel.
- (C) **Compressed air supply (if present)**  
 Display flashes in red zone, fuel supply is very low. Fill up with fuel.
- (D) **Engine temperature**  
 Display in the green zone, working pressure has been reached.  
 Display flashes in the red zone, working pressure has not yet been reached.
- (E) **Engine speed**  
 When the bar reaches the red zone, relieve the engine load immediately and allow to cool for about 2 minutes at 1000 rpm; then turn the engine off.
- (F) **Fan speed**  
 Time
- (G) **Setpoint temperature**  
 Speed display with radar sensor (option).
- (H) **Rear PTO speed**  
 (K) **Front PTO speed**  
 (L) **No. of operating hours**  
**NOTE:** The default display is the time and the number of operating hours.  
 This is interrupted for warnings, fault messages and on-board computer functions.
- (N) **Outside temperature**  
 (O) **Speed display**  
 (determined from the tire circumference)



3.1.2 Operating status display

	Hydraulic trailer brake		ABS function indicator for trailer
	Red: Brake pressure too low		ABS function indicator (only on the Vario 900 if the tractor is equipped with ABS)
	Yellow: Sensor fault		Fuel supply
	AdBlue® tank contents		Engine temperature

**NOTE:**

For a precise reading, adjust the speed display under operating conditions.

### 3.1.3 Multiple display

#### Control keys for multiple display

- (A) Return to previous menu level.
- (B) Key for browsing through the menu levels and setting functions.
- (C) Key for calling up menu levels and entering settings.




Fig. 3

#### Default display

- (A) Hydraulic oil gage
- (B) Time
- (C) Fan speeds
- (D) Setpoint temperature
- (E) Outside temperature
- (F) Operating hours

**NOTE:**

After approx. 10 seconds, the hydraulic oil gage switches to the air conditioning and ventilation display.




Fig. 4



Press the button to switch between the hydraulic oil gage and the air conditioning and ventilation display.

#### First main menu level



Press key; the following menu appears.



Fault memory



Change menu level



Fig. 5

**Second main menu level**

Use the control keys to select the required menus.

Transmission calibration menu, display (A) appears.



Front PTO calibration menu, display (B) appears.



**NOTE:** Only appears if front PTO is fitted.



Front power lift calibration menu, display (C) appears.

**NOTE:**

Only displayed if comfort front power lift control is fitted



Front axle suspension calibration menu, display (D) appears.



Rear PTO calibration menu, display (E) appears.

appears.



EPC calibration menu, display (F) appears.



Hydraulic system calibration menu, display (G) appears.



Steering calibration menu, display (H) appears.

appears.



Heating valve and windscreen wiper calibration menu, display (J) flashes.

**NOTE:**

Calibration runs automatically.

**Transmission calibration menu**

Use the control keys (see image) to select the required menus.



Transmission calibration, display (A) appears.



Tire circumference display, display (B) appears.

**NOTE:** Tire circumference specified by default. Tire circumference can be changed manually. When the speed displays are calibrated, the tire circumference is stored automatically.

Fig. 7







Fig. 6




 Calibrate tire circumference/radar sensor, display (C) appears

**NOTE:**  
 Possible adjustment range from 30 m to 100 m.


 Change acceleration rate for level I, display (D) appears.


**NOTE:**  
 Possible adjustment range from 0,02 km/h to 0,5 km/h.


 Display (E) appears in emergency operation.

### Rear PTO calibration menu

Use the control keys (see image) to select the required menus.

 Rear PTO calibration, display (A) appears.

 Choose default settings for the switch-on point for automatic mode, display (B) appears.

 Change switch-on point for automatic mode, display (C) appears.

### 3.1.4 Control panel

#### Control panel for 200 Vario Standard S3

- (1) Keypad on the multifunction center
- (2) Joystick
- (3) EPC controls
- (4) Arrest for electric control valves (optional)
- (5) Sockets and switches
- (6) Rotary control for EPC
- (7) Automatic air-conditioning system (optional)
- (8) Trailer hitch remote control




Fig. 9



Fig. 8

**Control panel for 200 Vario V/F/P S3**

Vario joystick version without crossgate lever

- (A) Linear modules for operating hydraulic valves
- (B) EPC control panel
- (C) PTO operation
- (D) Joystick
- (E) Under the armrest, hydraulic setting functions




Fig. 10

Vario joystick version with crossgate lever

- (A) Linear modules for operating hydraulic valves
- (B) EPC control panel
- (C) PTO operation
- (D) Joystick
- (E) Crossgate lever
- (F) Under the armrest, hydraulic setting functions




Fig. 11

Professional joystick version

- (A) Linear modules for operating hydraulic valves
- (B) EPC control panel
- (C) Mini hydraulics — optional V, F
- (D) PTO operation
- (E) Joystick
- (F) Tilt angle mark (three-point linkage)
- (G) Under the armrest, hydraulic setting functions
- (H) Crossgate lever




Fig. 12

**Control panel for 300 Vario S4**

Power version

- (A) Joystick
- (B) EPC controls
- (C) EPC and PTO control unit
- (D) Throttle pedal resolution
- (E) Keypad on the multifunction center
- (F) Hand throttle




Fig. 13

Profi and ProfiPlus version

- (A) Joystick
- (B) Crossgate lever
- (C) EPC and PTO control unit
- (D) Throttle pedal resolution
- (E) Keypad on the multifunction center
- (F) Hand throttle
- (G) Vario terminal




Fig. 14

**Control panel for 500 – 700 Vario S4**

Power and PowerPlus version

- (A) Joystick
- (B) Crossgate lever
- (C) EPC and PTO control unit
- (D) Throttle pedal resolution
- (E) Multifunction armrest keypad
- (F) Storage compartment
- (G) Hand throttle
- (H) Vario terminal



Fig. 15

- Profi (10.4" terminal optional) and ProfiPlus version
- (A) Joystick
  - (B) Crossgate lever
  - (C) EPC and PTO control unit
  - (D) Throttle pedal resolution
  - (E) Multifunction armrest keypad
  - (F) Oddments tray and electric mirror adjustment
  - (G) Hand throttle
  - (H) Linear modules for operating hydraulic valves.
  - (J) Vario terminal




Fig. 16

**Control panel for 800 – 900 Vario S4**  
Power and PowerPlus version

- (A) Joystick
- (C) EPC and PTO control unit
- (D) Throttle pedal resolution
- (E) Multifunction armrest keypad
- (F) Oddments tray and electric mirror adjustment
- (G) Hand throttle
- (H) Linear modules for operating hydraulic valves.
- (J) Vario terminal



Fig. 17

Profi (10.4" terminal optional) and ProfiPlus version

- (A) Joystick
- (B) Crossgate lever
- (C) Vario terminal
- (D) EPC and PTO control unit
- (E) Holder for mobile phone
- (F) Throttle pedal resolution
- (G) Multifunction armrest keypad
- (H) Linear modules for operating hydraulic valves.
- (I) Oddments tray and electric mirror adjustment
- (J) Hand throttle




Fig. 18



**Control panel for 1000 Vario S4**  
PowerPlus version

- (A) Joystick
- (B) Vario terminal
- (C) EPC and PTO control unit
- (D) Throttle pedal resolution
- (E) Multifunction armrest keypad
- (F) Linear modules for operating hydraulic valves.
- (G) Oddments tray and electric mirror adjustment
- (H) Hand throttle




Fig. 19

Profi (10,4" terminal optional) and ProfiPlus version

- (A) Joystick
- (B) Crossgate lever
- (C) Vario terminal
- (D) EPC and PTO control unit
- (E) Holder for mobile phone
- (F) Throttle pedal resolution
- (G) Multifunction armrest keypad
- (H) Linear modules for operating hydraulic valves.
- (I) Oddments tray and electric mirror adjustment
- (J) Hand throttle




Fig. 20

**3.1.5 Joystick**

**Joystick for 200 Vario Standard S3**

- (1) Transmission ratio change




Fig. 21

- (2) Activation button
- (3) Cruise control
- (4) Acceleration behaviour (LED lights up in phase I).

**NOTE:**

If the vehicle is at a standstill, a change in transmission ratio or travel direction is only carried out if the activation key is pressed.

**Joystick for 200 Vario V/F/P S3, Vario joystick version**




Fig. 22

**NOTE:**  
If the vehicle is at a standstill, a change in transmission ratio or travel direction is only carried out if the activation key is pressed.

- (A) Change of forward transmission ratio
- (B) Change of reverse transmission ratio
- (C) Change of travel direction
- (D) Cruise control ON
- (E) Activation button

**Additional functions: Hydraulic circuits 3 and 4.**  
Additional third and fourth hydraulic circuit functions of implementations can be operated electronically (e.g. stock collectors, front loader etc.). The third and fourth hydraulic circuits can be operated using the buttons on the crossgate lever or the two buttons on the joystick. The button/switching behavior for the buttons can be configured.

- Switch 3rd hydraulic circuit on and off with button (A).
- Switch 4th hydraulic circuit on and off with button (B).

**NOTE:**  
If the LED in the button is lit, the corresponding connecting box is energized.




Fig. 23 Vario joystick version without crossgate lever

**Actuate valves on joystick**





Fig. 24

**NOTE:**  
If the vehicle is at a standstill, a change in transmission ratio or travel direction is only carried out if the activation key is pressed.

- (A) Change of forward transmission ratio
- (B) Change of reverse transmission ratio
- (C) Change of travel direction
- (D) Cruise control ON
- (E) Activation button

**Joystick for 200 Vario V/F/P S3, Profi joystick version**

- (A) = raise
- (B) = Lower/press
- (C) = floating position



Control options with the joystick





Fig. 26

**NOTE:**

The rotary control (see arrow) can be used to change operation at the joystick.

(A)	(B)	(C)	(D)
Position 1 Green (valve 4) Yellow (valve 1) Blue (valve 2) Rear linkage:	Position 2 Red (valve 3) Yellow (valve 1) Blue (valve 2) Rear linkage:	Position 3 Blue (valve 2) Red (valve 3) Green (valve 4) Rear linkage:	Position 4 Green (valve 4) Yellow (valve 1) Blue (valve 2) Red (valve 3)

4-valve version (4+0)

(A)	(B)	(C)	(D)
Position 1 Brown (valve 5) Yellow (valve 1) Blue (valve 2) Rear linkage:	Position 2 Red (valve 3) Yellow (valve 1) Blue (valve 2) Rear linkage:	Position 3 Brown (valve 5) Red (valve 3) Green (valve 4) Rear linkage:	Position 4 Brown (valve 5) Yellow (valve 1) Blue (valve 2) Red (valve 3)

4-valve (3+1)/5-valve (4+1) version




Fig. 28

**Joystick for 800 – 900 Vario S4 Power and PowerPlus**

- (A) Activate cruise control 1
- (B) Activate cruise control 2
- (C) Activate min. engine speed
- (D) Activate max. engine speed
- (E) Select acceleration rate
- (F) Activation button




Fig. 27

**Joystick for 300 Power and 1000 Vario S4 PowerPlus**

- (A) STOP
- (B) Disengage PTO
- Rear PTO automatic mode: Linkage remains stationary
- Rear PTO automatic mode: Rear PTO automatic mode
- (C) GO
- Rear power lift automatic mode: "Raise" function
- Rear power lift automatic mode: "Control" function
- Rear PTO automatic mode: Rear PTO automatic mode
- (D) Activate engine speed
- (E) Activate/switch cruise control
- (F) Activation button
- (G) Select acceleration rate

5-valve version (3+2), 6 valves (4+2)

(A)	(B)	(C)	(D)
Position 1	White (valve 6)	Yellow (valve 1)	Blue (valve 2)
Position 2	Red (valve 3)	Yellow (valve 1)	Blue (valve 2)
Position 3	Brown (valve 5)	Yellow (valve 1)	Blue (valve 2)
Position 4	White (valve 6)	Yellow (valve 1)	Blue (valve 2)
			Red (valve 3)
			Red (valve 3)
			Rear linkage.
			Rear linkage.

**Joystick for 300 – 1000 S4**

**Version 300 Vario S4 Profi and ProfiPlus, all versions 500 – 700 Vario S4, 800 – 900 Vario S4 Profi and ProfiPlus, 1000 Vario S4 Profi and ProfiPlus**

- (A) GO 1
- VarioTronic TI:
- Start/end sequence GO 1
- Rear power lift automatic mode:
- "Control" function
- Rear PTO automatic mode:
- Engage rear PTO
- (B) Floating position; red valve
- (C) GO 2
- VarioTronic TI:
- Start/end sequence GO 2
- Front power lift automatic mode:
- "Control" function
- Rear PTO automatic mode:
- Activate front PTO
- (D) Raise/lower red valve
- (E) END 1
- VarioTronic TI:
- Start/end sequence END 1
- Rear power lift automatic mode:
- "Raise" function
- Rear PTO automatic mode:
- Disengage rear PTO
- (F) Activate cruise control 2
- (G) Activate max. engine speed

**NOTE:**

The button assignment shown is only applicable for the Fendt settings.





Fig. 29

- (H) Activate min. engine speed
- (I) Select acceleration rate
- (J) Activate cruise control 1
- (K) Raise/lower green valve
- (L) END 2
- (M) VarioTronic TI:
- Start/end sequence END 2
- Front power lift automatic mode: "Raise" function
- Rear PTO automatic mode: Disengage front PTO
- (N) Floating position; green valve STOP
- Front/rear power lift automatic mode: Linkage remains stationary
- Front/rear PTO automatic mode: Disengage PTOs
- (O) Activation button

Fig. 30



### 3.2 Other operating controls for 700 Vario S4

#### 3.2.1 Multifunction armrest keypad




Fig. 31

- |     |  |
|-----|--|
| (A) | Travel speed range I                     |
| (B) | Travel speed range II                    |
| (C) | Throttle pedal mode ON - OFF             |
| (D) | Tractor Management System (TMS) ON - OFF |
| (E) | -  |
| (F) | Transmission neutral ON - OFF            |
| (G) | Lock for hydraulic valves ON - OFF       |
| (H) | VarioTronic TeachIn ON - OFF             |
| (J) | VarioGuide ON - OFF                      |
| (K) | VarioGuide standby mode ON - OFF         |
| (L) | Automatic front linkage mode ON - OFF    |
| (M) | Automatic rear linkage mode ON - OFF     |
- 
- |     |   |
|-----|---|
| (N) | Automatic 4WD mode ON - OFF               |
| (O) | Permanent 4WD (100%) ON - OFF             |
| (P) | Automatic differential lock mode ON - OFF |
| (Q) | Differential lock 100% ON - OFF           |
| (R) | Front axle suspension mode                |
| (S) | Front axle lock mode                      |
| (T) | Rear PTO speed selection level 540        |
| (U) | Rear PTO speed selection level 540E       |
| (V) | Rear PTO speed selection level 1000       |
| (W) | Rear PTO speed selection level 1000E      |
| (X) | Automatic front PTO mode ON - OFF         |
| (Y) | Automatic rear PTO mode ON - OFF          |

**NOTE:**

If the LED next to the pressed button is lit, the required function is activated.


**NOTE:**  
 The required function is activated if the LED next to the button lights up.  
 When the preheat and starter switch is set to "1" (engine off), the relevant LED flashes when a work light is switched on. Press the button again to switch the work light on.  
 If the headlight was switched on for longer than two minutes while the engine was running, the additional headlights (E) and/or the front headlights (F) (where there is no front power lift) will be switched on for at least one minute when the doors are opened.

- (N) Control keys for multiple display
  - (M) Tool lock
  - (L) vibration damping system
  - (K) Activate shock load stabilizing system, not functioning
  - (J) Hydraulic trailer brake pressure release
- it is shorter than the default interval, second time is adopted as the new interval if of time before it is switched on for the and off, and then on and off again. The period windshield wiper intermittent operation on The length of an interval can be set. Switch*

- NOTE:**  
 The rear windshield heater must be activated. The rear view mirror heater automatically switches on at temperatures below +12 °C and remains switched on until the tractor is restarted  
 Rear windshield washer system (wipers run automatically)  
 Rear windshield wiper intermittent operation ON - OFF
- (I) Rear windshield wiper intermittent
  - (H) Rear windshield washer system (wipers run automatically)

- (A) Hazard warning light ON - OFF
- (B) Rotating beacon ON - OFF
- (C) Main switch for work lights ON - OFF (The work lights that were last switched on can be switched on and off together)
- (D) Work lights ON - OFF
- (E) Additional headlight (standard with front power lift)
- (F) Headlights and marker lights ON - OFF (When the preheat and starter switch is set to "0", only the marker lights [parking lights] are switched on)
- (G) Rear windshield heater and rear view mirror heater with automatic shut-off function ON - OFF

Fig. 32



**3.2.2 Dashboard**



### 3.2.3 EPC operating controls

#### Control panel

- (A) Quick lift switch, quick entry
- (B) Depth control
- (C) STOP button: All EPC functions are terminated.




Fig. 33

#### Quick lift switch

- (A) Lower – implement is set to the value selected by the depth control.
- (B) Quick entry

#### NOTE:

If the quick-lift switch is actuated, the value set for depth control is not reached. When the switch is released, it returns to the set value.

- (C) Raise – implement is moved to the value selected by the lift height limit




Fig. 34

#### Depth control

The depth control (A) can be used for precise setting of the linkage working depth.

#### SA/DA function Floating position for rear power lifts with

The DA function must be switched off for the floating position. If the lower end position is not reached when lowering, i.e. the mounted implement is resting on the ground, the floating position is activated. The lower end position is set with depth control.

#### DA function Floating position for rear power lifts without

If a value greater than 9.5 is set during depth control, the floating position of the rear power lift is activated as soon as the mounted implement is resting on the ground.

#### Direction of rotation for depth control

Rotational direction right = raise linkage



Fig. 35

**NOTE:**  
 When using external controls, the hydraulic lower linkage lock is always set to manual lock (safety). The implement is centered. After unlocking the power lift, it remains on manual lock.

**NOTE:**  
 External operation is possible at any position of the depth control. External operation has priority over other operating controls. After external operation, the rear power lift is locked.

Pressure switch (A) to the left or right of the rear lamp for raising or lowering the linkage.

**External rear controls**




Fig. 38

If the floating position of the rear power lift is active, the symbol for floating position (A) appears on the Varioterminal in the tractor information display next to the rear power lift symbol.




Fig. 37

Rotational direction left = lower linkage  
 If the depth control is used to set the linkage floating position, then the symbol for the floating position appears in the status line in the Varioterminal next to the rear power lift symbol.




Fig. 36

### 3.2.4 Safety switch



**DANGER:**

Press the STOP key (C) to stop undesired movements of the power lift.

- STOP button (C)

When the safety lock is activated, the power lift does not work, i.e. after pressing the STOP key, the rear power lift is shifted into Stop mode. The



Stop symbol is displayed on the terminal next to the rear power lift status indicator.

#### The safety lock becomes active in any of the following situations:

1. When the ignition is switched off and on.
2. When starting the tractor.
3. If there is a fault in the electrical circuit.
4. By connecting or disconnecting an external sensor.

Stop mode can be suspended by actuating the quick-lift switch for the rear power lift.

### 3.2.5 Crossgate lever and linear module

#### Crossgate lever


#### Operating the valves with the crossgate lever

- (A) Raise
- (B) Lowering/pressure
- (C) Floating position

Fig. 40



Fig. 39



**Use of the 3rd or 4th hydraulic circuit**  
Use buttons (A) on crossgate lever to operate the 3rd or 4th hydraulic circuit.



Fig. 41

**Linear module**  
**Operate the valves with the linear module**

- (A) Raise
- (B) Lowering/pressure
- (C) Floating position




Fig. 42

### 3.3 Terminal

#### 3.3.1 Terminal overview

##### Brief overview of the two terminals

Hardware		7-inch Vario terminal	10.4-inch Vario terminal
Screen diagonals	7 inches	10.4 inches	
Resolution	480 x 800	800 x 600	
Number of colors	262,000	16 million	
Ports	USB, Ethernet	USB, Bluetooth, Ethernet, 2x camera	
Anti-reflective coating	+	+	
Touch screen	+	+	
External control panel	+	+	
Internal memory	1 GB	4 GB	
<b>Applications</b>			
Tractor operation	+	+	
VarioGuide	-	+	
VarioGuide light	+	-	
VarioDoc	-	+	
ISOBUS implement control	+	+	
VarioTronic TI	+	+	
Management of implement settings	+	+	
2 cameras	-	+	
Map display	+	+	
4 info screens	-	+	

**NOTE:**

In this Operator's Manual, operation of the tractor is displayed on the large Vario terminal as standard; differences are pointed out as necessary.

### 3.3.2 Terminal display

#### 10.4-inch Vario terminal display

(A) Touch screen  
 (B) External control panel

It is possible to operate the 10.4-inch Vario terminal with the touch screen (A) or with the aid of the external control panel (B).

**NOTE:**

Not all functions are available using the touch screen. Some functions can only be activated using the external control panel.

Pull flap (A) open to reveal the USB ports.

**NOTE:**

USB ports are only provided for maintenance purposes in the authorized dealer workshop or for when required, e.g. for a mobile phone charging cable.

#### 7-inch Vario terminal display

(A) Touch screen  
 (B) External control panel

It is possible to operate the 7-inch Vario terminal with the touch screen (A) or with the aid of the external control panel (B).

**NOTE:**

Not all functions are available using the touch screen. Some functions can only be activated using the external control panel.

Fig. 44




Fig. 43






Fig. 45



Key	Function
A	Help
B	ESC
C	Rotary wheel
D	Positioning
	7" terminal: Selection menu applications
	10.4" terminal: Positioning of applications on the screen
	Confirmation (equivalent to the OK button in the middle of the navigation keys) by pressing the wheel
	(Dynamic) setting of numbers or selection from lists by turning the wheel
	Jump to the first level if the key is kept pressed (more than 2 s)
	Jump up one menu level
	Call up the digital Operator's Manual on the terminal

**Key functions**



- (A) Help key
- (B) ESC key
- (C) Rotary wheel
- (D) 10.4" terminal: Key positioning
- (E) 7" terminal: Selection menu applications
- (F) Home key
- (F) Navigation keys (left - right / up - down) for cursor operation
- (G) Confirmation key (press rotary wheel to the left)

Keys on the external control panel

**3.3.3 External control panel**



**NOTE:**  
 USB ports are only provided for maintenance purposes in the authorized dealer workshop or for when required, e.g. for a mobile phone charging cable.

On the 7-inch Vario terminal, the flap (A) for the USB ports must be pushed first to unlock it. The flap will then open automatically. Misuse may cause damage to the opening mechanism.



Fig. 49

The screen is subdivided into 4 equal sections:  
 In the adjoining example, the camera view can be seen in the top left area of the display.  
 The tractor information screen is in the top right. The two sections in the bottom left and bottom right are occupied by the map view.

**NOTE:**

Occupation of the screen areas with the various applications is described in the chapter Screen allocation.



Fig. 48

The screen is divided into 3 sections:  
 In the example opposite, the tractor information screen can be seen in the top half.  
 The valve information screen can be seen in the bottom half.  
 The status bar is located at the very bottom.

**NOTE:**

Occupation of the screen areas with the various applications is described in the chapter Screen allocation.

**NOTE:**

In this Operator's Manual, operation of the tractor is displayed on the large Vario terminal as standard; differences are pointed out as necessary.

**3.3.4 Page layout and screen allocation**

Key	Function
E	Home
F	Cursor keys
G	Confirmation
	Key for confirmation of input
	Terminal operation by moving the focus frame
	The tractor information screen is always shown in the top right quarter when the Home key is pressed. The current applications are retained in the other quarters and set to their starting condition (retracted)



### 10.4-inch terminal screen allocation

When the "positioning view" is shown by actuating the appropriate key provided on the external control panel, symbols are displayed on each of the four screen sections for the application groups that can be displayed there.

Soft keys for application groups:

- (A) Tractor applications (tractor functions, VarioGuide functions, VarioDoc functions and setup functions)

- (B) Interactive map displays (always placed in the top right)

- (C) Info+ (pre-configured screens with important information)
- (D) ISOBUS implement applications
- (E) Camera applications

Additional soft keys

- (F) Confirmation of selection and leave the page
- (G) Leave the page without accepting the selection
- (H) Switch between day/night mode

### 3.3.5 Menu overview of tractor operation

Call up the tractor main page








Fig. 50








Call up rear power lift




Call up workshop mode




Call up front power lift




Call up workshop mode




Call up rear power lift details




Call up rear EHS valves






Call up front EHS valves




Call up further hydraulic functions




Call up other elements assignment


Go to - Engine and transmission




Call up TMS




Call up TMS (with reversible fan) (models 800, 900)






Call up Variontronic TI



Call up diesel particle filter



Call up consumption measurement



1. Select the save devices menu
2. Save the data under your name

### Save settings under a device name

1. Select the TeachIn menu and set the following values for the "GO 1" button
  - Lower the front power lift
  - Maximum speed memory on when front power lift position above 50 percent
  - Lower rear power lift by 4 m during forward travel
  - Rear PTO on when rear power lift position above 50 percent
  - DA yellow on when time over 0.2 s
  - Forward cruise control C1 to 3 m
2. An error occurs when you are entering the values:
  - Lower the front power lift
  - Configure the maximum speed memory according to the rear PTO position, depending on the rear power lift position
  - Configure the DA yellow according to the front power lift position
3. At button "END 1"
  - Disengage cruise control
  - Raise front power lift by pressing a button
  - Raise rear power lift by 4 m during forward travel
  - Rear PTO off when rear power lift position above 40 percent
  - MIN speed memory on over 2 s
  - DA yellow off when time over 1 s
  - DA blue on when time over 2 s

### "TeachIn" setting, headland management

1. Select the front power lift menu and enter the following values:
  - Lifting height: 90 percent
  - Lifting speed: 80 percent
  - Lowering speed: 60 percent
2. Select the rear power lift menu and enter the following values:
  - Lifting height: 90 percent
  - Lifting speed: 80 percent
  - Lowering speed: 60 percent
3. Select the control units menu and enter the following values:
  - DA yellow +80 l, -40 l, time 15 s activated, priority
  - DA blue +50 l, -50 l, time 10 s activated
  - DA red external
  - Actuation of DA yellow on olive finger tip
  - Actuation of DA blue on gray finger tip

### Basic settings for the hydraulic system

1. Select the transmission gearbox menu and enter the following values:
  - Cruise control C1 to 7 km/h and C2 to 30 km/h
  - Load limit control to automatic or manual 15%
  - Memo position forward to 19 km/h, reverse to 9 km/h, activated
  - Activate the TMS speed range 900 rpm to 1300 rpm with the control unit
  - Set the consumption display to 0, activate l/ha and adjust the working width to 4 m

### Basic settings for driving







## 4. motor

4.1 Fuel system	4-3
4.1.1 Fuel system	4-3
4.1.2 Diesel high-pressure pump: Bosch CP 4.1	4-5
<b>4.2 Exhaust gas system</b>	<b>4-9</b>
4.2.1 Exhaust after-treatment	4-9
4.2.2 CSF particulate filter (reduction of soot particles)	4-12
4.2.3 SCR catalytic converter	4-13



## 4.1 Fuel system

### 4.1.1 Fuel system




Fig. 1

- |      |  |      |  |
|------|--|------|--|
| (1)  | Fuel tank                                    | (6)  | High-pressure pump                                     |
| (2)  | Thermostatic valve with heater and hand pump | (7)  | Common rail (high-pressure accumulator)                |
| (3)  | Water sedimentor (pre-filter)                | (8)  | High-pressure limiting valve                           |
| (4)  | Fuel pump                                    | (9)  | Fuel cooler (only from a construction date of 02/2017) |
| (5)  | Main fuel filter                             | Y096 | injector 2   |
| B007 | immersed tube fuel-level sensor              | Y097 | injector 3   |
| B086 | rail pressure sensor                         | Y098 | injector 4   |
| B087 | fuel low pressure sensor                     | Y100 | injector 5   |
| B091 | water in fuel sensor                         | Y101 | injector 6   |
| Y091 | fuel dispensing unit                         |      |  |
| Y095 | injector 1                                   |      |  |

Component	Function
<b>B007</b> immersed tube fuel-level sensor	Fuel display on A007 - instrument panel
<b>B086</b> rail pressure sensor and high-pressure limiting valve DBV	<b>B086 rail pressure sensor:</b> Detects actual pressure (approx. 400 bar to 1600 bar in the rail [high-pressure accumulator]) <b>High-pressure limiting valve:</b> Limits the max. pressure (approx. 1800 bar)
<b>B087</b> fuel low pressure sensor	Detects low fuel pressure "primary fuel pressure" (approx. 6 bar)
<b>B091</b> water in fuel sensor	Detects the water level in the water sedimentor.
Thermostatic valve	Directs the fuel from the return into either the tank or back into the feed, depending on the temperature of the fuel.
<b>Y091</b> fuel dispensing unit	Controls the fill quantity of the high-pressure pumps and thus also the pressure in the rail (high-pressure accumulator).
<b>Y095</b> injector 1 <b>(on the flywheel)</b>	Injector
<b>Y096</b> injector 2	
<b>Y097</b> injector 3	
<b>Y098</b> injector 4	
<b>Y100</b> injector 5	
<b>Y101</b> injector 6	

### 4.1.2 Diesel high-pressure pump: Bosch CP 4.1




Fig. 2 Diesel high-pressure pump (Bosch CP 4.1)  
(1) supply pump  
(2) High-pressure pump

(3) Overflow valve (5 bar to 6 bar)  
Y091 Metering unit




Fig. 3 Diesel high-pressure pump (Bosch CP 4.1)

- (1) supply pump
- (2) High-pressure pump
- (2.1) Camshaft
- (2.2) Roller tappets
- (3) Overflow valve (5 bar to 6 bar)
- Y091 Metering unit

EK14471



Fig. 5 fuel delivery pump




Fig. 4 High-pressure pump and camshaft

(2) High-pressure pump  
(2.1) Camshaft  
(2.2) Roller tappets





Fig. 6 Fuel pump  
(1) supply pump  
IN Vacuum side

OUT Pressure side



The feed pump gears have assembly markings.

**NOTE:**

- (1) supply pump
- (1.1) Pressure relief valve approx. 12 bar
- (1.2) Overflow valve
- IN Vacuum side
- OUT Pressure side

## 4.2 Exhaust gas system

### 4.2.1 Exhaust after-treatment




Fig. 7 Deutz TTCD 6.1, charge air and exhaust gas after-treatment

- A082** nitrogen oxide NOx sensor 1, upstream of SCR
- A083** nitrogen oxide NOx sensor 2, downstream of SCR
- A133** - air intake throttle ECU
- A134** - exhaust gas recirculation ECU
- B192** CSF differential pressure sensor
- AGReX** External exhaust gas recirculation turbocharger
- ATL HD** High-pressure exhaust gas turbocharger
- ATL ND** Low-pressure exhaust gas turbocharger
- A082** nitrogen oxide NOx sensor 1, upstream of SCR
- A083** nitrogen oxide NOx sensor 2, downstream of SCR
- A133** - air intake throttle ECU
- A134** - exhaust gas recirculation ECU
- B192** CSF differential pressure sensor
- AGReX** External exhaust gas recirculation turbocharger
- ATL HD** High-pressure exhaust gas turbocharger
- ATL ND** Low-pressure exhaust gas turbocharger
- Y120** AdBlue metering valve
- WTL** Water-cooled intercooler
- SCR cat** SCR catalytic converter
- M054** - cooling water pump
- LLK** Intercooler
- CSF-PDF** CSF diesel particulate filter
- B218** - venturi differential pressure sensor
- B217** - temperature downstream of venturi sensor
- B193** - exhaust temperature upstream of CSF sensor

Exhaust after-treatment	
Item	Function
Two-stage Charging	<p>Two-stage intake boosting involves two turbochargers of different sizes connected in series with a bypass control (wastegate) and two intercoolers. The first turbocharger (ATL ND) is designed to be the low-pressure turbocharger, the second turbocharger (ATL HD) is designed to be the high-pressure turbocharger. First, the fresh air is pressurized in the low-pressure stage. This involves the relatively small high-pressure compressor operating at a higher pressure level with a low volume flow so that it can deliver the required air mass flow.</p> <p>Two-stage charging can achieve a particularly good level of compressor efficiency. At low engine speeds, the wastegate valve (A136) is closed so that both turbochargers operate. This results in a very fast and high build-up of boost pressure. If the engine speed increases, the wastegate valve opens until only the low-pressure compressor is still operating. The charging then seamlessly adjusts to meet the engine requirements.</p>
AGReX	<p><b>A134 AGReX exhaust gas recirculation for reducing NOx</b></p> <p>At low engine power -&gt; no exhaust gas recirculation</p> <p>At high engine power -&gt; exhaust gas recirculation -&gt; reduction in burning speed in the combustion chamber -&gt; low combustion temperature -&gt; reduction in NOx</p>

Exhaust after-treatment	
Item	Function
DPF-CSF	<p><b>CSF diesel particulate filter: Unburned hydrocarbons (HC) are reduced and particles (PM) are filtered from the exhaust gas and burned.</b></p> <p>CSF particulate filter:</p> <ul style="list-style-type: none"> <li>• Closed particulate filter with ceramic substrate.</li> <li>• Substrate with catalytic coating to reduce the soot combustion temperature.</li> <li>• Monitoring of the CSF particulate filter soot load and ash load through "extrapolation" load model:</li> </ul> <ul style="list-style-type: none"> <li>- A099 - engine control unit and (fuel injection volume, B086 rail pressure)</li> <li>- B192 - differential pressure sensor on CSF particulate filter</li> <li>- B193 - exhaust gas temperature upstream of CSF particulate filter</li> <li>- B105 - exhaust gas temperature upstream of SCR catalytic converter</li> <li>- B191 - exhaust gas pressure upstream of turbocharger</li> <li>- B217/B218 - exhaust gas recirculation</li> </ul> <p>CSF diesel particulate filter with three regeneration stages:</p> <ol style="list-style-type: none"> <li>1. Continuous, independent soot burn-off from an exhaust gas temperature of approx. 250 °C.</li> <li>2. Support under extreme partial load through automatic "heat mode" (via throttle in suction manifold and combustion parameters)</li> <li>3. Filter regeneration is possible in the workshop using the FENDIAS diagnostics program (Serdia) and/or Vario terminal: "active regeneration at a standstill"</li> </ol> <p>Active regeneration</p> <p>The exhaust gas temperature is raised using the throttle (approx. 550 °C). There is also a later diesel injection into the combustion chamber. Unburned diesel passes into the CSF particulate filter, which causes the soot load in the CSF filter to burn off. The high exhaust gas temperature causes urea deposits in the SCR catalytic converter to break down. The active regeneration can cause some unburned fuel to enter the engine oil (approx. 1 percent per active regeneration). After five active regenerations, the engine oil must be changed.</p> <p><b>Recommendation:</b> Perform active regeneration at the 500-hour engine oil change interval before you change the oil.</p> <p>Advantage: The CSF filter and SCR catalytic converter are burned clean and the monitoring electronics for the soot load condition in the CSF filter are reset to the starting condition.</p> <p><b>NOTE:</b> The burn-off of soot in the CSF filter results in ashes. If the ash load in the CSF filter rises to 100 percent, the CSF filter must be replaced with a new CSF filter.</p>
SCR cat	<p><b>SCR catalytic converter for reducing NOx (nitrogen oxides)</b></p> <ul style="list-style-type: none"> <li>• The A099 engine control unit records the fuel injection volume (engine power)</li> <li>• The A082 sensor records the NOx concentration upstream of the catalytic converter</li> <li>• The B194 sensor records the exhaust gas pressure downstream of the DPF</li> <li>• The B105 sensor records the exhaust gas temperature upstream of the catalytic converter</li> </ul> <p>The A099 engine control unit uses these parameters to calculate the AdBlue dosage. The AdBlue is added to the exhaust gas system by means of the Y120 flow valve. The A083 NOx downstream of catalytic converter sensor is used to monitor the functionality of the catalytic converter</p>

The soot deposited in the CSF particulate filter is continuously and independently burned off. This process is known as CRT (continuous regeneration trap). The CRT process is based on the fact that soot with nitrogen dioxide ( $\text{NO}_2$ ) can be burned off at exhaust gas temperatures of 300 °C to 400 °C in the diesel particulate filter (DPF). The procedure is reliable at these temperatures if the  $\text{NO}_2/\text{soot}$  ratio is greater than 8:1. In order to use this procedure, a diesel oxidation catalyst (DOC) that oxidizes NO to form  $\text{NO}_2$  is located upstream of the diesel particulate filter (DPF). This means that the conditions for regeneration as per the CRT procedure are generally provided in normal operation. This method is also called passive regeneration, as the soot is burned off without the need to initiate active measures.

At exhaust gas temperatures above 500 °C, the soot burns off independently in the diesel particulate filter (DPF). Adding  $\text{NO}_2$  through the diesel oxidation catalyst (DOC) is no longer necessary. For exhaust gas temperatures below 250 °C, the diesel oxidation catalyst (DOC) is not yet able to operate. This means that no  $\text{NO}_2$  is produced and therefore no soot is burned off in the diesel particulate filter (DPF). In this case, the A134 throttle in the suction manifold is partially closed and the diesel injection is adjusted. As a result, the exhaust gas temperature increases to above 250 °C and the diesel oxidation catalyst can perform its function. This process is known as "heat mode".

If soot is not burned off completely, the soot load in the diesel particulate filter (DPF) increases. An excessive soot load in the diesel particulate filter can be detected by:


- Calculation by the A099 engine control unit in line with the engine load spectrum.
- The B192 sensor, which records the differential pressure at the diesel particulate filter (DPF).

The A099 engine control unit emits a warning message, which is displayed on the A103 terminal. In this case, active filter regeneration must be performed via the A103 terminal. This active filter regeneration is also known as DPF stationary regeneration.

Recommendation: Perform active filter regeneration in the workshop using a dynamometer, as this then ensures that the exhaust gas temperature rises quickly.

## CSF particulate filter

Fig. 8 CSF (coated soot filter)



## 4.2.2 CSF particulate filter (reduction of soot particles)

4.2.3 SCR catalytic converter




Fig. 9

- (B) Tank ventilation
- (DV) Pressure valve
- (H) Tank heater
- (HF) Main filter
- (P) Pump
- (SI) Suction strainer

Item	Designation	Function
-	AdBlue® container	• AdBlue supply
B102	AdBlue temperature/level sensor "Level sensor"	<ul style="list-style-type: none"> <li>• Determines the AdBlue fill level [l]</li> <li>• Determines the AdBlue temperature [°C]</li> <li>• Tank heater (engine coolant)</li> <li>• Tank ventilation with filter</li> <li>• Intake duct with suction strainer</li> <li>• Return line</li> </ul>
E216	Tube heater	<ul style="list-style-type: none"> <li>• Tube heater on suction line (S)</li> <li>• Tube heater on return pipe (R)</li> </ul>
E217	Tube heater	<ul style="list-style-type: none"> <li>• Tube heater on pressure line (p)</li> </ul>
A084	AdBlue module "Feed module" (Bosch DNOX 2.2)	<ul style="list-style-type: none"> <li>• Suction strainer in intake socket (S)</li> <li>• Temperature sensor (determines the AdBlue temperature)</li> <li>• 4/2-directional valve for emptying the system</li> <li>• Speed-regulated membrane pump (feed volume and pressure)</li> <li>• AdBlue main filter (change interval is 500 running hours)</li> <li>• AdBlue main filter heater</li> <li>• Restrictor with non-return valve (9 bar) in return connection (R)</li> <li>• Pressure sensor 9 bar</li> </ul>
Y120	AdBlue flow valve Y120 - flow valve is cooled:	<ul style="list-style-type: none"> <li>• AdBlue dosing amount (using timed energizing)</li> <li>• Injection volumes depend on engine load (36 to 7200 g/h)</li> </ul>
Y169	AdBlue tank heater solenoid valve	<ul style="list-style-type: none"> <li>• AdBlue injection volume</li> <li>• Coolant for diesel engines</li> </ul>
		<ul style="list-style-type: none"> <li>• Directs coolant to the B102 sensor</li> </ul>

(SV) Suction valve  
(TA) AdBlue tank

(VF) Pre-filter



**Operating conditions of the SCR catalytic convertor**

Conditions	Function	Test
<p>Fill tank with AdBlue</p> <ul style="list-style-type: none"> <li>• Europe: DIN 700 70 (AdBlue)</li> <li>• USA: API certified DEF</li> <li>• Japan: JIS K2247</li> </ul> <p>AdBlue is not a hazardous material and is assigned to the lowest water hazard class</p> <ul style="list-style-type: none"> <li>• Deutz designation: Urea</li> <li>• North American designation: DEF (Diesel Exhaust Fluid)</li> <li>• European designation: AdBlue</li> </ul>	<p>AdBlue is a non-toxic aqueous urea solution that converts nitrogen oxides (NOx) in the emissions to non-hazardous nitrogen (N<sub>2</sub>) and water (H<sub>2</sub>O).</p> <p>To complete the chemical reaction, a catalytic converter temperature of approx. 250 °C is required.</p> <p>The nitrogen oxide (NOx) is reduced by approx. 85% in the catalytic converter.</p>	<p>AdBlue quality can be tested using refractometer X899.980.338.000.</p> <p>32.5% urea</p> <p>67.5% demineralized water</p>
<p><b>Outside temperature below -2 °C</b></p> <p>B076 - sensor (F800/900)</p> <p><b>AdBlue filter heater switches on:</b></p> <p>A084 - AdBlue module</p>	<p><b>Tube heater switches on:</b></p> <p>E216 - AdBlue suction line heater</p> <p>E216 - AdBlue return pipe heater</p> <p>E217 - AdBlue pressure line heater</p>	
<p><b>Outside temperature below 0 °C</b></p> <p>B076 - sensor (F800/900)</p> <p><b>Tube heater switches on:</b></p> <p>E216 - AdBlue suction line heater</p> <p>E216 - AdBlue return pipe heater</p> <p>E217 - AdBlue pressure line heater</p>	<p><b>AdBlue filter heater switches off:</b></p> <p>A084 - AdBlue module</p>	
<p><b>Outside temperature above 0 °C</b></p> <p>B076 - sensor (F800/900)</p> <p><b>Tube heater switches off:</b></p> <p>E216 - AdBlue suction line heater</p> <p>E216 - AdBlue return pipe heater</p> <p>E217 - AdBlue pressure line heater</p>	<p><b>AdBlue filter heater switches off:</b></p> <p>A084 - AdBlue module</p>	
<p><b>Outside temperature above 5 °C</b></p> <p>B076 - sensor (F800/900)</p>	<p><b>Tube heater switches off:</b></p> <p>E216 - AdBlue suction line heater</p> <p>E216 - AdBlue return pipe heater</p> <p>E217 - AdBlue pressure line heater</p>	
<p><b>Coolant temperature above 65 °C</b></p> <p>B089 - sensor</p> <p>and</p> <p><b>Calculated catalytic converter temperature above 150 °C</b></p> <p>B236 sensor</p>	<p>The <b>A082 NOx sensor upstream of the catalytic converter</b> is preheated for approx. 120 seconds and starts detecting NOx values [ppm].</p> <p>The <b>A083 NOx sensor downstream of the catalytic converter</b> is preheated for approx. 120 seconds and starts detecting NOx values [ppm].</p>	<p>FENDIAS- Diagnostics</p> <p>SERDIA Engine diagnostics:</p> <p>SCR overview</p>

Test	Function	Conditions
<p>FENDIAS- Diagnostics SERDIA Engine diagnos- tics: SCR overview</p>	<p>The diaphragm pump in the A084 Adblue module (feed module) is speed-regulated. Pressure in the A084 Adblue module builds up to approx. 9 bar. System is now ready for dispensing</p>	<p>Calculated catalytic converter temperature above 200 °C B236 sensor</p>
<p>FENDIAS- Diagnostics SERDIA engine diagnos- tics SCR overview</p>	<p>The A099 engine control unit is then controlled by a mapping field when regulating  <ul style="list-style-type: none"> <li>• Adblue pressure</li> <li>• Adblue flow rate</li> </ul>                     (adjustable speed of diaphragm pump — A084 Adblue module)  <ul style="list-style-type: none"> <li>• Adblue injection volume</li> </ul>                     (timed energizing of Y120 flow valve)</p>	<p><b>Adblue temperature in tank above -5 °C</b> B102 - "level sensor"</p> <p><b>If the outside temperature is below 0 °C</b> B076 - sensor (F800/900) the</p> <p><b>heating progress of the Adblue™ lines must be OK.</b> E216, E217 - tube heating A084 - Adblue filter heater</p> <p><b>Calculated catalytic converter temperature between 250 °C and 700 °C</b> B236 sensor</p> <p><b>Coolant temperature below approx. 65 °C</b> B089 - sensor =&gt;</p> <p><b>A082 NOX sensor upstream of the catalytic converter not yet detecting NOx values</b></p> <p><b>A083 NOX sensor downstream of the catalytic converter not yet detecting NOx values</b></p> <p><b>A099 engine control unit (F800/900) detects:</b></p> <ul style="list-style-type: none"> <li>• The engine load (calculated)</li> <li>• The catalytic converter temperature (calculated)</li> </ul> <p>Using these values, the A099 engine control unit calculates the optimal Adblue injection volume.</p>

Conditions	Function	Test
<p><b>-5 °C</b>                      B102 fill level sensor</p> <p><b>If the outside temperature is below 0 °C</b>                      B076 - sensor (F800/900)</p> <p>the</p> <p><b>heating progress of the AdBlue™</b>                      E216, E217 - tube heating                      A084 - AdBlue filter heater</p> <p><b>Calculated catalytic converter temperature between 250 °C and 700 °C</b>                      B236 sensor</p> <p><b>Coolant temperature above approx. 65 °C</b>                      B089 - sensor</p> <p>=&gt;</p> <p><b>A082 - sensor NOx upstream of catalytic converter</b>                      determines NOx value in exhaust gas</p> <p><b>A083 - sensor NOx downstream of catalytic converter</b>                      determines NOx value in cleaned exhaust gas</p> <p><b>A099 engine control unit (F800/900) detects:</b></p> <ul style="list-style-type: none"> <li>• The engine load (calculated)</li> <li>• The catalytic converter temperature (calculated)</li> <li>• The proportion of NOx in exhaust gas upstream of the catalytic converter</li> <li>• The proportion of NOx in exhaust gas downstream of the catalytic converter</li> </ul> <p>Using these values, the A099 engine control unit calculates the optimal AdBlue injection volume.</p>	<p>The A099 engine control unit is then controlled by a mapping field when regulating, depending on NOx value (A082 and A083)</p> <ul style="list-style-type: none"> <li>• <b>AdBlue pressure</b></li> <li>• <b>AdBlue flow rate</b></li> </ul> <p>(adjustable speed of diaphragm pump — A084 AdBlue module)</p> <ul style="list-style-type: none"> <li>• <b>AdBlue injection volume</b></li> </ul> <p>(timed energizing of Y120 flow valve)</p>	<p>FENDIAS- Diagnostics</p> <p>SERDIA Engine diagnostics:</p> <p>SCR overview</p>

**General information on AdBlue crystallization**

The formation of deposits in the SCR catalytic converter is a complex mechanism involving the deposit and decomposition of urea and its secondary products. The deposits should reach a balanced state that does not impair the function of the SCR system. Deposits become critical if they have a crucial effect on the

flow and distribution of the AdBlue spray. This may cause the SCR system to tip over, which in turn will cause a considerable amount of deposits to form. The deposits can be removed at temperatures of approx. 350 °C and above. The decrystallization function helps to reduce the amount of deposits in the catalytic converter.





## 5. Vario transmission

5-3	5.1 Function
5-3	5.1.1 Transmission control system functional sequence
5-6	5.1.2 Transmission function diagram
5-11	5.1.3 Transmission diagram ML400
5-13	5.2 Emergency mode
5-13	5.2.1 Driving in emergency mode
5-19	5.2.2 Towing





## 5.1 Function

### 5.1.1 Transmission control system functional sequence

#### Transmission type ML180

M Marschall, designer of this development  
 L Power splitting, mechanical and hydrostatic transmission  
 180 Size of continuously variable transmission

#### ML180 transmission

The ML180 is a continuously variable transmission for forwards and reverse travel. Power transmission can be hydrostatic or mechanical, or hydrostatic and mechanical. The following always applies:

- Slow forward travel: high hydrostatic transmission power/low mechanical transmission power
- Fast forward travel: low hydrostatic transmission power/high mechanical transmission power

For a detailed explanation, see transmission function plan

#### Hydrostatic power splitting

The ML transmission unit is flexibly mounted in the transmission housing. The transmission housing is also the oil reservoir for the hydrostatic drive.

Oil filling: Fendt Extra Trans 10W-40 or STOU oil, viscosity SAE 10W-40 or 15W-40

First filling: approx. 58 l

Refilling: approx. 47 l (when changing oil)

For the functional sequence, see the Transmission gearbox hydraulic circuit diagram

The servo pump draws in oil through the suction filter. The temperature sensor (B009) monitors the temperature of the transmission oil. Flow through the oil cooler is temperature-dependent. This means that if the transmission oil is cold, little oil flows through the oil cooler, while most flows through the bypass valve. The bypass valve opens when the differential pressure exceeds approx. 3,5 bar. The transmission oil temperature is monitored by the temperature sensor.

The servo pump generates the system pressure for the ML control valves and comfort control valves. The system pressure of approx. 18 bar is restricted by the pressure relief valve and restrictor orifice.

#### Two different pressures

1. System pressure for the ML transmission control system and comfort control pressure for the rear PTO clutch, rear PTO shaft control, differential lock and 4WD switchover approx. 18 bar

2. High pressure in ML transmission max. 550 bar + 15 bar

Pressure filter contamination is monitored by a pressure switch (S017) as a function of the transmission oil temperature. Pressure filter contamination is not monitored if the transmission oil temperature is below 50 °C. Two non-return valves (2V1 and 2V2) alternately feed cooled transmission oil into the high-pressure circuit. Hot transmission oil is discharged from the high-pressure circuit via the flushing valve (2V5).

The high pressure circuit comprises:

- Variable displacement pump (2P1)
- Variable displacement motor (2A1)
- Two non-return valves (2V1 and 2V2)
- Two pilot-operated pressure relief valves (2V3 and 2V4)
- Flushing valve (2V5)
- Clutch/turbo-clutch pressure relief valve (4V4)
- High-pressure safety valve (4V7)

transmission ratio towards slow.

The tractor is placed under load and the engine speed drops. The load limit control only ever changes the

### Control, setpoint transmission ratio has been reached.

The electronics detect the setpoint engine speed from the position of the throttle pedal by means of the analogue position sensor (potentiometer) on the pedal.

The electronics detect the setpoint engine speed from the position of the throttle pedal by means of the

manual). The default setting for load limit control is 14%

is started. However, the reduction in engine speed can be adjusted from 0 to 30 percent (see operator's slow so that the engine speed does not drop too far. Load limit control is always enabled once the engine

The engine speed is reduced when a load is applied. The electronics change the transmission ratio towards

### Load limit control (restricting the reduction in engine speed or adaptation to the engine speed)

the reference point (precise neutral point between forward and reverse travel)

point between forward and reverse travel) When the engine has started, the actuator unit (A009) locates When ignition is switched on, the actuator unit (A009) searches for the reference point (approx. neutral

6. Slip clutch 2,5 Nm to 3,5 Nm, less than 5 Nm at socket wrench of the emergency actuation.

5. 12 V<sub>DC</sub> electric motor; 0.4 A to 7 A; actuator unit (A009) no-load speed of 4500 rpm

4. Transmission  $i = 192:1$  (electric motor to actuator shaft)

3. Increment sensor: position sensor with digital resolution emitting 8000 pulses per revolution

2. Clutch for the drive

1. Drive for emergency mode (required in case of failure of the electronic control system)

The voltage level can be checked at the CAN bus sockets. The actuator unit (A009) controls the actuator shaft, thereby changing the transmission ratio in the ML transmission. The actuator unit (A009) comprises:

- **G BUS** - transmission BUS
- **K BUS** - comfort BUS
- **V BUS** - valve BUS
- **ISO BUS** - For attaching ISO implements

In the FENDT 800 Vario, data is transmitted via 4 CAN buses.

The CAN BUS is a data line and connects various components (also called users) with each other. If a large quantity of data is to be transmitted, the voltage in the CAN bus (positive and negative cable) increases.

### Electrical/electronic control

of dry running.

variable-displacement pump (2P1) and variable-displacement motor (2A1) may become damaged as a result

filtered through connection PU (measuring point M5). If the oil pressure filling is not performed, the

as in a normal mechanical gear transmission. If there is no oil in the high-pressure circuit, the transmission must be filled from an external pressurized filling unit. During filling, the transmission oil is additionally

**NOTE:** Filling the ML180 transmission with oil

The clutch and turbo-clutch function is controlled by the pressure relief valve (4V4).

If the two high-pressure limiting valves (2V3 and 2V4).

If the clutch pedal, hand brake or neutral switch is operated, the high-pressure circuit is depressurised by

engine has been started.

In the emergency mode switch position, the actuator shaft (3Z1) is actuated manually from the cab. In the emergency mode switch position, the transmission is automatically locked at approx. 30 km/h after the

variable-displacement motor (2A1) swivel accordingly.

setting the correct quantity of oil to be supplied or consumed. The variable-displacement pump (2P1) and

actuator shaft (3Z1). The actuator shaft (3Z1) is rotated as required by the actuator unit (A009), thereby

directional control valves (3V1 and 3V2). The 4/3-directional control valves are mechanically actuated by the servo cylinders (3A1 and 3A2) on the variable-displacement pump and motor are actuated by two 4/3-

- Test connection (PH)

- Crankshaft speed sensor (B088) and camshaft speed sensor (B085) measure the engine speed and report it to the engine control unit. This is transmitted to the A050 basic control unit via the G bus.
- The Hall sensor collecting shaft (B014) and bevel pinion (B015) measure rotational speed and detects the direction of rotation.
- High-pressure sensor (B008) transmits the current oil pressure in the high-pressure circuit to the electronic system.
- Clutch pedal sensor (B017) electronically monitors clutch pedal travel. Before the clutch is engaged, the transmission ratio is reduced. Starting up in travel speed range I approx. 5 km/h, starting up in travel speed range II approx. 10 km/h.
- Travel speed range detection sensor (B016) electronically monitors range control travel.
- Temperature sensor (B009) monitors the temperature of the transmission oil. Temperatures above 110 °C are logged with a fault code.
- Rotary position sensor (B055) electronically monitors the pedal travel of the throttle pedal.
- Transmission neutral/turbo-clutch solenoid valve (Y004) controls the turbo-clutch function. The high-pressure valves open depending on the engine speed.
- Speed governor solenoid valve (Y005) cancels the speed restriction to approx. 30 km/h when the electronics are operational. Speed governing is cancelled if  $800\text{mA} \pm 50\text{mA}$  is applied to the solenoid.
- The filter contamination pressure switch (S017) monitors clogging of the pressure filter on the ML transmission.
- Hand brake switch: When the hand brake is applied, the two high-pressure valves open. The two F/R lamps flash. The transmission is switched to neutral.
- The joystick is in the multifunction armrest.

**Sensors**

*Since the load limit control only changes the transmission ratio towards slow, it is beneficial to switch on cruise control. If the engine speed rises again with cruise control switched on, the transmission ratio is restored to the maximum stored speed. Control using the load limit control + cruise control can be dampened or accelerated using the accelerator ramp switch on the joystick.*

**NOTE:**

This means that the load limit control changes the transmission ratio towards "slow" from a speed of 1620 rpm. Theoretically, the load limit control will adjust the transmission ratio whilst under load until the road speed reaches zero.

<b>Example:</b>	
Engine speed according to throttle pedal position	2000 rpm
Load limit control setting 10% =	200 rpm
2000 rpm - 180 rpm = 200 rpm =	1620 rpm

The load limit control is enabled by:  
Reduction in engine speed of over 180 rpm + set value.



**5.1.2 Transmission function diagram**

- Planet gear diagram**
- (A) Planetary carrier (driven from the engine)
  - (B) Ring gear (drive to pump)
  - (C) Planet gear
  - (D) Sun gear (drive to collecting shaft)




Fig. 1

**Transmission diagram**





Fig. 2

- (A) Mechanical power flow
- (B) Hydraulic power flow
- (C) PTO drive
- (D) 4WD
- (1) Planet gear
- (2) Hydraulic pump
- (3) Collecting shaft
- (4) Hydraulic motor
- (5) Range control

Engine running, tractor stationary  
(A) Mechanical power flow  
(B) Hydrastatic power flow


Fig. 3



Operating status: Active standstill

(A) Mechanical power flow  
(B) Hydrastatic power flow  
**Power transmission:** 1% mechanical and 99% hydrastatic


Fig. 4



Operating status: Start off

(A) Mechanical power flow  
(B) Hydrostatic power flow  
**Power transmission: 50% mechanical and 50% hydrostatic**

Fig. 5




Operating status: Driving at average speed

(A) Mechanical power flow  
(B) Hydrostatic power flow

(Speed is dependent on engine speed)

**Power transmission:** Hydro motor 0° swung out, thus 100% mechanical

Fig. 6



Operating status: Transport




### 5.1.3 Transmission diagram ML400

(A) Mechanical power flow  
 (B) Hydrastatic power flow

Ring gear rotates faster than the combustion engine

Power transmission: 100% hydrastatic

Fig. 7




Operating status: Driving in reverse at average speed

- Hydrostatic pump HP (2) is swung in and therefore at zero delivery.
- Hydrostatic motor HM1 (4) is swung out to 45°.
- Hydrostatic motor HM2 (5) is swung out to 45°.

**Active stationary**

- |     |                                 |      |  |
|-----|---------------------------------|------|--|
| (1) | Planet gear                     | (1)  | Vibration damper (hydrodamp)                     |
| (2) | Hydrostatic pump (HP)           | (A)  | Planetary carrier (drive from combustion engine) |
| (3) | Collecting shaft                | (B)  | Planet gear                                      |
| (4) | Hydrostatic motor 1 (HM1)       | (C)  | Ring gear (drive to hydrostatic pump)            |
| (5) | Hydrostatic motor 2 (HM2)       | (D)  | Sun gear (drive to collecting shaft)             |
| (6) | 4WD clutch (AK)                 | (HA) | Rear axle  |
| (7) | disc clutch (engagement of HM2) | (VA) | Front axle                                       |
| (8) | Towing position to rear axle    |      |  |
| (9) | Towing position to front axle   |      |  |

Fig. 8



Presentation of transmission diagram: engine running, tractor stationary (active standstill)

## 5.2 Emergency mode

### 5.2.1 Driving in emergency mode

#### General

Two types of emergency operation are available:

1. Transmission adjustment via the multiple display (all current series).

2. Mechanical transmission adjustment via the auxiliary lever (from 500 Vario S4 to 1000 Vario S4).

This is possible due to the different transmission control units.

#### Transmission control unit

##### Slim version, from 200 Vario to 300 Vario S4

This transmission control unit does not permit mechanical transmission adjustment. The transmission adjustment is only possible via the multiple display.

##### A074 - Slim actuator unit




-  Right side of tractor on transmission housing
-  Remove right rear wheel and panel

Fig. 9



##### Normal version, from 500 Vario S4 to 1000 Vario S4

Both types of emergency mode are possible.

##### A009 - actuator unit

X037 - separation point on actuator unit





-  On the right side of the transmission
-  Remove right rear wheel.
-  Remove metal panel

Fig. 10



### 1. Transmission adjustment via the multiple display

If the transmission ratio can no longer be adjusted using the electronic system due to actual or indicated faults, the transmission adjustment can be performed electronically via the keypad. If the forward/reverse arrows are no longer displayed on the instrument panel, this indicates a fault in the gear ratio setting. For emergency mode, the power circuit for the transmission must first be activated. Depending on the fault, the transmission ratio can then be adjusted using the keypad.



### Activate clutched traction



**NOTE:**




Only one clutched traction can be activated! Neither a change of direction nor a change of speed ratio can be activated.


### Switch-on conditions

- Engine is running.
- Emergency mode available; no forward or reverse arrows in the instrument panel.
- Clutch pedal fully depressed.
- No turboclutch valve fault.
- No clutch pedal sensor fault
- No fault in engine speed sensor/bus connection to engine.

-  Press button. The first main menu level appears on the multiple display.
-  Press one of the buttons repeatedly until the symbol (A) flashes.

-  Press button. The second main menu level appears on the multiple display.
-  Press one of the buttons repeatedly until the symbol (A) flashes.

-  Press button. The image opposite appears on the multiple display.
-  Press one of the buttons repeatedly until the symbol (A) flashes.
-  Depress clutch pedal fully.

-  Press button.

**NOTE:**  
If there is a clutched traction, proceed with "Mechanical selection of gear ratio".

**Symbol (B) appears:**

- Clutched traction not available.




Fig. 11




Fig. 12




Fig. 13




Fig. 14

**NOTE:**

If there is no clutched traction, emergency operation is not possible. Vehicle must be towed.

**Drive with the arrow buttons (transmission control unit OK)**

**NOTE:**

The clutch pedal must be engaged carefully, as a gear ratio or a travel direction may be preselected!

**NOTE:**

When travelling uphill, do not disengage the clutch! Maximum road speed approx. 10 km/h.

**NOTE:** When using emergency operation, travel direction indicators are no longer active.

In emergency mode, there are two potential options for transmission adjustment. If the transmission adjustment can still be made using the keys on the keypad, the adjacent image is displayed after the emergency mode is activated.

Image(A) appears in emergency mode.

- Frictional connection of the transmission present
- No transmission control unit fault ((04.1.A1) to(04.1.A6)).



Press key multiple times (confirm error code). The image opposite appears on the multiple display.

**NOTE:**

The number (1500 in this example) is used to display the gear ratio. If the transmission ratio is changed by the operator using the arrow keys on the control panel, the value in the display also changes. If 0 is displayed, the transmission is engaged without travel direction — only if(A) is not displayed.



The required transmission ratio is adjusted using the arrow keys. If the clutch is released with the transmission in the neutral position, the tractor is set in motion by actuating the arrow keys.

**NOTE:**

If the symbol(A) is displayed, there is no transmission of power available at the transmission. Power circuit must be activated.

Fig. 18




Fig. 17




Fig. 16





Fig. 15



**Exit emergency mode**

- Stop the tractor.
- After switching the ignition Off, wait approx. 5 seconds.
- Ignition ON, emergency operation is ended.

**2. Mechanical transmission adjustment via the auxiliary lever**

**Access to the auxiliary lever for 500 – 700 Vario S4**

- Remove part of the floor mat by pulling it out



Fig. 19

- Use your right hand to hold up the floor mat and at the same time use your left hand to push the floor mat into the corner. This allows the floor mat to be pulled out from under the side panel and folded down



Fig. 20

- Unscrew bolts (E) and remove cover




Fig. 21

**Access to the auxiliary lever for 800 – 1000 Vario S4**

- Partially remove floormat, by pulling the floormat on the right next to the operator's seat out.

- Pull back the floormat until the cover (A) of the emergency operation is exposed.

- Unscrew bolts (B) and remove cover.



Fig. 22




Fig. 23




Fig. 24

**Drive with auxiliary lever (transmission control unit faulty)**

**NOTE:**

Do not use the auxiliary lever if the gear ratio can be set electronically (with keypad). When setting the gear ratio, only the auxiliary lever supplied should be used, otherwise the clutch in the transmission control unit may be overtorqued (maximum permissible torque 10 Nm).

**NOTE:**

The gear ratio can only be adjusted mechanically if a travel range is set. If no travel range is set, refer to the chapter "Set travel range".

**NOTE:**

The clutch pedal must be engaged carefully, as a gear ratio or a travel direction may be preselected!

**NOTE:**

When travelling uphill, do not disengage the clutch! Maximum road speed approx. 30 km/h.

**Switch-on conditions**

- Engine is running.
- Transmission adjustment unit is faulty.
- Emergency mode available (no forward or reverse arrows in the instrument panel).
- Clutch fully depressed.
- No turboclutch valve fault.
- No clutch pedal sensor fault.
- No fault in engine speed sensor/bus connection to engine.

**NOTE:**

The clutched traction must be activated, see above.

- Open or remove cover in cab floor.

**NOTE:**

See the chapter "Access to mechanical emergency operation"  
Attach auxiliary lever (A) to transmission adjustment.

**NOTE:**

Auxiliary lever is included in the standard delivery and is located in the tool box.

- Carefully engage clutch pedal.

The tractor starts moving in the last selected travel direction and accelerates up to the selected transmission ratio.

- If the auxiliary lever is pulled to the left when in forward travel, the tractor accelerates. If the auxiliary lever is pulled to the right, the tractor decelerates. The tractor is braked.
- If the auxiliary lever is pulled to the right when in reverse travel, the tractor accelerates. If the auxiliary lever is pulled to the left, the tractor decelerates. The tractor is braked.

**Exit emergency mode**

- Stop the tractor.
- After switching the ignition OFF, wait approx. 5 seconds.
- Ignition ON, emergency operation is ended.

**Set travel range**

**DANGER:** When putting the transmission into the neutral position, there is a danger of the tractor rolling away. Chock the vehicle to prevent it from rolling away.

Fig. 26




Fig. 25





**NOTE:**

In the current series, the travel range selector is only available from 500 Vario S4 to 900 Vario S4.

**Mechanical travel range selector 500 – 700 Vario S4**

**NOTE:**

Shown without the left rear wheel for clarity.

**Selector direction:**

- Bottom — travel speed range I (field)
- Center — towing position (neutral)
- Top — travel speed range II (road)




Fig. 27

**Mechanical travel range selector 800 – 900 Vario S4**

**NOTE:**

For greater clarity, this is shown without the right rear wheel and with the linings removed.

- Attach auxiliary lever to the travel speed range selector.
- Depress the clutch pedal.

**NOTE:**

An extension can be used as an aid for selecting the operating range. The max. travel speed for any range selection is 2 km/h.

**Selector direction:**

- Right — travel speed range I (field)
- Center — neutral position N (neutral)
- Left — travel speed range II (road)




Fig. 28

**5.2.2 Towing**



**WARNING:**

Towing the tractor is not possible or permitted, as this may damage the transmission.



**WARNING:**

Towing is only possible once the transmission has been put into the neutral position mechanically, if this is not the case, then towing will cause the transmission to be damaged. Before towing, please make sure that there is sufficient oil in the axles and transmission, particularly if there is visible oil loss!



**DANGER:**

Before putting the transmission into the mechanical towing position, secure the vehicle to prevent it from rolling away.

**NOTE:**

Maximum speed 10 km/h  
Maximum distance 8 km

### Procedure

- Engine off.
- Apply the parking brake.
- Open the cover in the cab floor, see "Access to the auxiliary lever" (only required from 800 to 900 Vario S4).
- Use the gear selector (from 200 to 700 Vario S4 and 1000 Vario S4) or auxiliary lever (800 and 900 Vario S4) to put the gearbox into the neutral position.
- Turn the ignition to position I. Display for mechanical neutral position appears in the multiple display.




Fig. 29

- Use a tow bar to connect the towing vehicle to the tractor. Secure the tractor to prevent it from rolling away.
- Release the parking brake. If it is not possible to release the parking brake, perform an emergency release.
- When parking, secure the vehicle to prevent it from rolling away.

**NOTE:**

In the current series with two travel ranges (500 – 900 Vario S4), the calibration code 4003 can also be used to put the gearbox into the neutral position. However, the engine must be capable of running. See "Calibration code 4003 (travel range selector)".



**WARNING:**

If the engine is not running, the hydraulic braking and steering assistance will not function. When there is no pressure in the compressed air system, the hand brake is locked. This means that when the service brake is operated, there will be no braking effect and greater effort is required for steering, which renders the vehicle uncontrollable. This may result in an accident.

Tow the vehicle, if possible, with the engine running. If this is not possible, ensure that the lack of braking effect and the more difficult steering do not pose additional hazards for yourself and other road users. Towing is generally permitted only with use of a tow bar. Use only the specified trailer points on the vehicle for towing. Do not attach any aids such as tow bars, chains or cables to implements, or any aids such as tow chains or cables to or in the cab.

**NOTE:**

After towing, use the gear selector or auxiliary lever to return the gearbox to the engaged position.

**Mechanical neutral position**  
**200 Vario V/F/P S3**

Switch the gearbox with the lever.

A Gearbox in neutral

E Gearbox coupled with axle drive

**NOTE:**

*Position of the lever: rear left on the linkage.*

**200 Vario S3 and 300 Vario S4**

Put the transmission in neutral with lever (A).

**NOTE:**

*Position of the lever: rear left under the cab.*

**500 – 700 Vario S4**

Position lever (A) on the left-hand side under the cab to the marking (B) (neutral position of travel range).

**NOTE:**

*Shown without the left rear wheel for clarity.*




Fig. 30




Fig. 31




Fig. 32

**800 – 900 Vario S4**

Attach auxiliary lever (located in the tool box) on the travel range selector. Shift transmission into neutral (arrowed).

**NOTE:**

Position of the travel range selector: on the right under the cab. To do this, open the cover in the cab floor. For greater clarity, this is shown without the rear wheel and with the lining removed.




Fig. 33

**1000 Vario S4**

Press up the locking plate (B) and thus unlock the neutral position.

Unlock gear lever (A) and pull it backwards until the lever clicks into place.

**NOTE:**

Position of the lever: rear right under the cab.




Fig. 34

It may happen that the gearbox will not switch into neutral because the switching mechanism is loaded (front axle drive and rear axle drive interlocked against each other). In this case you need to jack up at least one front wheel or create pressure by quickly pumping the auxiliary pump (arrow) at the rear end of the tractor. This opens the 4WD clutch, and the drive train is relieved. Then you should be able to switch into neutral.





Fig. 35

FH00298

FH00318











## 6. Electrical system/electronics

<b>6.1 Procedure</b> .....	6-3
6.1.1 Button & switch functionality .....	6-3
6.1.2 Hall sensor operation .....	6-8
6.1.3 Rotary position sensor function, when used as a current divider .....	6-14
<b>6.2 Measure and test</b> .....	6-20
6.2.1 Measure and test .....	6-20
6.2.2 Component position .....	6-26
<b>6.3 CAN BUS</b> .....	6-28
6.3.1 Description of CAN bus system .....	6-28
6.3.2 FENDT 300 Vario S4 electronics concept - Profi/ProfiPlus .....	6-29



## 6.1 Procedure

### 6.1.1 Button & switch functionality

The purpose of the buttons & switches are to supply a digital signal to the E-box. By operating the S1 button or switch, it opens or closes so that with S1 open there is a total resistance of 510 ohms and with the S1 closed there is a total resistance of 121 ohms. The E-box (A002/A050) generates a U1 basic signal voltage that is reduced to the U2 voltage by the resistances to earth.

#### Measure signal voltage at pin 2 and pin 1





Fig. 1

Axxx E-box	A002 comfort ECU e.g.: 700 COM II A050 basic control unit ECU e.g.: 900 COM III
Sxxx button or switch	Pin assignment on buttons or switches 1 = earth 2 = signal 3 = control LED supply (not always fitted)

Basic signal voltage	A050	6.1 V
U1	A002	8.0 V

Voltage	A050	A002	Note
U1			Switch ignition ON. E-box must send out the basic signal voltage
U2			The basic signal voltage must be present up to the point of the break.
U3			

Fig. 2



Error pattern for a break in the signal wiring

Voltage	S1	A050	A002
U2	Open		
	Closed		

Error pattern for a short circuit in the signal wiring





Fig. 3

Voltage	A050	A002	Note
U2			
<b>Diagnostic steps</b>			
1. Disconnect the button or switch			Switch has a short circuit
Measure at the plug			Short circuit in the signal wiring or the E-box is faulty
2. on the E-box Open the bridge from the adapter box			Short circuit in the signal wiring
Measure to the E-box			E-box faulty

Voltage	A050	A002	Note
U2			
Diagnostic steps			
1. Button Disconnect			Button has an earth connection
2. on the E-box Measure with adapter box			Break in the wiring, earth connection in the signal wiring or E-box is faulty
3. Open bridge on adapter box Measure to the E-box			Break in wiring
			Earth connection in the signal wiring or E-box is faulty
			Earth connection in the signal wiring
			E-box faulty

Fig. 4



Error pattern for an earth connection in the signal wiring

**Switches without diagnostic capability for breaks in wiring are:**  
**Measure the signal voltage at pin 2 and pin 1**  
**Switch open**  
 Resistance R = infinite => signal voltage = 6.1 V<sub>DC</sub> (A050), 8.0 V<sub>DC</sub> (A002)  
**Switch closed**  
 Resistance R = approx. 0 ohms => signal voltage = 0 V<sub>DC</sub>

*Other buttons or switches fitted on the tractor:*

DIN	Designation
A009	actuator unit
B014	collecting shaft sensor
B015	bevel pinion sensor
S005	right brake switch
S006	left brake switch
S017	filter contamination switch
S019	left external rear PTO button
S020	right external rear PTO button
S021	raise external front power lift button
S022	lower external front power lift button
S025	variable displacement pump pressure monitoring switch
S027	right raise external rear power lift button
S028	right lower external rear power lift button
S029	left raise external rear power lift button
S030	left lower external rear power lift button
S045	reverse drive control switch
S053	operator's seat switch
S067	raise external valve actuation button
S068	lower external valve actuation button
S079	forward/reverse shuttle switch
S080	hand brake switch
S086	right brake wear indicator switch
S087	left brake wear indicator switch

**6.1.2 Hall sensor operation**

The purpose of the Hall sensor is to measure the speed. The rotation of the impulse disk or gear wheel on the Hall sensor opens or closes the S2 sensor switch.  
 Impulse disk position A indicates that the impulse disk is at a low point: sensor switch open.  
 Impulse disk at position B indicates that the impulse disk is opposite the Hall sensor: sensor switch closed.  
 Power supply diagnostics are available for the Hall sensor, i.e.:  
 Supply OK = S1 diagnostics switch closes  
 The basic signal voltage from the E-box is reduced.

**Measure supply at pin #3 and pin #1**

Voltage = **12 to 14 Vdc** (depending on on-board voltage)

**NOTE:**

See also  
 Functional description: electronics box  
 Electrical wiring diagrams  
 Electrical/Electronic components — measuring and testing


DIN	Designation
S026	steering pump flow monitor switch
S075	wheel-driven steering pump flow-monitor switch



Fault code	Signal voltage		Switch S2 (Frequency)	Switch S1 (Diagnostics)	Supply
	A002	A050	Open	Open	0 V <sub>DC</sub>
Yes			Open / closed	Closed	12 V <sub>DC</sub>
No					


<b>A013</b> microfuses PCB	<b>A002</b> comfort ECU e.g.: 700 COM II <b>A050</b> basic control unit ECU e.g.: 900 COM III	Pin assignment on the sensor 1 = earth 2 = signal 3 = supply
<b>Bxxx</b> - Hall sensor		

Fig. 5



		Closed	Closed	U4
		Open	Closed	
A002	A050	S2	S1	Voltage

Fig. 6




**NOTE:**

The G931.970.020.042 active sensor was introduced from build date 04/2009.  
Please note KDM 02/2010

Voltage	A050	A002	Note
U1			Switch on the ignition; the E-box must send out the stabilized voltage of 8.5 V, thus closing the TLE in the microfuse board supply and the power supply is activated.
U2			The basic signal voltage must be present up to the point of the break.
U3			G816.970.020.040 passive sensor Ratchet wheel position is not important Plug color black
			G931.970.020.042 active sensor Voltage value dependent on impulse disk position Plug color gray


Fig. 7



Error pattern for break in the signal wiring

Voltage	A050	A002	Note
U4			
Diagnostic steps			
1. Disconnect sensor			Sensor has a short circuit
			Short circuit in the signal wiring or the E-box is faulty
2. on the E-box			Short circuit in the signal wiring
Open the bridge from the adapter box			E-box faulty

Fig. 8



Error pattern for a short circuit in the signal wiring



**Description of position sensor function (angle/current)**

The position sensor is used to detect angles. The sensor is supplied with **8.5 VDC** by the ECU/EXT via the **A013** microfuses PCB. The earth of the rotary position sensor goes to the ECU/EXT (**sensor system earth**). The position sensor is equipped with an **electronic current divider**, which sends a signal current of **4-20 mA** to the E-box depending on the angular position. Measured with the adapter cable, a signal voltage of **0.6-4.2 V<sub>DC</sub>** is generated. If the supply (positive or earth) is not OK, no signal is transmitted; an error code appears. The E-box **does not** supply basic signal voltage. **To compensate for mechanical and electrical tolerances in sensors, the sensor must be calibrated.**




Fig. 11

**Position sensor (angle/current) pin assignment**

1 = earth  
 2 = +supply  
 3 = signal

Fig. 10



**6.1.3 Rotary position sensor function, when used as a current divider**

Hall sensors fitted on the tractor are:

DIN	Designation	Note
B015	bevel pinion sensor (speed)	8.5 V supply
B020	rear PTO (stub shaft) speed sensor	
B021	rear PTO (clutch) speed sensor	

Measure the supply and signal voltage




Fig. 12


<b>A013</b> microfuses PCB	<b>A002</b> comfort ECU e.g.: 700 COM II <b>A050</b> basic control unit ECU e.g.: 900 COM III
<b>Bxxx</b> rotary position sensor	Pin assignment on the sensor 1 = earth 2 = supply 3 = signal

<b>Supply</b>	U1	8.5 V	<b>Note</b> Ignition ON, E-box supplies 8.5 V (stabilized) voltage, Microfuse OK
---------------	----	-------	---

<b>Signal</b>	A1	4-20 mA	<b>Note</b> Depending on the sensor position, the current is processed in the E-box (current input)
	U2		The voltage can be easily measured using the adapter cable (at the sensor). (connected in parallel to the multimeter)

Reading		Note
U1	8.5 V	Ignition ON, E-box supplies 8.5 V (stabilized) voltage, Microfuse OK
A1	0 mA	No current flow when there is a break in the wiring
U2		The signal comes from the sensor, ( <b>no</b> basic signal voltage from the E-box at the current input)
U3		Sensor tries to supply a current. A current cannot flow due to a wiring break, therefore voltage is used. Voltage is <b>not</b> dependent on the sensor position.

Fig. 13




Error pattern for a break in the signal wiring



Diagnostic steps	U4	<p>1. Disconnect sensor</p> <p>2. At the E-Box open the bridge of the adapter box</p> <p>Measure to the E-box</p>
Sensor has a short circuit	Short circuit in the signal wiring or the E-box is faulty	Short circuit in the signal wiring
		E-box faulty

Error pattern	U2	Note	Short circuit due to supply
---------------	----	------	-----------------------------

Fig. 14




DIN	Designation	Note
B016	travel range detection sensor	
B017	clutch pedal sensor	
B040	front power lift position sensor	
B055	foot throttle sensor	Combination sensor (current divider/voltage reducer)

Diagnostic steps	U4	
1. Connect multimeter U4	Earth connection in the sensor, wire or E-box	
2. Disconnect sensor	Sensor faulty	
3. Open bridge on adapter box	Earth connection in the wire or E-box	
	E-box faulty	
	Earth connection in signal line	

Error pattern	U2	Note
		U1=8.5 V, the sensor can only provide a signal if it has a power supply

Fig. 15



Error pattern for an earth connection in the signal wiring

**NOTE:**  
 See also  
 Functional description: electronics box  
 Electrical wiring diagrams  
 Electrical/Electronic components — measuring and testing

**To compensate for mechanical and electrical tolerances in sensors, the sensor must be calibrated.**

*Other rotary position sensors (angle/current) that are installed on the tractor:*

DIN	Designation	Note
B066	left wheel position sensor	
B067	steering angle sensor	
B068	right wheel position sensor	

**6.2 Measure and test**

**6.2.1 Measure and test**



**A007 - Instrument panel**

Connect the X899,980,208,100 adapter box to the A007 instrument panel using the X899,980,208,204 adapter cable

Pin at separation point	Pin on the adapter box (68-pin)
X101 separation point "yellow" (1 to 26)	1 to 26
X100 separation point "blue" (1 to 26)	31 to 56




Fig. 16





Fig. 17 Plan view onto the handle shell (connector)

EKI01732

Fig. 18



If voltage drop is greater than approx. 1 VDC, remove contact resistors (e.g. at fuse).

**NOTE:**

Measure the supply voltage (UB 15) for the A007 instrument panel

Test	Pin	Specified value	condition	Possible cause of fault
Supply	9	0 VDC	Ignition OFF	Fuse (F42) in X1445 fuse holder or in wiring set (see also electrical wiring diagram for supply to electronics)
	9	14.0 VDC	Ignition ON	
Electronics earth	12			
Supply	9	Voltage drop max. 1 VDC	Voltage drop max. 1 VDC	Voltage must remain stable even under load. If voltage drop is greater than approx. 1 VDC, remove contact resistors (e.g. at fuse).
Electronics earth	12			

X101 separation point "yellow" UB 15 (switched voltage, ignition switch)

Measure the supply voltage (UB 30) for the A007 instrument panel

Test	Pin	Specified value	condition	Possible cause of fault
Supply	8	12.0 VDC	Engine OFF, Ignition OFF	Fuse (F59) in X1446 fuse holder or in wiring set (see also electrical wiring diagram for supply to electronics)
	8	14.0 VDC	Engine is running	
Electronics earth	12			
Supply	8	Voltage drop max. 1 VDC	Voltage drop max. 1 VDC	Voltage must remain stable even under load. If voltage drop is greater than approx. 1 VDC, remove contact resistors (e.g. at fuse).
Electronics earth	12			

X101 separation point "yellow" UB 30 (battery voltage)

- Diagnostic PC with current FENDIAS software
- X899.980.246.205 adapter cable - connection to sensor
- Adapter box X899.980.304.000

**Recommended tools**




Signal	pin 2	approx. 1.6 V <sub>DC</sub>	Rear PTO rotates	<b>Unplug component:</b> If measured value is 0 V <sub>DC</sub> : fault in <b>A050</b> - Basic control unit ECU (EXT) or in wiring. If measured value is 6.4 V <sub>DC</sub> : fault with the component.
	pin 1	1.0 V <sub>DC</sub> or 5.0 V <sub>DC</sub>	Rear PTO stationary	

Test	Pin	Specified value	condition	Note
+UB	pin 3	12 V <sub>DC</sub> to 14 V <sub>DC</sub>	Ignition ON	Microfuse (S35) in A013 or wiring faulty.
Earth	pin 1			

**Measurement at component - separation point X169**

Pin assignment	B020 - Rear PTO stub shaft speed sensor	A050 - Basic control unit ECU (EXT)
Earth	#1 (X169)	#A46 (X1403)
Signal	#2 (X169)	#A10 (X1403)
+UB	#3 (X169)	-

Fig. 19



**B020 - Rear PTO stub shaft speed sensor**


Test	Pin	Specified value	condition	Note
+UB	pin 2	8.5 V <sub>DC</sub>	Ignition ON	Microfuse (S19) in A013 or wiring faulty.
Earth	pin 1			

**Measurement at component - separation point X898**

Pin assignment	B055 - Foot throttle sensor	A050 - Basic control unit ECU (EXT)
Signal	#6 (X898)	#A29 (X2186)
+UB	#5 (X898)	#A20 (X2186)
Earth	#4 (X898)	#A84 (X2186)

Pin assignment	B055 - Foot throttle sensor	A050 - Basic control unit ECU (EXT)
Signal	#3 (X898)	#B18 (X1402)
+UB	#2 (X898)	-
Earth	#1 (X898)	#A45 (X1403)

Fig. 20



**B055 - Foot throttle sensor**

- Adapter cable X899.980.304.201 - connection to adapter box

**NOTE:**

- Diagnostic PC with current FENDIAS software
- Adapter cable X899.980.246.208 - connection to sensor
- Adapter box X899.980.304.000
- Adapter cable X899.980.304.201 - 58-pin connection to adapter box for X1402 (B)
- Adapter cable X899.980.304.206, 91-pin connection to adapter box for X2186 (A)

**Recommended tools**

Test	Pin	Specified value	condition	Note
Signal	#A29	? mAdc	Foot throttle actuated	Remove bridge at pin #29 on adapter box
		? mAdc	Foot throttle not actuated	

Remove bridge at contact #29 on adapter box.

**NOTE:****Measurement on A099 engine control ECU (EDC 17) – separation point (X2186)**

Test	Pin	Specified value	condition	Note
Signal	#B18	19 mAdc	Foot throttle not actuated	Remove bridge at pin #18 on adapter box
		5 mAdc	Foot throttle actuated	

Remove bridge at contact #18 on adapter box.

**NOTE:****Measurement at A050 - Basic control unit ECU (EXT) - separation point X1402**

Signal	pin 6	0.6 Vdc	Foot throttle not actuated	
Signal	pin 6	4.3 Vdc	Foot throttle actuated	
Earth	pin 4			

Signal	pin 3	4.0 Vdc	Foot throttle not actuated	
Signal	pin 3	1.0 Vdc	Foot throttle actuated	
Earth	pin 1			

+UB	pin 5	5.0 Vdc	Ignition ON	A099 - engine control ECU or wiring faulty.
Earth	pin 4			




Pin assignment	S030 - left external rear power lift lower button	A050 - basic control unit ECU (EXT)
Signal	#1 (X240)	#B48 (X1402)
Earth	#2 (X240)	#A46 (X1403)

Pin assignment	S029 - left external rear power lift raise button	A050 - basic control unit ECU (EXT)
Signal	#1 (X239)	#B39 (X1402)
Earth	#2 (X239)	#A46 (X1403)

Pin assignment	S028 - right external rear power lift lower button	A050 - basic control unit ECU (EXT)
Signal	#1 (X238)	#B12 (X1402)
Earth	#2 (X238)	#A46 (X1403)

Pin assignment	S027 - right external rear power lift raise button	A050 - basic control unit ECU (EXT)
Signal	#1 (X237)	#B37 (X1402)
Earth	#2 (X237)	#A46 (X1403)

Fig. 21 (A) Variant with indicator lamp, (B) variant without indicator lamp



S027/S028/S029/S030 - external (rear power lift) buttons




Fig. 22

Cab, at top in steering column unit

A007 - Instrument panel

## 6.2.2 Component position

- Diagnostic PC with current FENDIAS software
- X899.980.246.205 adapter cable - connection to sensor
- Adapter box X899.980.304.000
- Adapter cable X899.980.304.201 - connection to adapter box

### Recommended tools





Test	Pin	Specified value	condition	Note
Resistance	pin 1	510 ohms	Button <b>not</b> pressed	If measured value is 0 V <sub>DC</sub> : There is a fault with the wiring or the A050 ECU If measured value is 6.2 V <sub>DC</sub> : fault in component.
	pin 2	121 ohms	Button pressed	
Signal	pin 1	3.7 V <sub>DC</sub>	Button <b>not</b> pressed	
Earth	pin 2	1.8 V <sub>DC</sub>	Button pressed	

### Measurement at component



Test	Pin	Specified value	condition	Note
Resistance	pin 1	510 ohms	Button <b>not</b> pressed	If measured value is 0 V <sub>DC</sub> : There is a fault with the wiring or the A050 ECU If measured value is 6.2 V <sub>DC</sub> : fault in component.
	pin 2	121 ohms	Button pressed	
Signal	pin 1	3.7 V <sub>DC</sub>	Button <b>not</b> pressed	
Earth	pin 2	1.8 V <sub>DC</sub>	Button pressed	


**B020** - Rear PTO (stub shaft) speed sensor  
**B021** - Rear PTO (clutch) speed sensor


*Flange PTO version*

 Rear of tractor, rear of the rear axle cover  
 Detach panel

**B055** - Foot throttle sensor

 Cab, on left foot throttle  
 Detach cover

**S027** - Right external raise rear power lift button  
**S028** - Right external lower rear power lift button  
 Rear of tractor, on right mudguard

**S029** - Left external raise rear power lift button  
**S030** - Left external lower rear power lift button  
 Rear of tractor, on left mudguard




Fig. 23




Fig. 24




Fig. 25




Fig. 26

## 6.3 CAN BUS

### 6.3.1 Description of CAN bus system

#### Description

In a bus system, all components are connected to a common data line via short branch lines. This reduces the wiring requirements and allows additional components to be connected more easily.

A Controller Area Network (CAN) connects several components with equal priority over two data lines. All subscribers are called nodes. The nodes are positioned on the data line like the bus stops on a bus route, hence the name "bus". Bus. The CAN bus is a serial bus system.

A CAN bus means that, for example, data from electrical control valves is no longer sent to the electronics box from each valve individually, with numerous specific lines for different data. Instead, data is collected on site, directly at the valve, and is then collected, pre-processed, digitized and only then sent via the bus. In so doing, the nodes filter out unimportant data after having been programmed appropriately, so that this data does not need to be transported at all.

#### Signal transmission

To protect the system from electrical interference, one bit is simultaneously represented on two lines:

CAN-Low and CAN-High. The first line carries the logical signal and the second line carries the inverted data signal. This is called a differential signal.

All the information is sent and received via this data line. The information is coded as numerical signals (0 or 1). Each component recognizes the messages intended for it and processes these messages.

The CAN may be in one of two different states:

- Bus is logically high: recessive state
- Bus is logically low: dominant state

The dominant state represents a logical zero: if a component puts a logical zero on the bus, it overwrites the logical one of another node.

The "neutral" voltage is  $2.5 V_{DC}$  on an active bus (LBS). On a passive bus (K-Bus, G-Bus) the lines are given a pre-voltage of  $1.6 V_{DC}$  or  $3.2 V_{DC}$ .




Fig. 27

On a passive CAN bus, the two parallel-terminated terminating resistances are checked. On an active CAN bus, a voltage value is determined.

The transmission rates are as follows:

- K-Bus (main bus): 100 kBit/s
- G-Bus: 250 kBit/s
- LBS Bus: 125 kBit/s
- ISO Bus: 250 kBit/s

**Frame**

Communication occurs via telegram. The design of a telegram is standardized and labelled as a Frame. One frame is made up of seven parts:




Fig. 28

Part	Designation	Description
1	Start field	Synchronizes all control units (dominant)
2	Allocation field	Information for receivers and priority information (identifier)
3	Control field	Contains details of the size of the following data field
4	Data field	Contains the actual information
5	Test field	Contains a 15-bit checksum plus end marking
6	Confirmation field	Contains the correct receipt confirmation from other subscribers
7	End field	Marks the end of the message

**Collision test**

Each subscriber may send messages to another subscriber unrequested. This means that several subscribers may want to send messages at the same time. The message with the lowest identifier is permitted to be sent. All subscribers who are not allowed to send messages then become receivers of the message with the highest priority, and re-attempt to send when the bus is free. This process is known as bit arbitration.

**6.3.2 FENDT 300 Vario S4 electronics concept - Profi/ProfiPlus**




Fig. 29

**X400** - ISO socket (rear)

**A050** - Basic control unit ECU (EXT)

### ISO-Bus

**Y181** - Front power lift valve

**Y179** - Position 4 spool valve (green)

**Y178** - Position 3 spool valve (red)

**Y177** - Position 2 spool valve (blue)

**Y176** - Position 1 spool valve (yellow)

**A050** - Basic control unit ECU (EXT)

### Valve bus (V bus)

**A144** - Engine control unit ECU (EDC 17)

**A143** - Nitrogen oxide sensor 2, downstream of SCR catalytic converter

**A142** - Nitrogen oxide sensor 1, upstream of SCR catalytic converter

**A135** - Air mass measurement sensor

**A124** - Wastegate ECU

**A089** - Exhaust gas recirculation actuator unit

**A050** - Basic control unit ECU (EXT)

### Engine bus (M bus)

**A144** - Engine control unit ECU (EDC 17)

**A074** - Slim actuator unit

**A050** - Basic control unit ECU (EXT)

### Transmission bus (G bus)

**A172** - NTOX terminal

**A141** - Multifunction center (MFC)

**A050** - Basic control unit ECU (EXT)

**A007** - Instrument panel

### Comfort bus








## 7. Hydraulics

<b>7.1 Basics</b> .....	<b>7-3</b>
7.1.1 Task sheet: Hydraulic pumps .....	7-3
7.1.2 Basic hydraulic systems .....	7-4
7.1.3 Task sheet: Carry out hydraulic measurement .....	7-7








Note:


Fig. 8



Open system

### 7.1.2 Basic hydraulic systems

Fig. 7



Closed system





Fig. 9

Note:



Load sensing





Fig. 10

Note:



Load sensing

7. Hydraulics



Fig. 12





Fig. 13



Note:









