

HINO Dutro Fault Codes list (PDF)

Diagnostic Code		Detection Trip	Lamp Output	Check	Memory	Item
SAE	TCCS		CE			
P0030 / P0031 / P0130 / P0131 / P0132	21	1	O	×	O	A/F sensor (B1S1)
P0036 / P0037 / P0136 / P0137 / P0138	27	1	O	×	O	A/F sensor (B1S2)
P0087	49	1	O	×	O	Rail pressure abnormality (fixed output)
P0088	78	1	O	×	O	Pump valve abnormality (high-pressure in rail)
P0093	78	1	O	×	O	Fuel leak abnormality
P0095 / P0097 / P0098	23	1	O	O	O	Intake air temperature sensor No.2 (post-turbo intake air temperature sensor)
P0100 / P0102 / P0103	31	1	O	×	O	Mass airflow meter
P0105 / P0107 / P0108	35	1	O	O	O	Pressure sensor
P0110 / P0112 / P0113	24	1	O	O	O	Intake air temperature sensor
P0115 / P0117 / P0118	22	1	O	O	O	Coolant temperature sensor
P0120 / P0122 / P0123	41	1	O	O	O	Throttle sensor
P0168	39	1	O	×	O	Abnormally high fuel temperature
P0180 / P0182 / P0183	39	1	O	O	O	Fuel temperature sensor
P0190 / P0192 / P0193	49	1	O	O	O	Rail pressure sensor with back-up sensor
P0191	49	1	O	O	O	Rail pressure sensor with back-up sensor (out-of-range)
P0200	97	1	O	×	O	EDU abnormality (engine part diagnostic)
P0234	34	1	O	×	O	VN turbo abnormality (closed-side abnormality)
P0263	78	1	×	×	O	Injector abnormality (FCCB abnormality) (No. 1 cylinder)
P0266	78	1	×	×	O	Injector abnormality (FCCB abnormality) (No. 2 cylinder)
P0269	78	1	×	×	O	Injector abnormality (FCCB abnormality) (No. 3 cylinder)
P0272	78	1	×	×	O	Injector abnormality (FCCB abnormality) (No. 4 cylinder)
P0299	34	1	×	×	O	VN turbo abnormality (open-side abnormality)
P0335	13	1	O	×	O	Crankshaft position sensor (open circuit / phase difference /power flicker)
P0335	12	1	O	×	O	Crankshaft position sensor (open circuit)

P0339	13	1	O	×	O	Crankshaft position sensor (NE power flicker)
P0340	12	1	O	×	O	Cylinder recognition sensor (open circuit, power flicker)

Diagnostic Code		Detection Trip	Lamp Output	Check	Memory	Item
SAE	TCCS		CE			
P0340	12	1	O	×	O	Cylinder recognition sensor (during start-up)
P0400	71	1	O	×	O	EGR (FLOW MALFUNCTION)
P0400	71	1	O	×	O	EGR-V
P0405 / P0406	96	1	×	O	O	Lift sensor
P0488	15	1	O	×	O	Intake restriction motor control system
P0500	42	1	O	O	O	Vehicle speed sensor (MT)
P0504	51	1	×	×	O	STP light switch
P0607	89	1	O	×	O	CPU abnormality
P0627	78	1	O	×	O	Pump abnormality (open/short circuit)
P1133	00	1	O	O	O	Exterior accelerator position No. 1 sensor is HIGH
P1143	19	1	O	O	O	Throttle knob is HIGH
P1229	78	1	O	×	O	Pump valve abnormality
P1238	78	2	O	×	O	Injector injection abnormality
P1251	34	1	O	×	O	VN turbo (power flicker)
P1530	92	1	×	×	O	Emergency stop switch system
P1601	89	1	O	×	O	Multiple-point injector correction (EEPROM abnormality)
P1611	17	1	O	×	O	Internal IC abnormality
P1611	17	1	O	×	O	RUN pulse abnormality
P1674	36	1	O	×	O	Exhaust brake VSV system
P2120 / P2122 / P2123 / P2125 / P2127 / P2128 / P2138	19	1	O	×	O	Accelerator position sensor
P2121	19	1	O	×	O	Accelerator position sensor (out-of-range)
P2226 / P2228 / P2229	A5	1	O	O	O	Atmospheric pressure sensor (open circuit)

